

# HART

## STB Multiplexer

### Applications Guide

4/2013

---

The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission of Schneider Electric.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed.

Failure to use Schneider Electric software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

© 2013 Schneider Electric. All rights reserved.

---

# Table of Contents




---

	<b>Safety Information</b> .....	<b>5</b>
	<b>About the Book</b> .....	<b>7</b>
<b>Chapter 1</b>	<b>Getting Started</b> .....	<b>9</b>
	Creating Your First Multiplexer .....	9
<b>Chapter 2</b>	<b>Introducing HART</b> .....	<b>23</b>
	Introducing HART .....	24
	Introducing the STB HART Multiplexer .....	26
	HART Multiplexer Features .....	28
	HART Multiplexer Functions .....	29
	Multiplexer Data Flow .....	31
<b>Chapter 3</b>	<b>Planning the HART Multiplexer</b> .....	<b>33</b>
	Island Segments .....	34
	Extending the Island Bus .....	40
	Enclosing the HART Multiplexer .....	42
	The Power Distribution Modules .....	47
	Logic, Sensor, and Actuator Power Distribution on the Island Bus .....	52
	Understanding Multiplexer Island Power Supply and Consumption .....	56
	Selecting Power Supplies .....	60
<b>Chapter 4</b>	<b>Building the Multiplexer</b> .....	<b>63</b>
	Installing the DIN Rail .....	64
	Installing the HART Enabled Ethernet NIM .....	65
	Creating the Backplane of the Island Bus .....	68
	Terminating the Island Bus .....	71
	Inserting STB Modules into their Bases .....	73
	Installing Extension Segments to the Island Bus .....	76
<b>Chapter 5</b>	<b>Grounding the HART Multiplexer</b> .....	<b>79</b>
	Galvanic Isolation Requirements for Power Supplies on the Island Bus ..	80
	Voltage Cut-out Switching .....	81
	Creating a Protective Ground Connection .....	82
	Creating a Functional Ground Connection .....	84
	Using EMC Kits .....	85

<b>Chapter 6</b>	<b>Assigning an IP Address to the HART Multiplexer . . . . .</b>	<b>93</b>
	Assigning an IP Address to the HART Multiplexer. . . . .	94
	Determining the HART Multiplexer Default IP Address . . . . .	98
<b>Chapter 7</b>	<b>Configuring the HART Multiplexer . . . . .</b>	<b>99</b>
	Auto-Configuring the HART Multiplexer. . . . .	100
	Customizing the HART Multiplexer Configuration . . . . .	103
	Configuring STB AHI 8321 Channel Settings . . . . .	105
	Mapping Data items to the HART Multiplexer Island Data Process Image	108
	Viewing the IO Image for the STB AHI 8321 HART Interface Module. . .	110
	Configuring the STB AHI 8321 Module as Mandatory or Not Present. . .	112
	Data Process Image Items for the STB AHI 8321 HART Interface Module	114
	Using the STB XMP 4440 Optional Removable Memory Card to	
	Configure the Island. . . . .	121
	Applying a Stored Configuration to the HART Multiplexer. . . . .	123
<b>Chapter 8</b>	<b>Wiring the Multiplexer . . . . .</b>	<b>127</b>
8.1	Providing Power to the HART Multiplexer . . . . .	128
	Wiring External Power Supplies to the HART Multiplexer Island. . . . .	128
8.2	Wiring the HART Multiplexer to I/O Modules . . . . .	132
	Resistance Calculation for Current Loop Wiring . . . . .	133
	Setting Analog Output Rise and Fall Times for the STB AHI 8321 Module	134
	STB I/O Wiring Example . . . . .	136
	Quantum I/O Wiring Example . . . . .	141
	Premium I/O Wiring Example. . . . .	146
	M340 I/O Wiring Example . . . . .	151
<b>Chapter 9</b>	<b>HART Device Management Software . . . . .</b>	<b>155</b>
9.1	Configuring HART Devices . . . . .	156
	Using the DTM. . . . .	157
	User Interface Configuration for the HART STB Multiplexer DTM. . . . .	161
9.2	AMS Device Management Software Example . . . . .	171
	Eltima Software <i>Serial to Ethernet Connector Setup</i> . . . . .	172
	Add the Schneider Electric Multiplexer to the AMS Device List. . . . .	176
	Creating a HART Multiplexer Network. . . . .	180
	Managing HART Network Devices . . . . .	185
<b>Glossary</b>	. . . . .	<b>189</b>
<b>Index</b>	. . . . .	<b>201</b>

---

## Safety Information



---

### Important Information

#### NOTICE

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a Danger safety label indicates that an electrical hazard exists, which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

### **DANGER**

**DANGER** indicates an imminently hazardous situation which, if not avoided, **will result in** death or serious injury.

### **WARNING**

**WARNING** indicates a potentially hazardous situation which, if not avoided, **can result in** death or serious injury.

---

 **CAUTION**

**CAUTION** indicates a potentially hazardous situation which, if not avoided, **can result in** minor or moderate injury.

***NOTICE***

***NOTICE*** is used to address practices not related to physical injury.


**PLEASE NOTE**

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and its installation, and has received safety training to recognize and avoid the hazards involved.

---

# About the Book



---

## At a Glance

### Document Scope

This manual describes specific application solutions employing the Highway Addressable Remote Transducer (HART) multiplexer.

The specific configuration settings contained in this manual are intended to be used for instructional purposes only. The settings required for your specific configuration may differ from the examples presented in this manual.

### Validity Note

The solutions described in the manual require the use of the following versions of hardware and software:

- Advantys configuration software version 5.5 with patch 4 build 6, or Advantys Configuration software version 7.0 or higher
- STB AHI 8321 HART interface module, version 1.00 or higher
- STB NIP 2311 network interface module, version 4.00 or higher

---

## Related Documents

For additional information about the STB AHI 8321 HART interface module, refer to the online help files for the Advantys configuration software, and to the following technical publication:

Title of Documentation	Reference Number
Advantys STB Special Modules Reference Guide	31007730 (English), 31007731 (French), 31007732 (German), 31007733 (Spanish), 31007734 (Italian)
Advantys STB Standard Dual Port Ethernet Modbus TCP/IP Network Interface Module	EIO0000000051 (English), EIO0000000052 (French), EIO0000000053 (German), EIO0000000054 (Spanish), EIO0000000055 (Italian)

You can download these technical publications and other technical information from our website at [www.schneider-electric.com](http://www.schneider-electric.com).

## User Comments

We welcome your comments about this document. You can reach us by e-mail at [techcomm@schneider-electric.com](mailto:techcomm@schneider-electric.com).

---

# Getting Started



# 1

---

## Creating Your First Multiplexer

### Overview

The Schneider Electric HART multiplexer acts as a gateway to HART-enabled intelligent field instruments. This example shows you how to get started and build your first Schneider Electric HART multiplexer.


After you complete this chapter, you will be able to see the status and data from HART field instruments on the multiplexer web pages.

This example is intended for use on your test bench. For permanent installation, consult the later chapters of this guide.

### The HART Multiplexer

The Schneider Electric HART multiplexer solution is modular and expandable solution. A single Schneider Electric HART multiplexer can support up to 32 HART channels. The HART protocol communicates at the rate of 1200 baud.

This example shows you how to build the following Schneider Electric HART multiplexer. This example presents the minimum configuration.



- 1 STB NIP 2311 Ethernet network interface module version 4.0 or higher
- 2 STB PDT 3100 power distribution module
- 3 STB AHI 8321 4-channel HART interface module
- 4 STB XMP 1100 terminator plate

## Explosive Environments

The STB AHI 8321 multiplexer is ATEX and FM certified for use in hazardous locations where potentially explosive atmospheres may exist. For details see Explosive Environments in the Advantys STB System Planning and Installation Guide (890 USE 171).

**⚠ DANGER**


### EXPLOSIVE ENVIRONMENT HAZARD

Do not substitute components which may impair suitability for ATEX Ex or FM Class 1 Division 2 certifications.


**Failure to follow these instructions will result in death or serious injury.**

### Task 1: Selecting a DIN Rail

The STB modules in your HART multiplexer are designed to be mounted on a standard high-profile din rail. A standard DIN rail is 35 mm (1.38 in) wide.



The standard DIN rail is 15 mm (0.59 in) deep:



Select a DIN rail that is wider than the cumulative widths of modules you will install on it. In this example, select a DIN rail that is at least 152 mm (6 in) long.

**NOTE:** The HART multiplexer requires 24 Vdc power. If you plan to mount your power supply on the DIN rail, select a DIN rail long enough for both the HART multiplexer modules and the power supply.


### Task 2: Installing the HART-Enabled Ethernet Network Interface Module

Every HART multiplexer includes a single HART-enabled Ethernet network interface module (NIM). The NIM is the first (leftmost) module on the DIN rail.

In this example, use an STB NIP 2311 NIM, product version 4.0 or higher. You can locate the NIM product version (PV), plus the original module firmware version and certification markings, on the face of the NIM as indicated below:





Install the STB NIP 2311NIM directly on the DIN rail in one piece, as follows:

Step	Action
1	Determine the exact location on the DIN rail where you want to position the NIM before you place it on the rail. <b>NOTE:</b> Reserve sufficient space to the right of the NIM for the other island modules you want to mount on the DIN rail.
2	Turn the release screw (2) on the NIM so that the mounting clips on the back are in their relaxed state. 

**⚠ CAUTION****UNINTENDED EQUIPMENT OPERATION**

Do not slide the NIM along the DIN rail. Sliding the NIM can crush the functional ground (FE) contacts on the back of the NIM. Crushed FE contacts can prevent the creation of the FE connection.

**Failure to follow these instructions can result in injury or equipment damage.**


Step	Action
3	<p>Align the mounting clips with the DIN rail and push the NIM straight onto the rail. The slope of the mounting clips causes the rail to open the clips when you apply light pressure.</p> 
4	<p>Push the module pushed on to the rail until the clips snap closed.</p> 



**Task 3: Assembling the HART Multiplexer Backplane**

Unlike the NIM, the remaining island modules are not attached directly to the DIN rail. Instead, each module resides in a base unit that comes with the module. In this example, you will create the HART multiplexer backplane by interconnecting the following sequence of base units:

1. add one STB XBA 2200 base unit (for the STB PDT 3100 power distribution module) to the right of the NIM
2. add one STB XBA 3000 base unit (for the STB AHI 8321 HART interface module) to the right of the PDT base
3. add an STB SMP 1100 termination plate to the right of the PDT base, to terminate the HART multiplexer backplane

Proceeding in a left to right direction from the NIM, follow these steps to create your HART multiplexer backplane:

Step	Action
1	Select the STB XBA 2200 base unit that came with your PDM to place directly to the right of the NIM.
2	Using a small screwdriver with a flat blade no wider than 2.5 mm (0.99 in), move the DIN rail latch on the base unit to its full open position. 


Step	Action
3	<p>Align the contacts on the base with the contact channels on the NIM and push the base toward the DIN rail until the interlocking channels meet. Using the interlocking channels as guides, slide the base toward the DIN rail (push from the center of the base). When the base meets the DIN rail, hold the base unit firmly against the DIN rail and push the DIN rail latch into the locked position.</p> 
4	<p>Select the STB XBA 3000 base unit for the STB AHI 8321 HART interface module. Insert this unit directly to the right of the previous base unit; then repeat steps 2 and 3.</p>
5	<p>Select the STB XBE 1100 termination plate</p>
6	<p>Align the interlocking channels at the top and bottom left of the termination plate with the channels on the right side of the last module base.</p>
7	<p>Using the interlocking channels as guides, slide the plate toward the DIN rail until it snaps onto the rail.</p>  <p><b>NOTE:</b> The illustration, above, displays several base units. The backplane you will construct in this example includes only 2 base units.</p>

#### Task 4: Providing Power to the HART Multiplexer

The next task is to bring 24 Vdc power to the HART multiplexer. You need to supply power to both:

- STB NIP 2311 NIM, which provides logic power to the HART multiplexer modules
- STB PDT 3100 power distribution module, which provides both sensor and actuator power to the island

The following graphic shows you how to provide power supply wiring to the STB NIP 2311 NIM and an STB PDT 3100 standard PDM:



- 1 +24 Vdc sensor bus power
- 2 sensor bus return
- 3 +24 Vdc actuator bus power
- 4 actuator bus return
- 5 +24 Vdc island logic power supply
- 6 island logic power return
- 7 External 24 Vdc power supply
- 8 Wurth 74271633 ferrite bead


**NOTE:** To maintain CE compliance, use a Wurth 74271633 ferrite bead with NIM, PDM, BOS, and CPS power supplies. Pass the twisted pair wiring through the ferrite bead twice.

Schneider Electric recommends the Phaseo ABL8 RP 24100 power supply (see page 61) for supplying logic, actuator and sensor power.

## Task 5: Wiring the Current Loops

Each STB AHI 8321 HART interface module provides 4 HART channels. Each channel can connect to a single 4-20 mA current loop and communicate with a single HART field instrument. In this example, the HART multiplexer is connected to a single HART field instrument on channel 1.

The following graphic shows you how to connect 4-20 mA current loop wiring channel 1 of the STB AHI 8321 HART interface module:



- 1 220 Ω resistor
- 2 Channel 1 current loop (+) wiring to HART field instrument
- 3 Channel 1 current loop (-) return from HART field instrument
- 4 Functional ground (FE)
- 5 HART field instrument
- 6 24 Vdc current loop power supply

As the preceding graphic indicates, use pins 2 and 4 to connect channel 1 of the STB AHI 8321 HART interface module to a HART field instrument.


When connecting the island modules to current loop wiring:

- use wire sizes in the range 0.20...0.82 mm<sup>2</sup> (24...18 AWG)
- strip at least 9 mm from the wire's jacket for the connection to STB AHI 8321 module
- use shielded twisted-pair cable
- tie the twisted-pair cable shield to an external clamp that is tied to ground

**NOTE:** Refer to the topic [Wiring the HART Multiplexer to I/O Modules](#) (see page 132) for examples of wiring the HART multiplexer to I/O on STB, Quantum, Premium, and M340 platforms.

## Task 6: Assigning an IP Address

In this example, you will set the IP address of the HART multiplexer to its default IP address. To do this, use the bottom rotary switch (the ONES switch) on the front of the STB NIP 2311 NIM.



Follow these steps to assign your HART multiplexer island its default IP address:

Step	Action
1	Apply power to the HART multiplexer.
2	Turn the bottom (ONES) switch on the STB NIP 2311 NIM so that it points to one of the <b>CLEAR IP</b> positions. This clears any previously assigned IP address. <b>NOTE:</b> The position of the top (TENS) switch does not matter.
3	Turn the bottom (ONES) switch on the STB NIP 2311 NIM so that it points to one of the <b>STORED</b> positions. This NIM applies its default IP address. <b>NOTE:</b> The position of the top (TENS) switch does not matter.

The default IP address is derived from the last 2 pair of two-digit numbers in the MAC ID of your STB NIP 2311 NIM. The MAC ID of your STB NIP 2311 NIM is printed on the front of the NIM above the two Ethernet connector ports.

The default IP address observes the format 10.10.x.y, where:

- 10.10. are constants
- x.y. are the decimal values of the last 2 pair of two-digit numbers in the MAC ID.

The following example shows you how to convert the two x.y. pair of two-digit numbers from hexadecimal to decimal format and identify the HART multiplexer's default IP address:

Step	Action	
1	Using a sample MAC ID of 00-00-54-10-25-16, ignore the first four pair (00-00-54-10). <b>NOTE:</b> You need to use the MAC ID that appears on your STB NIP 2311 NIM.	
2	Convert the last two pair (25 and 16) from hexadecimal to decimal format.	<b>25:</b> $(2 \times 16) + 5 = 37$ <b>16:</b> $(1 \times 16) + 6 = 22$
3	Observe the specified format (10.10.x.y.) to assemble the derived default IP address.	The default IP address is: 10.10.37.22

### Task 7: Auto-Configuring the HART Multiplexer

The auto-configuration process assigns default settings to the modules that comprise your HART multiplexer island—except IP address, which was assigned in the previous task. Using auto-configuration, no manual configuration of island modules needs to be performed. To perform auto-configuration, press the RST button on the STB NIP 2311 NIM.


## ⚠ CAUTION

### UNINTENDED EQUIPMENT OPERATION

Do not press the RST button—or force auto-configuration—for a HART multiplexer island that is operating using an application that was custom configured with Advantys configuration software.

**Failure to follow these instructions can result in injury or equipment damage.**

The RST button is located immediately above the CFG port on the NIM, behind the NIM hinged cover:



To perform auto-configuration, follow these steps:

Step	Action
1	Confirm that power is applied to the HART multiplexer.
2	Using a small screwdriver with a flat blade no wider than 2.5 mm (0.99 in), press the RST button and hold it down for at least 2 seconds. Do not use: <ul style="list-style-type: none"><li>• a sharp object that can damage the RST button, or</li><li>• a soft item like a pencil that can break off and jam the RST button</li></ul>

### Task 8: Confirming the HART Multiplexer is Operating Normally

To confirm that your multiplexer is operating properly, check the RDY and ERR LEDs on the front of the STB AHI 8321 HART interface module:



When your HART multiplexer is operating normally:

- the RDY LED is solid green
- the ERR LED is off

### Task 9: Monitoring HART Multiplexer Operations

After confirming that the HART multiplexer is operating normally, you can open the web pages for the STB NIP 2311 NIM where you can:


- monitor operations
- diagnose the HART multiplexer
- edit the HART multiplexer configuration—for example, you can assign the multiplexer a different IP address

**NOTE:** When commissioning a HART multiplexer for operation in a network, Schneider Electric recommends that you not use the default IP address. Instead, give each HART multiplexer its own unique IP address, as assigned by your network administrator.

To access the web pages, follow these steps:

Step	Action
1	Connect your PC via Ethernet cable to one of the Ethernet ports of the STB NIP 2311 NIM.
2	Confirm that your PC has an alternate IP address on the same network as the HART multiplexer. Recall that the default IP address of the multiplexer is in the format 10.10.x.y. You will probably need to add an alternate network IP address to your PC using the same format. Verify that the IP address you add is not the same as the default IP address for the HART multiplexer.
3	Open an internet browser on your PC and type in the default IP address of the HART multiplexer, then press <b>Enter</b> .
4	In the <b>Security</b> dialog, enter the appropriate username and password. <b>NOTE:</b> <ul style="list-style-type: none"> <li>the <b>User name</b> is the constant value <b>USER</b></li> <li>the default <b>Password</b> is also <b>USER</b>, but can be changed</li> </ul> The <b>Password</b> page opens.

The **Home** page of the STB NIP 2311 NIM:



You can access HART-specific web information by clicking on the **Diagnostics** menu item (above), then under **HART** selecting the following page:

- **Instrument Overview:** to monitor data relating to selected HART field instruments

The following is an example of the HART **Instrument Overview** web page:

Monitoring Control Diagnostics Maintenance Setup

**INSTRUMENT OVERVIEW** Help

Device 1 ▼

Instrument Overview	
PV	8.4075 psi
SV	—
Instrument Status	0x03
HART Revision	5
Device Revision	1
Software Revision	10
Hardware Revision	8
Device ID	0x3D1D2
Manufacturer's ID	0x005E

For details of the contents of this page, refer to the *Embedded Web Pages* section of the *Advantys STB Standard Dual Port Ethernet Modbus TCP/IP Network Interface Module Applications Guide*.

---

# Introducing HART

# 2

---

## Overview

This chapter introduces the Highway Addressable Remote Transducer (HART) protocol, and describes the Schneider Electric HART multiplexer.

## What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Introducing HART	24
Introducing the STB HART Multiplexer	26
HART Multiplexer Features	28
HART Multiplexer Functions	29
Multiplexer Data Flow	31

## Introducing HART


### The HART Protocol

The Highway Addressable Remote Transducer (HART) protocol provides digital communication to microprocessor-based analog process control instruments.

HART uses the Bell 202 frequency-shift-keying (FSK) standard to superimpose a digital signal on top of the 4-20 mA current loop analog signal:

- the analog signal communicates the primary measured process variable value
- the digital signal communicates additional instrument information including instrument status, additional process variables, configuration data, and diagnostics

The digital signal shifts between a frequency of 1200 Hz (representing a binary 1) and a frequency of 2200 Hz (representing a binary 0):



These digital signal frequencies are higher than the analog signaling frequency range of 0...10 Hz. The digital signal is typically isolated using a passive high-pass filter with a cut-off frequency in the range of 400 Hz to 800 Hz. The analog signal is likewise isolated using a passive low-pass filter.

The separation in frequency between HART and analog signaling allows both signals to coexist on the same current loop. Because the HART digital signal is phase continuous:

- it does not interfere with the 4-20 mA signal, and
- allows the analog process to continue operating during HART digital communication

## Half-duplex Communication Protocol

HART communication is half-duplex in design, which means that a HART-compliant instrument does not simultaneously transmit and receive.

## Master - Slave Protocol

HART is a master-slave protocol. A HART-slave responds only when commanded by a HART master. Examples of HART-compliant instruments include:

- HART masters:
  - asset management software (AMS) running on a PC
  - a HART interface module—for example, the STB AHI 8321 module—when it is communicating with a HART process control instrument
  - a hand-held device temporarily attached to the network
- HART slaves:
  - a HART process control instrument

## Defining HART Instruments

A Device Description Language (DDL) file—provided by the device manufacturer—can define a HART instrument. The DDL serves as a universal software interface for new and existing network instruments.

## Introducing the STB HART Multiplexer

### Multiplexer Components


The Schneider Electric STB HART multiplexer is a special-purpose STB island that includes some combination of the following modules:

- Required modules:
  - 1 HART-enabled STB Ethernet network interface module, for example the STB NIP 2311 version 4.0 or higher
  - 1 STB PDT 310x power distribution module
  - a minimum of 1, up to a maximum of 8, STB AHI 8321 HART interface modules
- Optional modules:
  - Analog input modules
  - Analog output modules
  - STB CPS 2111 auxiliary power supply modules, as needed
  - STB XBE 1300 beginning of segment (BOS) modules
  - STB XBE 1100 end of segment (EOS) modules

#### **NOTE:**

- The HART multiplexer is a special kind of STB island. Only the modules described above relate to the use of the STB island as a HART multiplexer. Although you can add other types of modules to a HART multiplexer, STB island designs that include other modules are beyond the scope of this document.
- The HART multiplexer operates at the default backplane speed of 800 kbaud. However, if you add an STB XBE 2100 CANopen extension module to the island, you need to re-configure the backplane speed to 500 kbaud, thereby slowing the performance of the HART multiplexer. Refer to the help topics for the STB XBE 2100 CANopen extension module for additional information.

The following is an example of an HART multiplexer island.



- 1 STB NIP 2311 Ethernet network interface module, version 4.0 or higher
- 2 STB PDT 3100 power distribution module
- 3 2 STB ACO 0220 analog output module (optional)
- 4 STB AHI 8321 HART interface module
- 5 STB CPS 2111 auxiliary power supply
- 6 STB ACI 8320 analog input module (optional)
- 7 STB XMP 1100 terminator plate

### Maximum Multiplexer Size

A single Schneider Electric HART multiplexer can support a maximum of 32 HART instruments—one instrument per channel—when you use:

- the maximum of eight (8) STB AHI 8321 HART interface modules per island
- the maximum of four (4) channels for each HART interface module

## HART Multiplexer Features

### Multiplexer Features

The STB HART multiplexer presents the following features:

- Auto-configurable default operating parameter settings, which enable the commissioning of the multiplexer without custom configuration
- A minimum of 4 (up to a maximum of 32) 4-20 mA current loop connections, each connection linking a channel on an input or output module to an analog HART instrument
- Passive filters on each channel that attenuate HART communication signals, permitting pass-through of the analog signal to analog I/O
- Two Ethernet ports (on the NIM) that let you place the multiplexer into service in a daisy chain topology, or in a daisy chain loop with RSTP enabled
- Capacity to receive IP address settings from a DHCP or BootP server
- Embedded web page diagnostics
- Custom configurable operating parameter settings—via Advantys configuration software
- An Ethernet interface to a HART master, for example, asset management software resident on a PC
- A fieldbus interface over Ethernet, such as Modbus TCP, which lets a PLC connect to a HART instrument and access instrument process variables and status

---

## HART Multiplexer Functions

### The Role of a Multiplexer

The STB HART multiplexer facilitates the transmission of HART field instrument data as follows:

- the multiplexer provides one-to-many communications between:
  - a HART master device, for example, asset management software resident on a PC, and
  - multiple HART slave devices (for example, HART field instruments)
- the multiplexer provides HART instrument data to a secondary fieldbus—such as Modbus TCP—where it is made available to the fieldbus master, for example a PLC.

### Multiplexer Component Functions

The HART multiplexer component modules perform the following functions:

- The STB AHI 8321 HART interface module is a passive device that can pass through the analog transmission between an analog field instrument and an analog I/O module. A single HART interface module can be placed into up to four 4-20 mA current loops (or channels)—one instrument per channel
- The STB AHI 8321 HART interface module receives a combined analog and digital signal from each connected HART instrument.
- The STB AHI 8321 HART interface module filters out the digital HART signal and, if connected to an analog I/O module, passes the analog portion of the signal to the I/O module.
- The STB AHI 8321 HART interface module uses the digital signal to cyclically poll the HART instrument for HART data. The HART data describes the status of each channel and the connected HART instrument.
- Each STB AHI 8321 HART interface module forwards HART data—contained in digital signals received from a HART instrument—to a HART enabled Ethernet network interface module, for example, the STB NIP 2311.
- The HART enabled Ethernet NIM stores the HART data received from each HART interface module located in the multiplexer island. The network interface module makes this data available as follows:
  - HART data is available to asset management software (AMS) running on a PC connected to the NIM via Ethernet.
  - Some of the HART data is stored in registers and becomes part of the island data process image. You can access this data via the PLC, and in the network interface module web pages.

- The HART enabled Ethernet NIM also processes asynchronous commands it receives from HART master devices. These commands instruct the HART instrument to read, write, or reset data values, including instrument configuration and diagnostic data. The network interface module forwards the command to the target HART instrument and returns the response to the master.

**NOTE:** HART master devices include:

- Asset management software (AMS) running on a connected PC. AMS is referred to as a primary HART master, that can send both read and write commands.
- Hand-held devices that are temporarily attached to the control loop on the instrument side of the HART multiplexer. Referred to as a secondary HART master, a hand-held device can also send both read and write commands.

## Multiplexer Data Flow


### The Path from HART Field Instrument to Analog I/O

The HART multiplexer is a passive, pass-through device placed between analog HART field instruments and analog I/O modules.

The physical location of the I/O does not matter. The I/O can be an STB I/O module that resides in the STB HART multiplexer island. Or it can be a module that resides in a Quantum, Premium, M340, or third-party platform rack.

**NOTE:** In the following data flow diagram, the Ethernet transmission is performed via Modbus TCP. The PC with asset management software is equipped with serial-to-Ethernet connector software.

The following figure outlines the flow of data for non-HART tolerant I/O:



## I/O Placement

For both HART tolerant I/O and non-HART tolerant I/O, the physical location of the I/O can vary. The I/O can be an STB analog I/O module that resides in the STB HART multiplexer island. Or it can be an analog I/O module that resides in a separate rack. Typical I/O placement locations include the following:

Placement of I/O modules	Platforms	Use this design for...
The STB HART multiplexer island	STB	New STB networks
A separate I/O drop	<ul style="list-style-type: none"> <li>● STB</li> <li>● M340</li> <li>● Premium</li> <li>● Quantum</li> <li>● Third party platforms</li> </ul>	Existing networks

You can create a topology that combines both designs and places analog I/O modules both in the multiplexer island and in a separate I/O drop.

---

# Planning the HART Multiplexer

# 3

---

## Introducing the STB HART Multiplexer

The HART multiplexer is a specific-purpose STB island. An STB HART multiplexer island is a modular distributed I/O system. This chapter describes how to plan the installation of an STB HART multiplexer island.

## What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Island Segments	34
Extending the Island Bus	40
Enclosing the HART Multiplexer	42
The Power Distribution Modules	47
Logic, Sensor, and Actuator Power Distribution on the Island Bus	52
Understanding Multiplexer Island Power Supply and Consumption	56
Selecting Power Supplies	60

## Island Segments


### The Primary Segment

Every HART multiplexer island begins with a group of interconnected devices called the *primary segment*. The primary segment consists of the island NIM and a set of interconnected module bases attached to a DIN rail. The PDMs, auxiliary power supplies, I/O, and HART interface modules reside in these bases on the DIN rail. The NIM is the first (leftmost) module in the primary segment.

Depending on your needs, you can expand the island to include additional segments of STB modules, called *extension segments*.

### The DIN Rail

The NIM and the module bases snap onto a 35 mm (1.38 in) wide, conductive metal, DIN rail:



### The Bases

The bases provide the physical connections between modules on the island bus. These connections enable communication between the NIM and other island modules. A set of contacts on the side of each base transmit:


- logic power from the NIM, from a beginning of segment BOS module, or from an auxiliary power supply
- sensor power (for inputs) from the PDM
- actuator power (for outputs) from the PDM]
- the auto-addressing signal
- island bus communications between the NIM and other island modules, including I/O and HART interface modules

There are seven types of bases that can be used in a segment. For a specific module, use only the base required by that module.

**NOTE:** When you buy a module, it is packaged as a part of a kit that includes the base for that module.

When constructing the island bus, install the bases in the same left-to-right sequence as the modules they will support.

Bases come in several sizes (see page 69). For example, the STB AHI 8321 HART interface module uses a size 3 base. The following graphic depicts typical base components, in this case an STB XBA 1000 size 1 base:



- 1 user-customizable label tab
- 2 six island bus contacts
- 3 DIN rail lock/release latch
- 4 DIN rail contact
- 5 five field power distribution contacts

As you assemble the island bus, insert the correct base in each specific island location.


## The Island Bus

The module bases that you interconnect on the DIN rail form an island bus structure. The island bus houses the modules and supports the communications buses across the island.

The NIM, unlike the PDMs and I/O modules, attaches directly to the DIN rail.

When an STB system consists of a single primary segment, terminate the island by placing an STB XMP 1100 terminator plate (which is included in the NIM packaging) in the right-most island position. If a second segment is added, replace the terminator plate with an STB XBE 1100 end of segment (EOS) extension module.


The structure of a single-segment island bus:



- 1 NIM
- 2 module bases
- 3 termination plate
- 4 DIN rail

## An Example of an STB Island

The following illustration presents a multiplexer island bus with standard STB modules.



- 1 The NIM in the first location of the segment. The NIM provides 5 Vdc logic power to the I/O and HART interface modules located between the NIM and the STB CPS 2111 auxiliary power supply.
- 2 Two 24 Vdc STB PDT 3100 power distribution modules. One is installed directly to the right of the NIM; the other is installed to the right of an STB CPS 2111 auxiliary power supply. The NIM distributes DC power over the sensor and actuator buses to the I/O directly to its right. The auxiliary power supply supplies DC power to the single input module to its right.
- 3 Two STB ACO 0220 2-channel output modules, which receive DC field power from the island actuator bus. The 4-20 mA current loops from these modules pass through the adjacent STB AHI 8321 HART interface module. Each current loop is connected to a HART field instrument.
- 4 Two 4-channel STB AHI 8321 HART interface modules. The first (leftmost) HART interface module is connected via pass-through wiring to current loops (or channels) on the two 2-channel output modules. The second (rightmost) HART interface module is connected to current loops (or channels) on the single 4-channel input module.
- 5 An STB CPS 2111 auxiliary power module, which provides 5 Vdc logic power to the I/O and HART interface modules located to its right.
- 6 An STB ACI 8320 4-channel input module, which receives DC field power from an external 24 Vdc power supply. Each current loop is connected to a single HART field instrument. The four 4-20 mA current loop signals from this module connect to the STB AHI 8321 HART interface module on the same even numbered pins used by the HART field instrument(s).
- 7 An STB XMP 1100 terminator plate

## Network Interface Module Functions

The first module on the HART multiplexer primary segment is a HART-enabled Ethernet NIM, for example the STB NIP 2311. The NIM performs several key functions:

- It is the master of the island bus, supporting the I/O and HART interface modules by acting as their communications interface across the bus.
- It is the gateway between the island and the fieldbus on which the island operates. It manages the data exchange between the island modules (including both I/O and HART interface modules) and the fieldbus master.
- It is the gateway between HART asset management software (resident on a dedicated PC connected via Ethernet) and both the island HART interface modules and the HART field devices.
- It provides an interface to the Advantys configuration software, which you can use to customize the island configuration.
- It is the primary power source for logic power on the island bus, delivering 5-Vdc logic power to modules in the primary segment.

## Power Distribution Modules

The second module on the primary segment is a PDM (*see page 47*). If the STB island is intended to perform only as a HART multiplexer, it requires only 24 Vdc field power for the modules in a segment.

**NOTE:** If digital I/O is required for the island, refer to the *Advantys STB System Planning and Installation Guide* for information on how to supply 24-Vdc power to digital I/O.

## I/O Modules

An STB HART multiplexer island can include resident analog 24 Vdc input modules and output modules.

## I/O Module Logic Power

Logic power is the power that the STB I/O modules require to run their internal processing and light their LEDs.

The NIM converts the incoming 24 Vdc to 5 Vdc. The NIM then distributes the 5 Vdc as logic power for the primary segment (*see page 52*). A similar power supply built into the beginning of segment (BOS) modules provides 5 Vdc for the I/O modules in any extension segments.

Each power supply produces 1.2 A. If the sum of the logic power current consumed by the I/O modules in a segment exceeds that value, you can insert an auxiliary power supply (for example, the STB CPS 2111) to provide an additional 1.2A of power to the modules located to its right. Therefore, the total current draw (*see page 56*) determines the number of power supplies required by a segment.

**The Last Device on the Primary Segment**

If the STB island consists of only a single (primary) segment, terminate the island bus by placing an STB XMP 1100 terminator plate at the end of the segment.

**Extending the Island Bus**

If you elect to extend the island bus (*see page 40*) to another segment, terminate the primary segment with an STB XBE 1100 EOS bus extension module.

The EOS module has an IEEE 1394-style output connector for a bus extension cable. The extension cable carries the island communications bus and auto-addressing line to the extension segment or to the preferred module.


## Extending the Island Bus

### Why Extend the Island Bus?

There are two reasons for adding extension segments to the island bus:

- to place island modules near to the actuators, sensors, and other end devices with which the island modules communicate
- the physical length of the island exceeds the size of the cabinet

An example of a primary island segment with an extension segment:



- 1 Primary island segment
- 2 Extension segment
- 3 Network interface module (NIM)
- 4 Power distribution module (PDM)
- 5 STB XBE 1100 EOS module
- 6 STB XBE 1300 BOS module
- 7 STB XCA 100x extension cable
- 8 Island bus termination plate

### Maximum Length Considerations

The maximum electrical length of an island bus is 15 m (49.2 ft) end-to-end. The maximum length computation includes:

- The width of every STB module in every segment
- Every extension cable connecting island segments to:
  - other island segments
  - preferred modules

The maximum island bus length does not include the space required for supporting devices, such as external 24-Vdc power supplies. Also, maximum bus length does not include space required for the wiring between these devices and the island.

### **Maximum Number of Extension Segments**

An island bus can support up to six extension segments of STB modules in addition to the primary segment. Extension segments can be installed on the same, or on separate DIN rails.

## Enclosing the HART Multiplexer

### Open System Requirement

STB modules meet CE mark requirements for open equipment. Schneider Electric recommends that you install the multiplexer in an enclosure that meets NEMA 250 type 1 requirements and IP 20 requirements conforming to IEC 529. Use of an enclosure is recommended to help reduce the likelihood of:

- unauthorized access
- personal injury resulting from access to live parts

Consider the specific environmental conditions under which the modules operate when planning the enclosure.

### Size of the Enclosure

Verify that the size of the enclosure is large enough to house the modules included in the island. To fit more easily into the enclosure, you may want to divide the HART multiplexer island into multiple island segments, then arrange the segments horizontally.

A single HART multiplexer island supports up to 32 analog I/O channels, and includes:

- one NIM
- up to 32 analog modules, including analog I/O and HART interface modules
- PDMs, auxiliary power supplies, and EOS/BOS modules as needed

### Module Dimensions

STB modules come in three widths, and present the following dimensions:

Module type	Width of module	Height of module in base	Depth of module in base with field connectors
1	13.9 mm (.55 in.)	128.25 mm (5.05 in.)	75.5 mm (2.97 in.)
2	18.4 mm (.73 in.)	128.25 mm (5.05 in.)	75.5 mm (2.97 in.)
2-PDM	18.4 mm (.73 in.)	137.90 mm (5.45 in.)	79.5 mm (3.13 in.)
3	28.1 mm (1.11 in.)	128.25 mm (5.05 in.)	70.1 mm (2.76 in.)

In addition to the module depth and height dimensions, above, consider the dimensions of external power supplies or other equipment—not described above—that you may attach to your island.


### STB Modules Size & Base Type


Each STB module comes packaged with the base that is appropriate for that module. Use the base unit that comes with your module. If you need to replace a base unit for any reason, refer to the following table:

Model	Type	Base	Model	Type	Base
<b>Analog Input Modules</b>			<b>Analog Output Modules</b>		
STB ACI 0320	2	STB XBA 2000	STB ACO 0120	2	STB XBA 2000
STB ACI 8320	2	STB XBA 2000	STB ACO 0220	2	STB XBA 2000
<b>Power Distribution Modules</b>			<b>Special Purpose Modules</b>		
STB PDT 3100	2	STB XBA 2200	STB AHI 8321	3	STB XBA 3000
STB PDT 3105	2	STB XBA 2200	STB XBE 1100	2	STB XBA 2400
STB CPS 2111	2	STB XBA 2200	STB XBE 1300	2	STB XBA 2300

### Spacing Requirements

Maintain adequate clearance between the modules installed in the enclosure and surrounding fixed objects such as wire ducts and inside surfaces. The following two illustrations depict the spacing requirements within an enclosure





**NOTE:** The preceding graphic is not drawn to scale.


## Mounting

Mount the island on one or more 35 mm (1.38 in) wide DIN carrier rails.

Install the metal DIN rail by:

- attaching it to a flat metal mounting surface
- mounting it on an EIA rack
- mounting it in a NEMA cabinet enclosure

The standard DIN rail is 35 mm x 15 mm (1.38 in x 0.59 in) deep.



Use M5 threaded mounting hardware to affix the DIN rail to the mounting surface. Allow a maximum spacing of 150 mm (5.91 in) between each mounting hardware.

## Wiring

Install wiring so that it does not obstruct the 100 mm (3.94 in) of free air space above and below the island segment. Tie down the wiring to help guard against undue load or strain on the STB modules. Use a service loop to dress the leads from a harness or cable channel. This practice helps reduce strain on the module.

## Thermal Considerations

For proper heat dissipation, allow a minimum clearance of 100 mm (3.94 in) above and below each island segment. Allow the unobstructed flow of air to the vent openings on the top and bottom of the modules.

The following list presents some worst-case values for estimating the wattage dissipation when you plan the cooling for your system and cabinet enclosure:

<b>Module Type</b>	<b>Base Type</b>	<b>Worst-case Wattage Value</b>
inputs	type 1	1.5 W
	type 2	2.75 W
	type 3	3.5 W
outputs	type 1	1.0 W
	type 2	2.25 W
	type 3	3.5 W
HART interface module	type 3	3.5 W
EOS	type 2	1.0 W
BOS	type 2	2.5 W
auxiliary power supply	type 2	2.5 W
DC PDM	type 2 - PDM	1.5 W
NIM		3.5 W

These values assume elevated bus voltage, elevated field-side voltage and maximum load currents. Typical wattage values are often lower.

---

## The Power Distribution Modules

### Functions

The power distribution module (PDM) supplies field power to the input and output modules resident on the island. Standard PDM modules can distribute sensor power and actuator power via the same or separate power lines across the island bus.

The PDM includes a user-replaceable fuse that helps protect both the island input and output modules, and the wiring. It also provides a protective ground (PE) connection for the island.

### Positioning

The HART multiplexer, like other STB islands, requires the placement of a PDM immediately to the right of the NIM, BOS or auxiliary power supply. Depending on the number of input and output modules resident on the segment, additional PDMs can be required. The placement of a PDM to the right of a module group terminates the sensor and actuator buses for the preceding (leftward) module group.

### Selecting a PDM

If you are building an STB island to serve exclusively as a HART multiplexer, you will need to include only 24 Vdc analog I/O modules. There are two PDMs that can supply 24 Vdc power:

- the STB PDT 3100 standard module
- the STB PDT 3105 basic module

### Standard versus Basic PDMs

When you use a standard PDM, the PDM separately provides power to:

- the island sensor bus, for the input modules in its group
- the actuator bus, for the output modules in its group

When you use a basic PDM, the PDM simultaneously provides power to both the sensor bus and the actuator bus.


The standard PDM can also handle more current than a basic PDM.

### Standard PDM Power Distribution

Place a PDM immediately to the right of the NIM (or BOS or auxiliary power supply) on the island. The modules in the group follow in series to the right of the PDM.

**NOTE:** The illustrations presented below are simplified drawings that focus on a single island feature. They may not display every necessary component.


The following simplified illustration shows a STB PDT 3100 PDM supporting a cluster of analog 24 Vdc I/O modules:



- 1 24 Vdc sensor power signal to the PDM
- 2 24 Vdc actuator power signal to the PDM

Sensor power (to the input modules) and actuator power (to the output modules) are brought to the island (from an external 24 Vdc power supply) via separate two-pin connectors on the PDM.

In the following simplified illustration, an STB CPS 2111 auxiliary power supply is placed directly to the right of the last I/O module in the first module group, to provide additional logic power (see page 52) to the island. A second PDM is then required to provide power for new sensor and actuator buses for the 24 Vdc modules to the right of the second PDM:



- 1 24 Vdc sensor power signal to the PDM (first module group)
- 2 24 Vdc actuator power signal to the PDM (first module group)
- 3 24 Vdc sensor power signal to the PDM (second module group)
- 4 24 Vdc actuator power signal to the PDM (second module group)


Each standard PDM contains a pair of time-lag fuses:

- a 10 A fuse for the actuator bus
- a 5 A fuse for the sensor bus

These fuses are user-replaceable.

### Basic PDM Power Distribution

If your island uses an STB PDT 3105 basic PDM, power is sent from a single power source (in the PDM) to the sensor bus and the actuator bus. The sensor and actuator busses join together in the PDM. In the following illustration, two basic STB PDT 3105 PDMs are used to provide actuator power and sensor power to two separate groups of I/O:




- 1 24 Vdc actuator and sensor power to the first (leftmost) module group
- 2 24 Vdc actuator and sensor power to the second (rightmost) module group

Each basic PDM contains one 5 A time-lag fuse that is user-replaceable.

## PE Grounding

A captive screw terminal on the bottom of the PDM base connects to each I/O base, establishing an island PE bus. The screw terminal on the PDM base meets IEC-1131 requirements for field power grounding. Wire the screw terminal to the PE point on your system.




## Logic, Sensor, and Actuator Power Distribution on the Island Bus

### Logic Power

The NIM requires an external supply of 24 Vdc power. The NIM converts the supplied 24 Vdc, then provides 5 Vdc logic power to the I/O and HART interface modules in the primary island bus segment.

**NOTE:**

The illustrations presented below are simplified drawings that focus on a single island feature. The illustrations may not display every necessary component.




The NIM can supply maximum current of 1.2 A to the island segment modules. If your island design requires more power than the NIM can provide, you can:

- install an STB CPS 2111 auxiliary power supply to provide additional logic power to the remaining (rightward) modules.
- segment the island: Remove some modules from the primary segment to reduce the current draw on that segment to less than 1.2 A. Place these modules into an island extension segment with a BOS.

BOS and auxiliary power supply modules on STB island extension segments require their own 24 Vdc logic power source. This source can come either from the same power supply used by the primary island segment, or from an additional one. The same 1.2 A current limit applies to each extension segment. If a segment exceeds the 1.2 A current draw limit, auxiliary power supplies can also be added to the extension segment.

Here is an illustration of the extension segment scenario:



Operating voltages for the island range from 19.2 Vdc to 30 Vdc.

The power components are not galvanically isolated. Use them only in systems designed to provide SELV isolation between:

- the supply inputs or outputs, and
- the load devices or system power buses

## **⚠ CAUTION**

### **IMPROPER GALVANIC ISOLATION**

Use SELV-rated supplies to provide 24 Vdc source power to the NIM.

**Failure to follow these instructions can result in injury or equipment damage.**

### Sensor and Actuator Power

For standard PDMs, provide power to the island sensor and actuator buses separately from external sources. The source power is fed to separate two-pin power connectors on the PDM.


- The top connector is for the sensor (input) power bus.
- The bottom two-pin connector is for the actuator (output) power bus

Depending on your application, you can use the same or different external power supplies (see page 60) to feed the 24 Vdc sensor and the actuator busses.

For basic PDMs, provide power to both the sensor and actuator buses via a single two-pin power connector on the PDM.

### 24 Vdc Field Power Distribution

In the following illustration, an external power supply delivers 24 Vdc power to an STB PDT 3100 PDM. The PDM, in turn, distributes field power to the island sensor and actuator busses:



- 1 24 Vdc signal to the NIM logic power supply
- 2 24 Vdc signal to the segment sensor bus
- 3 24 Vdc signal to the segment actuator bus
- 4 optional relay on the actuator bus

Above 130 Vac, the relay module may compromise the double insulation provided by a SELV-rated power supply.

** CAUTION****COMPROMISED DOUBLE INSULATION**

When you use a relay module, use separate external 24 Vdc power supplies for the PDM supporting that module and the logic power to the NIM or BOS module when the contact voltage is above 130 Vac.

**Failure to follow these instructions can result in injury or equipment damage.**

You can use the same power supply for both logic power and field power when:

- the I/O load on the island bus is low, and
- the system is operating in a low electromagnetic noise environment

## Understanding Multiplexer Island Power Supply and Consumption

### Overview

When you design your HART multiplexer, consider:

- the combined capacity of modules that supply logic, sensor and actuator power to the island, and
- the load requirements of each module—including I/O modules and HART interface modules—that consume the supplied power

The operating temperature ranges for the STB HART multiplexer modules are listed in the following tables. The listed modules are designed to operate in an environment where the ambient temperature is in the range 0...60° C (32...140° F).

### Input Voltage Power Supply Temperature Range Variations

Input voltage for NIMs, STB XBE 1300, STB XBE 1100, STB CPS 2111, STB PDT 3100 modules, and external power supplies can vary with temperature. For the normal operating temperature range of 0...60°C, the supply voltage range is 19.2...30 Vdc

### NIM, BOS & Auxiliary Power Supply Modules

The operating temperature ranges for the STB NIM, BOS, and Auxiliary Power Supply modules are as follows:

<b>NIM, BOS, and Auxiliary Power Supply Modules</b>			
<b>Model</b>	<b>Product Version</b>	<b>Type</b>	<b>Logic Bus Current Supply at 0...60°C</b>
STB NIP 2311	4.0	Dual Port Ethernet MB TCP/IP NIM standard	1.2 A
STB CPS 2111	N/A	Auxiliary Power Supply	1.2 A
STB XBE 1300	N/A	BOS Extension Module	1.2 A

Check the front of the NIM (*see page 11*) to confirm that it is product version 4.0 or higher.

## Analog I/O Modules

The heat generated by the following STB analog I/O modules is, under normal operating conditions, noticeably greater than the other STB I/O modules. The microprocessor and digital signal processor, required for these types of modules, primarily generate the heat in these modules. These components operate correctly at higher temperatures as noted by their respective manufacturers. The modules are:

- STB ACI 0320 (4 channel analog, current input)
- STB ACI 8320 (4 channel analog, current input)
- STB ACO 0120 (1 channel analog, current output)
- STB ACO 0220 (2 channel analog, current output)
- STB AHI 8321 (4 channel HART interface module)

The HART multiplexer operates in the range 0...60° C. When installing an STB island, mount the product vertically so that natural convection cooling is not impeded.

Logic bus current consumption amounts for analog modules operating in the normal operating temperature range are as follows:

Analog Input Model	Type	Logic Bus Current Consumption @ 0...60°C
STB ACI 0320	Cur, 4 ch, 4-20 mA, 16-bit standard	95 mA
STB ACI 8320	Cur, 4 ch, 4-20 mA, 16-bit standard	95 mA

Analog Output Model	Type	Logic Bus Current Consumption @ 0...60°C
STB ACO 0120	Cur, 1 ch, 4-20 mA, 16-bit standard	155 mA
STB ACO 0220	Cur, 2 ch, 4-20 mA, 16-bit standard	210 mA

## Special Purpose Modules

Logic bus current consumption amounts for special purpose modules operating in the normal operating temperature range are as follows:

Special Purpose Model	Type	Logic Bus Current Consumption @ 0...60°C
STB AHI 8321	HART Interface Module	400 mA
STB XBE 1100	EOS Extension Module	25 mA


### Power Distribution Modules

Field power supplied to I/O modules by the PDM operating in the normal operating temperature range are as follows.

PDM Model	Type	Field Power Supplied to I/O Modules @ 0...60°C
STB PDT 3100	24 Vdc Power Distr. standard	8.0 A
STB PDT 3105	24 Vdc Power Distr. basic	4 A

### STB PDT 3100 Performance Considerations

For the STB PDT 3100 PDM, the maximum combined module current—the sum of the actuator and sensor currents—depends upon the island ambient temperature. The following diagram presents a curve that plots the module’s maximum combined current against its operating temperature range.



This example shows:

- At 60 °C the total maximum combined current is 8 A
- At 45 °C the total maximum combined current is 10 A
- At 30 °C the total maximum combined current is 12 A

**NOTE:** At any temperature, the maximum actuator current is 8 A and the maximum sensor current is 4 A.

### Logic Bus Current Draw Variations

The total number of modules in a logic power supply group determines the total bus current drawn from the NIM, BOS, or auxiliary power supply. The more modules, the greater the amount of current required to support them. You can determine the total bus current required from the NIM by totaling the individual current requirements for the I/O modules residing on the island.

Verify that the total bus current value is within the allowable current draw range listed for the particular type of NIM module installed on the island. If the logic bus current draw exceeds the capacity of the NIM, either:

- divide the island segment into smaller segments, or
- add an auxiliary power supply to the segment

## Selecting Power Supplies

### Overview

The power components are not galvanically isolated. They are for use only in systems designed to provide SELV isolation between the supply inputs or outputs and the load devices or system power bus.

### CAUTION

#### IMPROPER GALVANIC ISOLATION

- Use SELV-rated supplies to provide 24 Vdc source power to the NIM and any BOS or auxiliary power supply modules in your system
- If you are using a relay module with a contact voltage above 130 Vac, do not use a common external 24 Vdc power supply for the PDM supporting that module and the logic power in the NIM, auxiliary power supplies, or BOS modules
- Above 130 Vac, the relay module defeats the double insulation provided by a SELV-rated power supply

**Failure to follow these instructions can result in injury or equipment damage.**

In an STB island, there can be three different connections that need 24 Vdc power from an external source:

- logic power connection (to the NIM, to any auxiliary power supplies, and to any BOS extension modules in the island)
- actuator power connection (to a PDM)
- sensor power connection (to a PDM)

Source power for these power connections can come from one or more supplies. The following considerations should be considered when selecting your power options:

- field devices
- voltage and current needs
- isolation requirements
- EMI/RFI suppression needs
- CE requirements
- cost limitations

## Logic, Sensor, and Actuator Power

Use external 24 Vdc power to support the logic, sensor, and actuator requirements of each segment in your STB island.

For a standard STB PDT 3100 or a basic STB PDT 3105 PDM, verify that the power supplies you choose operate within a voltage range bounded by:

- a lower voltage limit of 19.2 Vdc
- an upper voltage limit of 30 Vdc

## Wattage Requirements

Supply the NIM with at least 13 W of power. If your island uses a BOS or an auxiliary power supply, supply each such module on your island with at least 7 W of power.

**NOTE:** If the 24 Vdc source power supply also supplies field voltage to a PDM, add the field load to your wattage calculation. For 24 Vdc loads, the calculation is:  $amps \times volts = watts$ .

## Recommended Supplies

We recommend the Phaseo ABL8 family of 24 Vdc power supplies. Here are several possible power supply solutions to consider:

- one supply for 4-20 mA current loop power: ABL8 MEM 24003
- one supply for three connections (logic power, actuator power, and sensor power): ABL8 RPS 24100
- two supplies for three connections (one for logic power, one for actuator and sensor power)  
For logic power: ABL8 RPS 24030  
For the 24 Vdc PDM: ABL8 RPS 24100
- three supplies for three connections (one for logic power, one for actuator power and one for sensor power)  
For logic power: ABL8 RPS 24030  
For the 24 Vdc PDM sensor: ABL8 RPS 24050  
For the 24 Vdc PDM actuator: ABL8 RPS 24100

For more information on recommended 24 Vdc Phaseo power supplies, contact your Schneider Electric representative and ask for brochure 8440BR1001.



---

# Building the Multiplexer

# 4

---

## Overview

This chapter describes how to assemble the physical components comprising an STB HART multiplexer.

## What Is in This Chapter?


This chapter contains the following topics:

Topic	Page
Installing the DIN Rail	64
Installing the HART Enabled Ethernet NIM	65
Creating the Backplane of the Island Bus	68
Terminating the Island Bus	71
Inserting STB Modules into their Bases	73
Installing Extension Segments to the Island Bus	76

## Installing the DIN Rail

### Carrier Rails for the Island Bus

The STB modules are designed for mounting on 35 mm x 15 mm (1.38 in x 0.59 in) deep DIN rail conforming to IEC 60715. The use of 15 mm deep DIN rail is required to achieve the stated system performance specifications. As shown on the following illustration, install M5 threaded mounting hardware at the end positions and at 150 mm (5.91 in) maximum increments along the length of the rail.



Low profile 7.5 mm (0.30 in) deep DIN mounting rail can be used with low profile mounting hardware such as flat head screws, with countersunk mounting holes.

#### NOTE:

- Mount the DIN rail on a grounded metal plate.
- If you use low profile 7.5 mm deep DIN rail, the fastener screw head cannot protrude more than 1.0 mm (0.04 in) above the DIN rail.

### Grounding Function

The DIN rail provides the functional ground (*see page 84*) across the island.


## Installing the HART Enabled Ethernet NIM

### The First Module on the Island Bus

Every STB island includes a single NIM. It is the first (leftmost) module on the DIN rail in the primary island segment. For the HART multiplexer island, use only a HART enabled Ethernet NIM, such as the STB NIP 2311 version 4.0 and higher.

### How to Install the NIM

Unlike other STB modules, the mounting base of the NIM is permanently attached to the module. Install the NIM on the DIN rail in one piece, as follows:


Step	Action
1	Determine the exact location on the DIN rail where you want to position the NIM before you place it on the rail. <b>NOTE:</b> Reserve sufficient space to the right of the NIM for the other island modules you want to mount on the DIN rail. In addition, reserve space for any DIN-mounted external devices you plan to use, for example, power supplies.
2	Turn the release screw (2) on the NIM so that the mounting clips on the back are in their relaxed state. 

## **⚠ CAUTION**

### **UNINTENDED EQUIPMENT OPERATION**

Do not slide the NIM along the DIN rail. Sliding the NIM can crush the functional ground (FE) contacts on the back of the NIM. Crushed FE contacts can prevent the creation of the FE connection


**Failure to follow these instructions can result in injury or equipment damage.**

Step	Action
3	<p>Align the mounting clips with the DIN rail and push the NIM onto the rail. The slope of the mounting clips causes the rail to open the clips when you apply light pressure.</p> 
4	<p>When the module is pushed completely on to the rail, the clips snap closed.</p> 

For instructions on how to remove the NIM, refer to the *Advantys STB System Planning and Installation Guide*.

## FE Contacts

One of the roles of the DIN rail is to provide a FE for the modules on the island. FE helps protect the island from radio frequency interference (RFI) and electromagnetic interference (EMI). The contacts on the back of the NIM, (3), make the functional ground connection between the rail and the NIM.



## Creating the Backplane of the Island Bus

### Installation Plan

To help you install island modules in the correct sequence, create an installation plan before you begin the actual installation process. A useful installation plan describes:

- the sequence of modules
- the base required for each module


It is also helpful to use the STB XMP 6700 marking label kit to identify the module you plan to add to each base

### Interlocking Base Units on the DIN Rail

After you attach the NIM to the DIN rail, create the island back plane by interconnecting the proper sequence of base units.

Start directly to the right of the NIM with a PDM base unit. Then add a series of base units for the modules you plan to add to the island. Base units are installed from left to right along the rail. These base units together with the NIM form the backplane for the primary segment of the island.

The following illustration depicts features that relate to connecting base units to the DIN rail.



- 1 Interlocking channels
- 2 Contacts
- 3 Contact channels
- 4 DIN rail latch

## The Base Units

The following table lists the base types.


Base Model	Base Width	STB Modules It Supports
STB XBA 1000	13.9 mm (0.53 in)	size 1 I/O modules
STB XBA 2000	18.4 mm (0.71 in)	size 2 I/O modules
STB XBA 2100	18.4 mm (0.71 in)	the STB CPS2111 auxiliary power supply
STB XBA 2200	18.4 mm (0.71 in)	PDMs
STB XBA 2300	18.4 mm (0.71 in)	the BOS module
STB XBA 2400	18.4 mm (0.71 in)	the EOS module
STB XBA 3000	28.1 mm (1.06 in)	the STB AHI 8321 HART interface module and other size 3 modules

## How To Attach Base units to the DIN Rail

The following steps describe how to attach base units to the DIN rail. When attaching base units, proceed in a left to right direction.

Step	Action
1	Working from your installation plan, select an STB XBA 2200 base unit for the PDM to place directly to the right of the NIM.
2	Using a screwdriver, move the DIN rail latch on the base unit to its full open position.

The diagram illustrates the mechanical action of opening the DIN rail latch. A screwdriver is shown inserted into the latch mechanism of a base unit. The latch is being pushed upwards and outwards, as indicated by a curved arrow. Dashed lines show the latch's position before and after being moved. The base unit is shown in a side profile, with the latch mechanism highlighted in red.

Step	Action
3	<p>Align the contacts on the base with the contact channels on the NIM and push the base toward the DIN rail until the interlocking channels meet. Using the interlocking channels as guides, slide the base toward the DIN rail (push from the center of the base). When the base meets the DIN rail, hold the base unit firmly against the DIN rail and push the DIN rail latch into the locked position.</p> 
4	<p>Working from your installation plan, select the correct base unit for the module. Insert this unit directly to the right of the previous base unit; then repeat steps 2 and 3.</p>
5	<p>Repeat steps 2 ... 4 until base units for all the modules in the primary segment are installed.</p> 
6	<p>Refer to the procedures in the next topic (<i>see page 71</i>) for information on installing the last device in the segment.</p>

## Terminating the Island Bus

### One or More Segments?

Terminate the last device on the HART multiplexer island bus with an STB XMP 1100 termination plate, which is included in your NIM packaging.

- If the island bus is a single segment (without extension segments), terminate the island at the right end of the segment.
- If the island is extended (see page 40), terminate only the last segment of the island bus.

### Termination Options


The following table describes the different ways to terminate the island bus, depending on the type of installation.

If the island bus includes...	then...
A primary segment with no extension segments	Terminate the segment with an STB XMP 1100 termination plate.
A primary segment plus one or more extension segments	Install an STB XBA 2400 base at the end of the segment. This base holds an STB XBE 1100 end of segment EOS module. Terminate at the end of the last segment with an SCB XMP 1100 termination plate. The EOS module provides a connector for a bus extension cable. This cable runs to the STB XBE 1300 (BOS) module placed in the first position in the extension segment.

### How to Terminate the Last Segment

To terminate the last segment on the island bus:

Step	Action
1	Align the interlocking channels at the top and bottom left of the termination plate with the channels on the right side of the last module base.
2	Using the interlocking channels as guides, slide the plate toward the DIN rail until it snaps onto the rail.



For instructions on how to remove the termination plate, refer to the *Advantys STB System Planning and Installation Guide*.

## Inserting STB Modules into their Bases


### Preliminary Considerations


Each STB module slides into its base and locks with snap latches. Match each module with the base designed for use with that module. Before you install the modules in their bases, we recommend that you consult your installation plan (see page 68) and confirm that you have the correct base in each position on the island backplane.

If you have not already done so, use the STB XMP 6700 marking label kit to identify the module you plan to add to each base.

### How to Insert a Module in a Base

To install a module into its base:

Step	Action
1	<p data-bbox="443 654 1108 678">Guide the bottom of the module into the tray at the bottom of the base.</p>  <p data-bbox="443 1328 824 1430">           1 Module to base latch (bottom)            2 Module base latch receptor (bottom)            3 Module latch (top)            4 Module to base latch receptor (top)         </p>

Step	Action
2	Push the bottom of the module toward the back of the base until the latch (1) fully engages the bottom of the base (2). A snapping sound is audible when the bottom of the module is engaged.
3	<p>Push the top of the module inward until the latch (3) fully engages the top of the base (4). A snapping sound is audible when the top of the module is engaged.</p> 
4	Pull outward on the module to confirm that the module is affixed to its base.


## How to Remove a Module from its Base

Only remove a module from its base when power to the island is disconnected.

### NOTE:

- If you remove an I/O module from the island, any connected sensor or actuator field instruments will no longer work.
- If you remove a module configured as a mandatory module, island operations stop.

To remove a module from its base:

Step	Action
1	Remove any wiring connectors from the module.
2	Using both hands, release the module from the base by depressing the two module to base latches. Latches are located on both the top and on the bottom of the module.  <p>1 Module to base latch (top) 2 Module to base latch (bottom)</p>
3	With a rocking motion, slowly pull the module evenly out of the base.

## Installing Extension Segments to the Island Bus

### How to Build an Extension Segment

Build a HART multiplexer extension segment the same way you would build the primary segment, with one exception. Place a beginning of segment (BOS) module in the first position, instead of a NIM.


The BOS module mounts in a special size 2 base, the STB XBA 2300. A BOS delivers logic power across the extension island backplane. Like the NIM, connect a BOS module to an external 24 Vdc power supply.

The rest of the modules are assembled the same as in a primary segment. The second module is a PDM followed by other STB modules.

The last device in the segment can be:

- an STB XMP 1100 termination plate, if placed at the end of the island bus
- an STB XBE 1100 EOS module, if the island bus includes one or more additional segments

An example of a primary segment with extension segment:



- 1 Primary island segment
- 2 Extension segment
- 3 Network interface module (NIM)
- 4 Power distribution module (PDM)
- 5 STB XBE 1100 EOS module
- 6 STB XBE 1300 BOS module
- 7 STB XCA 100x extension cable
- 8 Island bus termination plate

### Length of the Island Bus

The maximum length of an island bus (the maximum distance between the NIM and the last device on the island) is 15 m (49.2 ft). This length includes the extension cables between segments, extension cables between preferred modules, and the space consumed by the devices themselves.

## EOS/BOS Paired Modules

You can use an EOS module to connect to either:

- a BOS module in the first position of an extension segment
- a preferred module

Refer to the *Advantys STB System Planning and Installation Guide* for instructions on how to connect a primary segment to a preferred module.

When joining island bus segments together, only paired EOS/BOS modules work with one another. Use the STB XBE 1100 EOS module and the STB XBE 1300 BOS module when extending HART multiplexer island segments

## Connectors

The STB XBE 1300 BOS module can accept 24V-DC voltage from a 24V-DC power supply connected to its 2-pin power connector. This module can then pass power to the modules on its segment.

Both of the following connectors, which are included with the EOS and BOS modules as part of the kit, can connect to the modules 2-pin connector:

- a *screw type* power connector, available in a kit of 10 (model STB XTS 1120)
- a *spring clamp* power connector, available in a kit of 10 (model STB XTS 2120)

## Island Bus Extension Cables

The STB XCA 100x island bus extension cable connects two STB island segments:

- One cable end plugs into the island bus communications output port on the front panel of the EOS module (at the end of a segment)
- The other end plugs into the island bus communications input port on the front panel of the BOS (at the beginning of the next segment).

Bus extension cables are available in five lengths:

Model	Cable Length
STB XCA 1001	0.3 m (1 ft)
STB XCA 1002	1.0 m (3.3 ft)
STB XCA 1003	4.5 m (14.8 ft)
STB XCA 1004	10.0 m (32.8 ft)
STB XCA 1006	14.0 m (45.9 ft)

Each cable has IEEE 1394-style connectors on each end. The cable does not transmit the 5-Vdc logic signal to the next segment.

### How to Extend the Island Bus

Use the following procedure to extend the island bus from one end of segment (EOS) module to the next beginning of segment (BOS) module:

1	Confirm that the STB XBE 1100 EOS module is in the last (right-most) position in the previous segment.
2	Install the matched STB XBE 1300 BOS module (in an STB XBA 2300 base) in the first position in the extension segment.
3	Build the rest of your segment, starting with the appropriate PDM (in an STB XBA 2200 base) next to the BOS module.
4	Use an extension cable to connect the EOS module in the previous segment to the matched STB XBE 1300 BOS module in the extension segment.
5	Connect the BOS module to your source power supply.

---

# Grounding the HART Multiplexer

# 5

---

## Overview

This chapter presents techniques for grounding the HART multiplexer.

## What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Galvanic Isolation Requirements for Power Supplies on the Island Bus	80
Voltage Cut-out Switching	81
Creating a Protective Ground Connection	82
Creating a Functional Ground Connection	84
Using EMC Kits	85

## Galvanic Isolation Requirements for Power Supplies on the Island Bus

### Isolation Requirements

Verify that the power sources for the NIM and any other auxiliary power supply or BOS modules are galvanically isolated. Galvanic isolation is not provided by the NIM, BOS or auxiliary power supply modules.

### External Power Supply Requirement

Use only SELV-rated external 24 Vdc power supplies to provide power to the island bus. Verify that the input side is galvanically isolated from the output side.

This SELV requirement applies to 24 Vdc power supplies supporting both logic power and field power.

The power components are not galvanically isolated. They are for use only in systems designed to provide SELV isolation between the supply inputs or outputs and the load devices or system power bus. Above 130 Vac, the relay module defeats the double insulation provided by a SELV-rated power supply.

### CAUTION

#### IMPROPER GALVANIC ISOLATION

- Use SELV-rated supplies to provide 24 Vdc source power to the NIM and any BOS or auxiliary power supply modules in your system.
- If you are using a relay module with a contact voltage above 130 Vac, do not use a common external 24 Vdc power supply for the PDM supporting that module and the logic power in the NIM, auxiliary power supplies, or BOS modules.

**Failure to follow these instructions can result in injury or equipment damage.**


## Voltage Cut-out Switching

### Advantage of the Power Distribution Method

One of the key features of an STB island featuring a standard NIM is the separate distribution of field power to input and output modules. The STB PDT 3100 standard PDM distributes field power to island modules via a sensor bus. It independently distributes field power to the output modules over an actuator bus.

You can test your application program with live inputs while the outputs are disabled. To do this place a relay or switch installed between the source power supply and the actuator bus connection on the standard PDM,

Here is an example of this relay or switch setup:



### Recommended Relays

Schneider Electric recommends its Preventa line of relays. For a complete selection, contact your Schneider representative and ask for catalog MKTED208051EN-US-2011-SU.

## Creating a Protective Ground Connection

### PE Contact for the Island

In addition to distributing sensor and actuator power to the I/O modules, the PDM can provide protective ground (PE) to the multiplexer. On the bottom of each STB XBA 2200 PDM base is a captive screw in a plastic block. Use the captive screw, on every PDM base in the multiplexer, to make a PE contact with the island bus.

### How to Make a PE Contact

To create a PE contact:


Step	Action
1	Bring a PE connection to the HART multiplexer island using a heavy-duty cross-sectional wire, usually a copper braided cable that is 6 mm <sup>2</sup> or larger.
2	Connect the protective ground conductor to the bottom of the PDM base, using the PE captive screw.
3	Tie the wire to a single grounding point.

**NOTE:** Local electrical codes take precedence over our PE wiring recommendations.

### Making Multiple PE Connections

If the multiplexer island includes more than one PDM, distribute PE by connecting a protective ground conductor to each PDM base (*see page 85*).

This illustration shows separate PE connections tied to PE protective ground points:



- 1 the NIM
- 2 a PDM
- 3 another PDM
- 4 captive screws for the PE connections
- 5 FE connection on the DIN rail
- 6 Protective ground points

## Creating a Functional Ground Connection

### Functional Ground (FE) on the DIN Rail

The DIN rail for your STB island is the functional ground (FE) plane for your system. EMI and RFI are suppressed at the DIN rail. The contacts—on the back of both the NIM and the module bases—establish the connection between the functional ground and your island.

### Rail Mounting Tips

Create the FE connection by mounting the NIM and the module bases on the DIN rail.

#### CAUTION

##### UNINTENDED EQUIPMENT OPERATION

Do not slide the NIM along the DIN rail. Sliding the NIM can crush the functional ground (FE) contacts on the back of the NIM. Crushed FE contacts can prevent the creation of the FE connection.

**Failure to follow these instructions can result in injury or equipment damage.**

When performing this task, consider the following tips:

- Do not slide the NIM and the module bases along the DIN rail when installing them. Sliding them along the DIN rail can crush the FE contacts on the back of the NIM and bases. Crushed FE contacts can prevent the creation of the FE connection.
- If you are using 7.5 mm (0.30 in) DIN rail, use flat-head threaded mounting hardware. Countersink the mounting hardware so that the head does not protrude more than 1 mm (0.04 in) above the DIN rail.

**NOTE:** If the top of the mounting hardware protrudes 1 mm or more above the DIN rail, the base units may not be able to make proper contact with the DIN rail and create an FE connection.

- A 7.5 mm DIN rail can support vibration conditions up to 3 g. For high vibration environments (up to 5 g), use 15 mm (0.59 in) DIN rail and fasten the rail to the mounting surface along areas where the island modules are mounted. Confirm that the screw heads on 15 mm rail are sufficiently recessed so that they do not interfere with the base-to-rail FE contacts.

## Using EMC Kits

### Overview


EMC kits reduce electromagnetic and radio interference by grounding the shielded cables entering your island modules at close proximity.

The STB XSP 3000 kit comes with a 1 m (39.37 in) grounding bar that can be cut to needed lengths.

Reasons to use the EMC kits on the HART multiplexer island include:

- to make STB analog I/O modules CE compliant
- to enable the use of shielded cables that help protect analog signals from interference from RFI/EMI


The following illustration depicts an STB island segment with an EMC kit making the analog I/O modules CE compliant.



- 1 metal mounting, grounded surface
- 2 the DIN rail attached to metal mounting surface
- 3 Functional ground (FE) grounding point
- 4 EMC side brackets
- 5 PDM PE screw
- 6 EMC FE clamp
- 7 FE grounding bar from an STB XSP 3000 EMC kit, used as a FE point for shielded cables and as a cable stabilizer
- 8 EMC cable clamp
- 9 cable channel
- 10 6 mm<sup>2</sup> braided cable to plant protective ground
- 11 Protective ground (PE) grounding point (made as close as possible to the I/O)

**The Kits**


Schneider Electric offers 3 kits you can use to provide functional ground to your shielded cable. An initial setup consists of an STB XSP 3000 kit and at least one of the cable clamp kits (STB XSP 3010 or STB XSP 3020). STB XSP 3010 kit comes with ten cable clamps for 1.5 mm to 6.5 mm (0.059 to 0.256 in) size cable. STB XSP 3020 kit comes with ten cable clamps for 5 mm to 11 m (0.19 in to 36.09 ft) size cables.



Kit	Comes with...
STB XSP 3000	two side brackets, one 1 m grounding bar and one FE grounding clamp  A technical diagram showing the components of the STB XSP 3000 kit. It features two side brackets, each with a circular hole at the top and a rectangular base. A long, thin grounding bar is positioned between them. One end of the bar is secured by an FE grounding clamp. Arrows point from the text labels 'Side brackets', 'Grounding bar', and 'FE grounding clamp' to their respective parts in the diagram.
STB XSP 3010	10 small cable clamps for 1.5mm to 6.5mm (0.059 to 0.256 in) cable  A technical drawing of a small cable clamp. It consists of a U-shaped metal piece with a circular hole at one end and a small protrusion at the other, designed to grip a cable.




Kit	Comes with...
STB XSP 3020	10 medium cable clamps for 5mm to 11mm (0.19 in to 36.09 ft) cable 

### STB XSP 3000 Assembly

Use the following procedure to assemble an STB XSP 3000 kit.

Step	Action
1	Open kit STB XSP 3000 and confirm you have the two side brackets, one grounding bar and one FE grounding clamp.
2	Assemble an STB island segment. 

Step	Action
3	<p data-bbox="428 201 1223 277">Loosen the bracket lockdown screws on each side bracket. Attach the side brackets to the DIN rail on both ends of your assembled STB island segment. They gently snap into place.</p>  <p data-bbox="428 711 617 735">Side brackets</p> <p data-bbox="897 358 1048 383">Lockdown screw</p> <p data-bbox="735 753 1048 777">1 2 3</p>
4	<p data-bbox="428 812 1223 859">Push the side brackets toward both ends of your segment so that they are snug against its walls, and tighten the lockdown screws.</p>  <p data-bbox="440 930 600 954">Lockdown screw</p> <p data-bbox="1002 930 1163 954">Lockdown screw</p>


Step	Action
5	<p>Determine the grounding bar length by measuring the distance between the outsides of the side bracket/segment assembly and add 1 cm (0.39 in). You can estimate a different bar length to meet your particular needs. Cut the bar to length.</p>  <p>The grounding bar is originally 1 M (9.37 in) long x 18 mm (0.71 in) wide x 3 mm (0.12 in) thick. It is made of tinned copper. Contact a supplier to order extra grounding bars.</p>
6	<p>With the bar cut to length, slide the FE grounding clamp onto the grounding bar. Tighten the lockdown screw on top of the clamp.</p> 
7	<p>Attach the grounding bar to the side brackets and tighten the lockdown screws on the side brackets.</p> 

Step	Action
8	Attach the clamp to your supplied functional ground using flat braided grounding cable.


**Clamp and Cable Assembly**

Use the grounding clamps to attach the shielding of the stripped cable to the FE grounding bar.

Step	Action
1	Position the grounding clamp in front of the module to which you intend to fasten the wiring. Pull back the spring loaded lock down bolt on the clamp. Slip the clamp onto the grounding bar, then release the lockdown bolt.



The diagram illustrates the assembly process in two parts. Part 1 shows a front view of a rack-mounted module with a grounding bar passing through it. A grounding clamp is positioned at the bottom of the module, ready to be attached to the bar. An upward-pointing arrow labeled '1' indicates the direction of assembly. Part 2 shows a close-up of the clamp. A hand is shown pulling back a spring-loaded lock-down bolt on the clamp. An upward-pointing arrow labeled '2' indicates the next step in the process.

Step	Action
2	<p>Strip 2.5 cm (0.98 in) of insulation off your cable to expose the braided shield. (Confirm the cable on either side of the stripped area is long enough to reach the I/O and field instruments). Pull back on the spring loaded lockdown bolt and slip the cable into the clamp. Release the lockdown bolt.</p>  <p>Alternatively, you can clamp your cable to the grounding bar while you attach the cable clamp to the bar.</p>
3	Connect your cable to its I/O and devices.

---

# Assigning an IP Address to the HART Multiplexer

# 6

---

## Overview

Now that you have built the multiplexer, you need to give it an IP address to be able to communicate with it. This chapter describes several different ways to do this.

## What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Assigning an IP Address to the HART Multiplexer	94
Determining the HART Multiplexer Default IP Address	98

## Assigning an IP Address to the HART Multiplexer

### Planning your Ethernet Network

Before you assign an IP address to your multiplexer, it is helpful to first develop a plan for how you will assign an IP address to each device. Such a plan should identify:

- the network prefix of the IP address
- the (optional) use of subnet masks to organize your network into logically distinct subdivisions
- the unique IP address to be assigned to each addressable device

### Assignment Methods

The HART multiplexer island communicates to a PLC and to asset management software (resident on a connected PC) over Ethernet. To prepare the multiplexer for Ethernet communications, assign IP parameter settings to the HART enabled Ethernet NIM.


You can set the IP address of the multiplexer island's NIM in several different ways, including the use of:

- the rotary switches on the front of the NIM
- the NIM embedded web pages
- Advantys configuration software connected to the NIM via Ethernet or a serial cable

For information on using the NIM embedded web pages, refer to the documentation that comes with your HART enabled Ethernet NIM, for example the STB NIP 2311.

## Rotary Switches

Use the rotary switches on the front of the HART enabled Ethernet NIM to specify how the NIM obtains its IP address settings:



## IP Parameter Assignment Sources

Before assigning an IP address, use the rotary switches to clear the NIM stored IP parameters. After setting the lower switch to either CLEAR IP setting, cycle power to the NIM to clear the previous IP address.

You can assign a new IP address using the following rotary switch settings:

- **DHCP server:**

Set the upper and lower switches to numeric values—from 00 to 159—to create a device name. Do this by using both switches, as follows:

- On the upper switch (tens digit), the available settings are 0...15.
- On the lower switch (ones digit), the available settings are 0...9.

The device name is the three-digit concatenation of the module name, the upper switch value, and the lower switch value. For example, for an STB NIP 2311 NIM:

- an upper switch setting of 12 and a lower switch setting of 3 creates a device name of *STBNIP2311\_123*, or
- an upper switch setting of 1 and a lower switch setting of 3 creates a device name of *STBNIP2311\_013*

**NOTE:** You also need to separately configure a DHCP server to assign the desired IP address to the NIM based on this device name. For example, you can use the DHCP server that is included in your Schneider Electric PLC Ethernet communication module.

- **BootP server:**

For a BootP-served IP address, select either of the two **BOOTP** positions on the bottom switch. (The setting of the top switch is ignored.)

**NOTE:** Separately configure a BootP server to assign the desired IP address to the NIM based on the NIM MAC ID. For example, you can use the BootP server that is included in your Schneider Electric PLC Ethernet communication module.

- **Static IP address settings:**

Set the lower switch to one of its two **STORED** positions. (The setting of the upper switch is ignored.) Then, use either the Advantys configuration software or the HART enabled Ethernet NIM embedded web pages to input IP address settings. Any assignment takes place on next power cycle.


- The two **CLEAR** IP settings clear the NIM stored IP parameters, leaving the island without an IP address.

**NOTE:** After you use the rotary switches to specify the IP addressing source, cycle power to the NIM to configure the IP address.

If the NIM does not receive its IP address setting via the selected method, it assigns a default IP address based on its MAC address (*see page 98*). The MAC address for a NIM is displayed above the Ethernet ports on the front of the module.

## IP Address Assignment Flowchart

The NIM performs the following checks to determine the IP address:



## Determining the HART Multiplexer Default IP Address

### Deriving an IP Address from a MAC Address

The STB NIP 2311 NIM assigns itself a default IP address—derived from its MAC address—when it does not receive an IP address by the method specified by the rotary switches. For example, a default IP address is assigned if:

- the bottom (ONES) switch is set to CLEAR IP
- the top (TENS) and bottom (ONES) switches are set to numerical values, but no DHCP server assigns an IP address to the NIM
- the bottom (ONES) switch is set to BootP, but no BootP server assigns an IP address to the NIM
- the bottom (ONES) switch is set to STORED, but no user-defined IP address has been input using either the Advantys configuration software or the web pages.

This situation occurs, for example, when a new NIM is being used for the first time

The 32-bit default IP address of the NIM is derived from the last 2 octets of its 48-bit MAC address. The default IP address observes the format 10.10.x.y, where:

- 10.10. are constants
- x.y. are the decimal values of the last 2 hexadecimal octets of the MAC address.

The following example shows you how to convert the two x.y. octets from hexadecimal to decimal format and identify the default IP address:

Step	Action	
1	Using a sample MAC address of 00-00-54-10-25-16, ignore the first four pairs (00-00-54-10).	
2	Convert the last two pairs (25 and 16) from hexadecimal to decimal format.	<b>25:</b> $(2 \times 16) + 5 = 37$ <b>16:</b> $(1 \times 16) + 6 = 22$
3	Observe the specified format (10.10.x.y.) to assemble the derived default IP address.	The default IP address is: 10.10.37.22

---

# Configuring the HART Multiplexer

# 7

---

## Overview

Before placing the STB AHI 8321 HART interface module into operation, configure its operating parameters. There are several ways to configure the STB AHI 8321, including:

- Use the HART enabled Ethernet NIM auto-configuration function to apply default parameter settings to all configurable island modules, including the STB AHI 8321 HART interface module.
- Use the Advantys configuration software to customize the default configuration of the STB AHI 8321 HART interface module, and any other island module with configurable settings.
- If you previously saved the STB island configuration settings to a SIM card, you can also apply those saved settings to the island.

## What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Auto-Configuring the HART Multiplexer	100
Customizing the HART Multiplexer Configuration	103
Configuring STB AHI 8321 Channel Settings	105
Mapping Data items to the HART Multiplexer Island Data Process Image	108
Viewing the IO Image for the STB AHI 8321 HART Interface Module	110
Configuring the STB AHI 8321 Module as Mandatory or Not Present	112
Data Process Image Items for the STB AHI 8321 HART Interface Module	114
Using the STB XMP 4440 Optional Removable Memory Card to Configure the Island	121
Applying a Stored Configuration to the HART Multiplexer	123

## Auto-Configuring the HART Multiplexer

### Factory Default Settings

Every configurable STB module is shipped with a set of predefined parameter settings. When you apply these predefined parameter settings, the HART multiplexer island becomes operational. You can apply the default settings via auto-configuration.

When you auto-configure the HART multiplexer island, the following default parameter settings are applied to each STB AHI 8321 HART interface module in the multiplexer island:

Parameter	Description	Default Setting
CH-Enable	The states—enabled or disabled—of the four channels of the HART interface module.	15 (all channels are enabled)
Channel 1...4 Settings		
<ul style="list-style-type: none"> <li>Lower Scan Address</li> </ul>	The first address, of a range of addresses, scanned by the HART interface module when looking for a HART instrument on the channel.	0
<ul style="list-style-type: none"> <li>Upper Scan Address</li> </ul>	The last address, of a range of addresses, scanned by the HART interface module when looking for a HART instrument on the channel.	15
<ul style="list-style-type: none"> <li>Number of Preambles</li> </ul>	The minimum number of preambles the HART interface module uses to communicate with a HART instrument.	5
<ul style="list-style-type: none"> <li>Number of Communication Retries</li> </ul>	The number of times the HART interface module will re-send a command after failing to communicate with a HART instrument.	5
<ul style="list-style-type: none"> <li>Number of Busy Retries</li> </ul>	The number of times the HART interface module will re-send a command after receiving a busy reply from a HART instrument.	2
<ul style="list-style-type: none"> <li>Fallback Mode Setting</li> </ul>	If the HART instrument on this channel is disconnected, or if there is no HART instrument, this value is assigned to the field instrument variables until a connection to a HART instrument is made.	NaN

**NOTE:** Your HART multiplexer island can also include the following analog I/O modules:

- STB ACI 0320
- STB ACI 8320
- STB ACO 0120
- STB ACO 0220

Refer to the *Advantys STB Analog I/O Modules Reference Guide* for a description of analog I/O default parameter settings.

To perform auto-configuration, you can use either:

- the RST button on the front face of the NIM
- the **Online** → **Force Auto-configuration** command in the Advantys configuration software

The simplest way to auto-configure the HART multiplexer is to use the RST button.

**NOTE:** Auto-configuration overwrites any pre-existing custom configuration with default settings for island modules. If you have previously used Advantys configuration software to apply a custom configuration (*see page 103*) to your HART multiplexer island, do not press the RST button or force auto-configuration.

## **⚠ CAUTION**


### **UNINTENDED EQUIPMENT OPERATION**

Do not press the RST button—or force auto-configuration—for a HART multiplexer island that is operating using an application that was custom configured with Advantys configuration software.

**Failure to follow these instructions can result in injury or equipment damage.**

### **The RST Button**

The RST button performs a Flash memory overwrite operation. The RST button is located immediately above the CFG port on the NIM, behind the NIM hinged cover:



## How to Perform Auto-Configuration

To perform auto-configuration, follow these steps:

Step	Action
1	Remove any SIM card ( <i>see page 125</i> ) from the NIM.
2	Using a small screwdriver with a flat blade no wider than 2.5 mm (0.99 in), press the RST button and hold it down for at least 2 seconds. Do not use: <ul style="list-style-type: none"><li>• a sharp object that can damage the RST button, or</li><li>• a soft item like a pencil that can break off and jam the RST button</li></ul>

If the HART multiplexer island was previously auto-configured, auto-configuration changes no parameter settings. However, the HART multiplexer island stops updating I/O during the auto-configuration process.

If you previously used Advantys configuration software to edit the island parameters, auto-configuration overwrites your customized settings with the factory default parameters.

## Customizing the HART Multiplexer Configuration

### Using Advantys Configuration Software

After the HART multiplexer island is powered up and auto-configured, you can use the Advantys configuration software to upload the default island configuration, where you can customize the configuration.

**NOTE:** You do not need to use the Advantys configuration software to operate your HART multiplexer. Using the RST button, you can apply default settings (see page 100) to each module in your island, and continue to operate the multiplexer in its default configuration. However, Schneider Electric recommends that you use Advantys configuration software to configure and monitor your HART multiplexer.

You can use the Advantys configuration software to:

- create, modify, and save the logical description of the physical devices used in a project
- monitor, adjust data values, and debug the project in online mode
- view a graphical display of the selected equipment and a hierarchical display of the island (the **Workspace Browser**)
- enhance performance of specific modules

For information on how to use the Advantys configuration software to configure the configurable modules in your HART multiplexer island, refer to the Advantys configuration software online help. Detailed instruction on how to use Advantys configuration software is beyond the scope of this document.

### Customizing the STB AHI 8321 HART Interface Module

To customize the configuration of the HART multiplexer island, including the STB AHI 8321 HART interface module, you need to use the Advantys configuration software. In the Advantys configuration software, with the island unlocked, select a HART interface module in the island and open the **Module Editor**, which presents the following tabs:

- Use the **Parameters** tab to access and edit configurable parameters for the STB AHI 8321 module.
- Use the **I/O Mapping** tab to edit the multiplexer island data process image, by adding and removing STB AHI 8321 module data items.
- Use the **IO Image** tab to view a list of STB AHI 8321 module data process image items for the selected HART interface module.
- Use the **Options** tab to specify that the STB AHI 8321 module is:
  - a mandatory island module
  - not present, but its place preserved in the island process image

### **Schneider Electric Technical Support**

Schneider Electric provides technical support for its products, including the Advantys configuration software. To reach Schneider Electric tech support, visit [www.Schneider-Electric.com](http://www.Schneider-Electric.com) and click on the image for the Schneider Electric

*Customer Care Center*  .

## Configuring STB AHI 8321 Channel Settings

### Configuring HART Interface Module Channel Properties


Use the **Parameters** tab of the **Module Editor** for the STB AHI 8321 module to configure the HART channels. In this tab, you can:

- enable or disable each of the module's four HART channels
- define the range of address the STB AHI 8321 module scans when searching for a HART instrument on each HART channel
- specify the minimum number of preambles the STB AHI 8321 module uses to communicate with a HART instrument

Create the STB AHI 8321 module configuration settings offline, then download them—along with the rest of the multiplexer island settings—to the NIM. The NIM uses these settings to configure the STB AHI 8321 module before placing the island into the run state.

**NOTE:** You cannot configure values or labels when the island is locked or online. For editable parameters, the valid value range is displayed in the status bar of the **Module Editor**.

The **Parameters** tab:



**NOTE:** Configuration changes entered in this tab take effect only after you use the Advantys Configuration Software to:

1. save your edits by clicking either the **OK** or **Apply** button
2. download the island configuration by using:
  - a. the **Online** → **Connect** command to connect to the island
  - b. the **Online** → **Download into the Island** command to send the configuration to the island

### Configurable Parameters

You can configure the following parameters for the STB AHI 8321 HART interface module:

Parameter Name	Description
CH-Enable	<p>The state of all four of the HART channels. The CH-Enable value equals the sum of the bit value for each channel that is enabled:</p> <ul style="list-style-type: none"> <li>● bit 0 (channel 1) has a value of 1, when enabled</li> <li>● bit 1 (channel 2) has a value of 2, when enabled</li> <li>● bit 2 (channel 3) has a value of 4, when enabled</li> <li>● bit 3 (channel 4) has a value of 8, when enabled</li> </ul> <p>The default value is 15, indicating all 4 HART channels are enabled.  <b>NOTE:</b> When CH-Enable appears as a parameter in this tab, it is not mapped to the process image and cannot be controlled by program logic. You can map the CH-Enable parameter to the process image by selecting it in the <b>I/O Mapping</b> tab.</p>
● Channel 1...4	<p>Bit 0 (channel 1), bit 1 (channel 2), bit 2 (channel 3), bit 3 (channel 4) of CH-Enable. Sets the status of the selected channel to one of the following settings:</p> <ul style="list-style-type: none"> <li>● 0 = disabled</li> <li>● 1 = enabled (default)</li> </ul>
Channel 1...4 Settings	
● Lower Scan Address	<p>Use these two settings to establish the address range the HART interface module searches when looking for a HART instrument on the specified channel.</p> <ul style="list-style-type: none"> <li>● minimum value = 0</li> <li>● maximum value = 63</li> </ul> <p>Lower Scan Address Default = 0; Upper Scan Address Default = 15.  <b>NOTE:</b> The value of the Upper Scan Address must be equal to or greater than the value of the Lower Scan Address.</p>
● Upper Scan Address	

Parameter Name	Description
<ul style="list-style-type: none"> <li>Number of Preambles</li> </ul>	<p>The minimum number of preambles the HART interface module uses to communicate with a HART instrument. If the HART instrument requires:</p> <ul style="list-style-type: none"> <li>more preambles, the HART interface module sends more preambles</li> <li>fewer preambles, the HART interface module sends the minimum number configured by this setting</li> </ul> <p>Default = 5.</p>
<ul style="list-style-type: none"> <li>Number of Communication Retries</li> </ul>	<p>The number of times the HART interface module re-sends a command to a non-responsive HART instrument. Valid values = 0, 1, and 2. Default = 5.</p>
<ul style="list-style-type: none"> <li>Number of Busy Retries</li> </ul>	<p>The number of times the HART interface module re-sends a command after receiving a busy reply from a HART instrument. Valid values = 0, 1, and 2. Default = 2.</p>
<ul style="list-style-type: none"> <li>Fallback Mode Setting</li> </ul>	<p>If the HART instrument on this channel is disconnected, or if there is no HART instrument, this setting determines the value that is assigned to the primary variable (<b>PV</b>) until a connection to a HART instrument is made:</p> <ul style="list-style-type: none"> <li>0 - Set to 0</li> <li>1 - Hold Last Value</li> <li>2 - Not a Number (NaN)</li> </ul> <p>Default = NaN</p>

### Restore Default Values

You can click the **Restore Default Value** button to reset the modified values on this tab to their default values.

## Mapping Data items to the HART Multiplexer Island Data Process Image


### Editing the HART Multiplexer Data Process Image

You can modify the HART multiplexer island data process image only by using the Advantys configuration software. You can use the **I/O Mapping** tab of the **Module Editor** to perform the following tasks for a selected STB AHI 8321 module:

- Add data items to, or remove data items from, the multiplexer island data process image relating to the selected STB AHI 8321 module
- Configure the CH-Enable parameter for the selected STB AHI 8321 module as either:
  - a static property manually set in the **Parameters** tab of the **Module Editor**, or
  - a dynamic property controlled by program logic
- Restore the default list of input and output data items included in the island data process image by clicking the **Restore Default Values** button
- Display the data type and object ID for each input and output data item

I/O mapping lets you optimize the HART multiplexer island process image on a module-by-module basis. The title bar at the top of the **Module Editor** displays the name of the HART interface module and its exact location on the island bus.

The **I/O Mapping** tab:



**NOTE:** Configuration changes entered in this tab take effect only after you use the Advantys configuration software to:

1. save your edits by clicking either the **OK** or **Apply** button
2. download the island configuration by using:
  - a. the **Online** → **Connect** command to connect to the island
  - b. the **Online** → **Download into the Island** command to send the configuration to the island

Both the **Input Data** and the **Output Data** areas present the following columns:

Column Name	Description
Data Item Name	Displays both mapped and unmapped data items.
I/O	A check mark indicates the data item is mapped to the island data process image. You can manage the quantity of data included in the HART multiplexer data process image by selecting or de-selecting data items in this column. <b>NOTE:</b> A gray background in this column indicates the data item is part of the data process image and cannot be deleted.
User Defined Label	Displays the labels associated with each data item. You can edit labels for a single HART interface module in the <b>I/O Image</b> tab and the <b>Parameters</b> tab of the <b>Module Editor</b> . <b>NOTE:</b> You can also use the <b>Island</b> → <b>Label Editor...</b> command to open a <b>Label Editor</b> and edit labels for the entire island.

**NOTE:** Saving an added or deleted data item in this tab simultaneously adds or deletes it in the **IO Image** tab.

If the current setting of any data item is different from its default setting, the  icon is displayed to the left of the **Hexadecimal** check box.

To restore input and output data items to their default mappings, click **Restore Default Values** in offline mode.

### Mapping Input Data Items

For information describing individual input data items, refer to the topic **STB AHI 8321 Input Items** (*see page 114*).

### Mapping Output Data Items

For information describing individual output data items, refer to the topic **STB AHI 8321 Output Items** (*see page 118*).

## Viewing the IO Image for the STB AHI 8321 HART Interface Module


### Viewing Mapped Data Items

Use the **IO Image** tab of the **Module Editor** for the STB AHI 8321 module to:

- view the STB AHI 8321 module data items that are part of the multiplexer island data process image
- add user-defined labels to items in the list

The title bar of the **Module Editor** displays the name of the module and its exact location on the island bus.

The **IO Image** tab:



The **IO Image** tab presents the following columns:

Column Name	Description
Data Item Name	Displays data items, for the selected STB AHI 8321 module, that have been mapped to the HART multiplexer island data process image. Items that appear in this column are selected in the <b>I/O Mapping</b> tab
Current Value	<b>Current Value:</b> Displays the current value for each mapped data item. You can toggle the format of the displayed values between decimal (the default) and hexadecimal by selecting or clearing the <b>Hexadecimal</b> check box. <b>NOTE:</b> The actual values are displayed only when the island is online and in either the operational state or the non-mandatory module mismatch state. For other states, the symbol --- is displayed.
User Defined Label	Displays the labels associated with each data item. Double-click in the appropriate cell to enter label text. Each label can be up to 24 characters long.
Memory Address	Displays the Modbus register address for parent data items. Values in this column are read-only


## Configuring the STB AHI 8321 Module as Mandatory or Not Present

### Introduction

Use the **Options** tab of the **Module Editor** to indicate if the STB AHI 8321 HART interface module is:

- a mandatory island module (see page 113)
- a module that is not present (see page 113) in the island

The **Options** tab of the STB AHI 8321 HART interface module:



The **Prioritize** parameter is disabled and does not apply to the STB AHI 8321HART interface module.

## Mandatory Module

Select the **Mandatory Module** setting to designate the module as mandatory. If a mandatory module stops operating or is removed from the island, the island stops writing to outputs, and island modules go to their fallback states.

The island returns to its operational state after you install at this exact location on the bus:

- the same functional module
- a new module of the same type and major version number

By default, the **Mandatory Module** setting is de-selected.

**NOTE:** The **Mandatory** check box can be selected or de-selected only when the island is in offline mode.

## Not Present

Check this box to mark the module as virtual placeholder.

The virtual placeholder designation lets you physically remove both a module and its base from the island without changing the island process image. In this way, you can physically remove one or more modules without having to edit the PLC program that controls the island.

In the **Module Editor**, modules configured as *Not Present* are marked with crossed red lines.

## Data Process Image Items for the STB AHI 8321 HART Interface Module

### Input and Output Data Process Image Items

The STB AHI 8321 HART interface module supports the mapping of HART instrument input and output data items to the HART multiplexer island process image.

### Input Data Items

The **Input Data** area of the **I/O Mapping** tab of the **Module Editor** lists read-only input items for the STB AHI 8321 HART interface module. These items can be added to the HART multiplexer island data process image, and include:

Data Item	Data Type	Mapped by Default?	Is Default Mapping Editable?	Bytes
Module Status	Word	Yes	No	2
Channel 1...4 Status	Word	Yes	No	2
Alignment	Word	No	Yes	2
Channel 1...4 Hart Instrument Specific Variables:				
Primary Variable (Channel 1...4 Input Data)	Float	Yes	Yes	4
Instrument Status	32 bit unsigned	No	Yes	4
Secondary Variable	Float	No	Yes	4
Current Value	Float	No	Yes	4
Percent Value	Float	No	Yes	4
Update Counter	32 bit unsigned	No	Yes	4

**NOTE:** You can monitor the status of the mapped input data items, listed above, as follows:

- you can view all of the mapped input data items in the Advantys configuration software **Module Editor** for the selected STB AHI 8321 HART interface module, or
- you can view many of the mapped input data items in the diagnostic web pages for the HART enabled Ethernet NIM

## Module Status

The **Module Status** word presents a snapshot of the overall health of the HART interface module and its 4 channels.

Bit Number	Name	Description
0	Global Status	= 1 if the HART interface module has detected one or more of the following conditions: <ul style="list-style-type: none"> <li>• one or more HART channels are disconnected (Bit 1 (Disconnected) = 1)</li> <li>• a HART channel is connected to a field device that is materially different from the device configured for that channel; e.g., a device of different device type or made by a different manufacturer. (Bit 3 (Instrument Changed, Major) = 1)</li> <li>• an internal communication event—ICE—has occurred (Bit 4 (ICE) = 1)</li> </ul>
1	Disconnected	= 1 if any channel is in the disconnected (CH-Disconnected) state
2	Instrument Changed, Minor	=1 if any channel is in the instrument changed, minor ( <i>see page 120</i> ) state
3	Instrument Changed, Major	=1 if any channel is in the instrument changed, major ( <i>see page 120</i> ) state
4...6	—	= 0 (not used)
7	ICE	= 1 on the occurrence of an <i>internal communication event</i>
8...15	—	= 0 (not used)

## Channel Status


The **Channel Status** words report the status of each of the STB AHI 8321 HART interface module's four channels. **Channel Status** values are as follows:

Value	Name	Description
0	CH-Disabled	The channel is disabled.
1	CH-Connecting	The STB AHI 8321 is searching for, and attempting to connect with, a HART instrument on the channel.
2	CH-Connected	The channel is connected to a HART instrument.
3	CH-MinorDiff	One or more minor differences ( <i>see page 120</i> ) exist between the connected HART instrument and the instrument description in the multiplexer island configuration.
4	CH-MajorDiff	One or more major differences ( <i>see page 120</i> ) exist between the connected HART instrument and the instrument description in the multiplexer island configuration.
5	CH-Disconnected	This state indicates either: <ul style="list-style-type: none"> <li>• The STB AHI 8321 discovered no HART instrument on the channel, after performing two scans of the specified address range.</li> <li>• The STB AHI 8321 discovered a HART instrument on the channel, but the connection was lost.</li> </ul> The STB AHI 8321 continues to search for a HART instrument on this channel.
6...255	—	(not used)

## Alignment

Use this parameter to place data objects on a 32-bit boundary, for architectures—such as the Schneider Electric M340 platform—that require input data to be read or written in 32-bit (2 register) increments. Mapping this parameter to the input data process image adds a 2 byte (1 register) buffer to the I/O image immediately in front of the input data.

You can use the **I/O Image** tab of the **Module Editor** in the Advantys configuration software to determine whether input data for an STB AHI 8321 HART interface module resides on a 32-bit boundary.



In the above example, the **Alignment** parameter is not enabled. Input data begins at memory address 45426. Because 45426 is an even number, input data begins at a 32-bit boundary. In this case, it is not necessary to enable the **Alignment** parameter.

Alternatively, if input data instead began at an odd number memory address—for example, 42425—input data would not begin at a 32-bit boundary. In this case, enabling the **Alignment** parameter adds a 2 byte buffer to the I/O image, and places the input data object on a 32-bit boundary.

## Channel 1...4 HART Instrument Specific Data Items

The STB AHI 8321 can also add to the multiplexer island process image the following data items for each HART channel:

- Primary Variable (PV): manufacturer defined
- Instrument Status: reports one of the following conditions:
  - Non-operational Instrument: a detected error rendered the instrument non-operational
  - Configuration Changed: an operation occurred that changed the instrument configuration
  - Cold Start: the instrument was reset, or power was cycled off then on
  - More Status Available: additional instrument information is available via HART command 48 (Read Additional Status Information)
  - Loop Current Fixed: current on the HART channel is being held at a fixed value, and is not responding to process variations
  - Loop Current Saturated: current on the HART channel has reached its upper or lower limit, and cannot increase or decrease further
  - Non-primary Variable Out of Limits: the value of an instrument variable, other than the Primary Variable (PV), has travelled beyond its operating limits
  - Primary Variable Out of Limits: the value of the instrument Primary Variable (PV) has travelled beyond its operating limits
- Secondary Variable (SV): manufacturer defined
- Current Value: the actual reading of loop current, from 4...20 mA
- Percent Value: the actual reading of loop current, expressed as a percent of the 16 mA range
- Update Counter: a counter that is incremented each time the data process image is updated

Check the documentation for your specific HART instrument to determine if it offers the above data items.

## Output Data Items

The **Output Data** area of the **I/O Mapping** tab of the **Module Editor** lists output items for the STB AHI 8321 HART interface module. These items can be added to the HART multiplexer island data process image. These items include:

Data Item	Data Type	Mapped by Default?	Is Default Mapping Editable?
CH-ResetChanged	Byte	Yes	No
CH-Enable	Byte	No	Yes

**NOTE:** When an output data item in the **I/O Mapping** tab is:

- *Selected*: program logic dynamically controls the item during run-time.
- *De-selected*: the data item is added to the list of configurable data items in the **Properties** tab, where you can set a static value to be assigned to the item at start-up.

## CH-ResetChanged

Logic in the PLC application uses the **CH-ResetChanged** data item to accept a HART instrument that has been detected to have a **Module Status** identity of either **Instrument Changed, Minor** or **Instrument Changed, Major**. When PLC logic causes a bit in this register to transition from 0 to 1, the HART instrument detected on that channel is accepted as the current instrument.

The **CH-ResetChanged** word includes the following bits:

Bit Number	Name	Description
0	CH-1 Reset	0 to 1 transition clears changed instrument indicators, and accepts the detected HART instrument on the channel.
1	CH-2 Reset	
2	CH-3 Reset	
3	CH-4 Reset	
4...15	—	(not used)

## CH-Enable

The **CH-Enable** output item reports and controls the state—enabled or disabled—of each of the four channels of the HART interface module. Default value = 15 (dec), indicating the 4 HART channels are enabled

The bits in the **CH-Enable** word:

Bit Number	Name	Description
0	CH-1 Enable	<ul style="list-style-type: none"> <li>● 0 = disabled</li> <li>● 1 = enabled (default)</li> </ul>
1	CH-2 Enable	
2	CH-3 Enable	
3	CH-4 Enable	
4...15	—	= 0

## Major and Minor Differences

When the STB AHI 8321 module establishes connection with a HART instrument, it checks whether the present connection is the first connection made on the channel.

If there was a previous connection, the module checks whether the connected instrument matches the previously connected instrument. It does this by comparing the instrument-defining elements in the presently connected instrument with those recorded for the previously connected instrument.

The module gathers data from the HART instrument in the same manner whether the instrument is connected, connected with major differences, or connected with minor differences.

### NOTE:

- To see which instrument-defining element has changed, you can use HART command 0 (Read Unique Identifier) to examine the definition of the presently connected HART field device.
- To accept a connected HART field instrument that has either major differences or minor differences, set the value of the **CH-ResetChanged** parameter to 1 for the appropriate channel.

### Major Differences:

The following differences in the definition of a HART field instrument are described as major:

- instrument type: e.g., a NIM (protocol gateway) instead of a sensor
- instrument manufacturer
- manufacturer-specific instrument model number
- instrument firmware revision number
- the collection of instrument supported Universal and Common Practice HART commands

### Minor Differences:

The following differences in the definition of a HART field instrument are described as minor:

- instrument serial number
- instrument supported HART protocol version: e.g., V. 7 instead of V.5
- instrument electronics components

## Using the STB XMP 4440 Optional Removable Memory Card to Configure the Island

### When to Use a SIM Card

You can use a removable memory card in the following scenarios. Each scenario assumes that a removable memory card—with a valid island configuration—is already installed in the NIM.

- Initial island bus configuration
- Replacement of the current configuration data in Flash memory to:
  - apply custom configuration data to your island
  - temporarily implement an alternative configuration; for example, to replace an island configuration used daily with one used to fulfill a special order
- Copying configuration data from one NIM to another NIM with the same part number. For example, copying the configuration from a non-operational NIM to its replacement.
- Configuring multiple islands with the same configuration data

**NOTE:** The use of the Advantys configuration software is required when writing configuration data to the removable memory card in the first instance.

### Applying Ethernet Address Settings Using a SIM Card

The removable memory card option in the STB NIP 2311 has an additional feature that allows you to store Ethernet network configuration parameters. When properly configured, these parameters are written to flash along with the island parameters on power up. To apply Ethernet addressing parameters:

1. Use the Advantys configuration software to configure the network communication parameters.
2. Configure the communication parameters only while the island is offline. The configured settings take effect after a power cycle of the STB NIP 2311.
3. Select the **Enable Editing** check box in the **Ethernet Parameters** tab to enable parameter entries. Verify that this check box remains selected when the configuration is downloaded to the island. If it is de-selected before configuration download to the island, these parameters are not used upon power up.
4. Set the **ONES** rotary switch position to **STORED** to use the configured communication parameters.

**NOTE:** Using the same memory card to replicate multiple islands with the same stored IP configuration can lead to duplicate IP addresses. In this case, obtain a unique IP address for each island NIM and separately configure the IP address (*see page 94*) for each island.

## Initial Configuration and Reconfiguration Scenarios

Use the following procedure to set up an island bus with configuration data that was previously saved to a removable memory card. You can use this procedure to configure a new island or to overwrite an existing configuration.

**NOTE:** The use of this procedure overwrites your existing configuration data.

Step	Action	Result
1	Install the removable memory card in its drawer in the NIM (see page 123).	
2	Power up the new island bus.	The configuration data on the card is checked. If the data is valid, it is written to the NIM and overwrites the existing configuration. The system restarts automatically, and the island is configured with this data. If the configuration data is invalid, it is not used and the island bus stops.

## Configuring Multiple Islands with the Same Data

You can use a removable memory card to make a copy of your configuration data; then use the card to configure multiple island buses. This capability is advantageous in a distributed manufacturing environment or for an OEM (original equipment manufacturer).

**NOTE:** The islands can be either new or previously configured, provided that:

- the island NIMs are the same type, with the same part number, and
- the physical island configurations (i.e., the sequence and identity of island modules) are the same

## Applying a Stored Configuration to the HART Multiplexer

### Using a Removable Memory Card

The STB XMP 4440 removable memory card (SIM card) lets you store, distribute, and reuse custom island bus configurations. If a memory card with a valid configuration is in the NIM on start-up, the configuration on the card overwrites the configuration in Flash memory. In this way, you can use a SIM card to replace the existing configuration in the NIM with the configuration that is stored on the SIM card. This process can be very useful if you need to replace your NIM or you want to quickly replicate island configurations.

The removable memory card is an optional STB feature.

### Caring for a SIM Card

SIM card performance can be degraded by dirt or grease on its circuitry. Contamination of, or damage to, the SIM card can create an invalid configuration.

#### CAUTION



##### **LOSS OF CONFIGURATION: MEMORY CARD DAMAGE OR CONTAMINATION**

- Use care when handling the card.
- Inspect for contamination, physical damage, and scratches before installing the card in the NIM drawer.
- If the card does get dirty, clean it with a soft dry cloth.

**Failure to follow these instructions can result in injury or equipment damage.**



## Installing the SIM Card

Use the following procedure to install the memory card:

Step	Action
1	<p>Punch out the removable memory card from the plastic card on which it is shipped.</p>  <p>Confirm that the edges of the card are smooth after you punch it out.</p>
2	<p>Open the card drawer on the front of the NIM. To more easily work with the SIM card, you can pull the drawer out from the NIM housing.</p>
3	<p>Align the chamfered edge (the 45° corner) of the removable memory card with the one in the mounting slot in the card drawer. Hold the card so that the chamfer is in the upper left corner.</p> 
4	<p>Seat the card in the mounting slot, applying slight pressure to the card until it snaps into place. Verify that the back edge of the card is flush with the back of the drawer.</p>
5	<p>Close the drawer.</p>

## Removing the Card

Use the following procedure to remove the memory card from the NIM. Avoid touching the circuitry on the card.

Step	Action
1	Open the card drawer. 
2	Push the removable memory card out of the drawer through the round opening at the back. Use a soft but firm object like a pencil eraser. 



---

# Wiring the Multiplexer



---

## Overview

This chapter presents sample wiring diagrams for the HART multiplexer island, including:

- providing logic power to the NIM
- providing sensor and actuator power to:
  - power distribution modules
  - auxiliary power supply modules
- wiring the STB AHI 8321 HART interface module to I/O, which can be:
  - located in remote I/O drops
  - resident in the HART multiplexer island

## What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
8.1	Providing Power to the HART Multiplexer	128
8.2	Wiring the HART Multiplexer to I/O Modules	132

## 8.1 Providing Power to the HART Multiplexer

---

### Wiring External Power Supplies to the HART Multiplexer Island

#### Logic Power

The STB NIP 2311 NIM provides 5 Vdc logic power to the HART multiplexer island backplane, and can provide 1.2 A of maximum current to island modules. If you place more modules in the primary island segment than the NIM can support, you can add an STB CPS 2111 auxiliary power supply to the island segment.

**NOTE:** Refer to the list of NIM, BOS and Auxiliary Power Supply Modules (see page 56) for information describing the logic power capacity of the STB NIP 2311 NIM. Refer to the list of Analog I/O modules (see page 57) for the power consumption requirements of island modules.

#### Input and Output Power

The STB PDT 3100 standard power distribution module (PDM) distributes power separately across the island's sensor bus to the input modules in its group and along the island's actuator bus to the output modules in its group. By contrast, the STB PDT 3105 basic power distribution module distributes a single supply of sensor and actuator power along a single bus.


If you place more modules in the primary island segment than either PDM can supply, you can add additional PDMs to the island. Placing a PDM to the right of a module group terminates the sensor and actuator bus for the preceding (leftward) group and begins a new (rightward) module group.

**NOTE:** Refer to the list of power distribution modules (see page 58) for information describing the logic power capacity of the STB PDT 3100 and STB PDT 3105 PDMs.

#### Providing Logic, Input and Output Power to the First Module Group

The first module in each HART multiplexer island is an STB NIP 2311 NIM, which provides logic power to the following modules. A PDM module is placed in the second position in the HART multiplexer island, and provides input (actuator) and output (sensor) power to the first module group.

The following graphic shows you how to provide power supply wiring to the STB NIP 2311 NIM and an STB PDT 3100 standard PDM:



- 1 +24 Vdc sensor bus power
- 2 sensor bus return
- 3 +24 Vdc actuator bus power
- 4 actuator bus return
- 5 +24 Vdc island logic power supply
- 6 island logic power return
- 7 External 24 Vdc power supply
- 8 Wurth 74271633 ferrite bead


**NOTE:** To maintain CE compliance, use a Wurth 74271633 ferrite bead with NIM, PDM, BOS, and CPS power supplies. Pass the twisted pair wiring through the ferrite bead twice.

**NOTE:** This example presumes a single external power supply is adequate to meet the logic, actuator and sensor power requirements of the first module group. If this is not true, you can use separate external power supplies to provide each type of power.

### Providing Logic, Input and Output Power to the Subsequent Module Groups

You begin a new (rightward) module group by inserting an additional PDM module into the island segment. The additional PDM provides input (actuator) and output (sensor) power to the new module group. You may also need to provide additional logic power to the new module group. In this case, you will add an auxiliary power supply.

The following graphic shows you how to provide power supply wiring to the STB CPS 2111 auxiliary power supply and an STB PDT 3100 standard PDM:



- 1 +24 Vdc sensor bus power
- 2 sensor bus return
- 3 +24 Vdc actuator bus power
- 4 actuator bus return
- 5 +24 Vdc island logic power supply
- 6 island logic power return
- 7 External 24 Vdc power supply
- 8 Wurth 74271633 ferrite bead

**NOTE:** To maintain CE compliance, use a Wurth 74271633 ferrite bead with NIM, PDM, BOS, and CPS power supplies. Pass the twisted pair wiring through the ferrite bead twice.

**NOTE:** This example presumes a single external power supply is adequate to meet the logic, actuator and sensor power requirements of the first module group. If this is not true, you can use separate external power supplies to provide each type of power.

## 8.2 Wiring the HART Multiplexer to I/O Modules

### Overview

A single Schneider Electric HART multiplexer can support up to 32 current loop channels. The STB AHI 8321 HART interface module is a passive device. If the HART interface module loses its power, the operations of connected analog I/O and HART field devices continue without interruption.

The following topics depict HART multiplexers that support the maximum number of channels for I/O modules that are:

- resident in the HART multiplexer STB island
- located in a remote M340, Premium, or Quantum drop

**NOTE:** Current loop wiring to the STB AHI 8321 HART interface module are made using the STB XTS 2150 18-terminal clamp style connector that ships with the module.

Unplugging the I/O wiring connector on the STB AHI 8321 HART interface module breaks the 4-20 mA current loop connecting the analog I/O card to the field devices. Digital and analog communication on the loop will be lost.

### WARNING

#### LOSS OF COMMUNICATION

Do not remove the I/O wiring connector on the STB AHI 8321 HART interface module while the system is operating under power.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

### What Is in This Section?

This section contains the following topics:

Topic	Page
Resistance Calculation for Current Loop Wiring	133
Setting Analog Output Rise and Fall Times for the STB AHI 8321 Module	134
STB I/O Wiring Example	136
Quantum I/O Wiring Example	141
Premium I/O Wiring Example	146
M340 I/O Wiring Example	151

## Resistance Calculation for Current Loop Wiring

### Calculating Resistance Requirements

A load resistor may need to be connected in series with either terminal of a HART field instrument. The maximum series resistance in the circuit—including wiring lead resistance—is a function of the voltage supply, and can be calculated using the formula:

$$R_L = \left( \frac{V_s - 12}{0.023} \right) - R_S$$

**R<sub>L</sub>** Load resistance expressed in ohms

**V<sub>s</sub>** Voltage supply expressed in Volts

**R<sub>S</sub>** Total loop resistance in ohms, including resistances of analog cards to which the HART instrument is to be serially connected

The following table displays examples of maximum series resistance at supply voltages, assuming  $R_S = 0$ :

Maximum Series Resistance (R <sub>L</sub> )	Supply Voltage
1300 ohms	42.0 Volts
520 ohms	24.0 Volts
417 ohms	21.6 Volts
250 ohms	18.0 Volts
0 ohms	12.0 Volts

**NOTE:** The wiring diagrams depicted in this chapter include the necessary load resistors for those specific wiring designs. Use the preceding formula when calculating load resistance for wiring designs that differ from the wiring diagrams depicted in this chapter.

## Setting Analog Output Rise and Fall Times for the STB AHI 8321 Module

### Adjusting Output Module Rise and Fall Times

Many analog output modules can exceed the maximum rise and fall time—known as “slope”—that is recommended by the HART Foundation for current signals. A faster than recommended slope can cause variations in the HART signal. To help avoid this occurrence, configure the application that drives analog current outputs so that maximum output rise and fall time does not exceed:

$0.8\text{ma/msec}$


or

$(0.04 * \text{Full Scale Value})/\text{msec}$

However, because the PLC, network interface module and analog I/O modules are updated only once every scan period, Schneider Electric recommends that analog current outputs be incremented or decremented 4% of full scale value every scan period until the desired current value is attained.

For example, in the case of an STB island with a scan period is 40 msec: for an output module (for example, the STB ACO 0220), the rise or fall slope should equal 4% of full scale value every 40 msec.

The following chart describes the relation between current and slope times for 4-20 mA current output modules:



## STB I/O Wiring Example

### HART Multiplexer with Resident I/O

The STB input and output modules that you connect to the HART multiplexer can be located in:


- the HART multiplexer island
- an STB island that is separate from the HART multiplexer island

The specific placement of your input and output modules is determined by your specific application.

The following diagram provides an example of a HART multiplexer island that supports the maximum number of 32 analog channels—in this example, 28 input channels and 4 output channels. The input and output modules are resident in the HART multiplexer island. This HART multiplexer is assembled using the following STB equipment:

- Modules:
  - STB NIP 2311 network interface module (1)
  - STB PDT 3100 power distribution modules (5)
  - STB ACI 8220 4-channel analog input modules (7)
  - STB ACO 0220 2-channel analog output modules (2)
  - STB AHI 8321 HART interface modules (8)
  - STB CPS 2111 Auxiliary Power Supplies (4)
- Bases:
  - STB XBA 2200 base (5)—for power distribution modules
  - STB XBA 2100 bases (4)—for auxiliary power supplies
  - STB XBA 2000 Type 2 bases (9)—for analog I/O modules
  - STB XBA 3000 Type 3 bases (8)—for HART interface modules

## A HART multiplexer with STB I/O:



- 1 PC running asset management software
- 2 Ethernet switch
- 3 Fieldbus master (PLC)
- 4 HART multiplexer with resident I/O and HART interface modules
- 5 4-20 mA current loop wiring from I/O to HART instruments

When connecting the island modules to current loop wiring:

- use wire sizes in the range 0.20...0.82 mm<sup>2</sup> (24...18 AWG)
- strip at least 9 mm (0.35 in) from the wire's jacket for the module connection
- use shielded twisted-pair cable
- tie the twisted-pair cable shield to an external clamp that is tied to functional ground (FE)


**NOTE:** Refer to the following examples, for detailed wiring diagrams of inputs and outputs.

### Wiring the STB ACI 8320 Input Module to the HART Interface Module

In this specific example:

- Current loop wiring connections are made directly from the HART compliant instruments to pins on the input module.
- Parallel wiring connections are made from the input module to the STB AHF 8321 for each HART channel.
- Each input module provides an internal 250 Ω resistor to the current loop.
- Each HART interface module provides an internal 260 Ω resistor to the current loop.

- Schneider Electric recommends that each current loop utilize a loop power supply (see page 61).
- NOTE:** For other I/O modules and configurations, you need to calculate your specific resistance requirements (see page 133).



- 1 HART instrument
- 2 External 24 Vdc power supply

The STB ACI 8320 input module uses two six-terminal field wiring connectors. You can use either:

- two STB XTS 1100 screw type field wiring connectors
- two STB XTS 2100 spring clamp field wiring connectors

Each field wiring connector has six connection terminals, with a 3.8 mm (0.15 in) pitch between each pin. Individual connector terminals accept one field wire. Use shielded twisted pair wire sizes in the range 0.20...0.82 mm<sup>2</sup> (24...18 AWG).


## Wiring the STB ACO 0220 Output Module to the HART Interface Module, Using Internal Power

The following diagram shows you how to wire the STB ACO 0220 output module to the STB AHI 8321 HART interface module for use as either a current source or a current sink.

- Current loop wiring connections are made from the HART compliant instruments, through the HART interface module, to pins on the output module. This design employs the 260  $\Omega$  HART filter in the STB AHI 8321 HART interface module.
- Jumper connections are made on the STB ACO 0220 output module to apply 24 Vdc internal power to the current loop.
- An external 220  $\Omega$  resistor is applied to each current loop.

**NOTE:** It may be necessary to adjust the rise and fall times (*see page 134*) of analog output modules to facilitate HART communication.

**NOTE:** For other I/O modules and configurations, you need to calculate your specific resistance requirements (*see page 133*).



The STB ACO 0220 output module uses two six-terminal field wiring connectors. You can use either:

- two STB XTS 1100 screw type field wiring connectors
- two STB XTS 2100 spring clamp field wiring connectors

Each field wiring connector has six connection terminals, with a 3.8 mm (0.15 in) pitch between each pin. Individual connector terminals accept one field wire. Use shielded twisted pair wire sizes in the range 0.20...0.82 mm<sup>2</sup> (24...18 AWG).

## Quantum I/O Wiring Example

### HART Multiplexer and Remote Quantum I/O Drop

The following graphic depicts an overview of a HART multiplexer that supports the maximum number of 32 analog channels—28 input channels and 4 output channels. The input and output modules are located in a Quantum PLC drop.


This HART multiplexer is assembled using the following STB equipment:

- Modules:
  - STB NIP 2311 network interface module (1)
  - STB AHI 8321 HART interface modules (8)
  - STB PDT 3100 power distribution modules (3)
  - STB CPS 2111 auxiliary power supplies (2)
- Bases:
  - STB XBA 2100 bases (2)—for auxiliary power supplies
  - STB XBA 2200 bases (3)—for power distribution modules
  - STB XBA 3000 type 3 bases (8)—for HART interface modules

The Quantum PLC includes the following modules:

- 140 CPS 124 20 power supply (1)
- 140 CPU 651 50 central processing unit (1)
- 140 ACI 030 00 8-channel input modules (4)
- 140 ACO 020 00 4-channel output module (1)

A HART multiplexer with Quantum I/O:



- 1 PC running asset management software
- 2 Ethernet switch
- 3 Quantum PLC with analog I/O
- 4 4-20 mA current loop wiring, connecting analog I/O and HART multiplexer
- 5 HART multiplexer
- 6 4-20 mA current loop wiring, connecting HART multiplexer to HART instruments

When connecting the island modules to current loop wiring:

- use wire sizes in the range 0.20...0.82 mm<sup>2</sup> (24...18 AWG)
- strip at least 9 mm (0.35 in) from the wire's jacket for the module connection
- use shielded twisted-pair cable
- tie the twisted-pair cable shield to an external clamp that is tied to functional ground (FE)


**NOTE:** Refer to the following examples, for detailed wiring diagrams of inputs and outputs.

### **Wiring the 140 ACI 030 00 Quantum Input Module to the HART Interface Module**

In the following diagram:

- Current loop wiring is made through the STB AHI 8321 HART interface module thereby employing its 260  $\Omega$  internal HART filter.
- Schneider Electric recommends that each current loop utilize a loop power supply (*see page 61*).
- Each input module provides an internal 250  $\Omega$  resistor to the current loop.

**NOTE:** For other I/O modules and configurations, you need to calculate your specific resistance requirements (*see page 133*).




### Wiring the 140 ACO 020 00 Quantum Output Module to the HART Interface Module

The following diagram shows you how to wire the 140 ACO 020 00 output module to the STB AHI 8321 HART interface module for use as either a current source or a current sink.

- Current loop wiring is made through the STB AHI 8321 HART interface module thereby employing its 260 Ω internal HART filter.
- Schneider Electric recommends that each current loop utilize a loop power supply (see page 61).

**NOTE:** For other I/O modules and configurations, you need to calculate your specific resistance requirements (see page 133).

**NOTE:** It may be necessary to adjust the rise and fall times (see page 134) of analog output modules to facilitate HART communication.



- 1 HART instrument  
2 External 24 Vdc power supply

## Premium I/O Wiring Example

### HART Multiplexer and Remote Premium I/O Drop

The following graphic depicts an overview of a HART multiplexer that supports the maximum number of 32 analog channels—28 input channels and 4 output channels. The input and output modules are located in a Premium PLC drop.


This HART multiplexer is assembled using the following STB equipment:

- Modules:
  - STB NIP 2311 network interface module (1)
  - STB AHI 8321 HART interface modules (8)
  - STB PDT 3100 power distribution modules (3)
  - STB CPS 2111 auxiliary power supplies (2)
- Bases:
  - STB XBA 2100 bases (2)—for auxiliary power supplies
  - STB XBB 2200 bases (3)—for power distribution modules
  - STB XBA 3000 type 3 bases (8)—for HART interface modules

The Premium PLC includes the following modules:

- TSX PSY 2600M power supply (1)
- TSX P57 5634M central processing unit (1)
- TSX AEY 810 8-channel input modules (4)
- TSX ASY 410 ASY 4-channel output module (1)

## A HART multiplexer with Premium I/O:



- 1 PC running asset management software
- 2 Ethernet switch
- 3 Premium PLC with analog I/O
- 4 4-20 mA current loop wiring, connecting analog I/O and HART multiplexer
- 5 HART multiplexer
- 6 4-20 mA current loop wiring, connecting HART multiplexer to HART instruments

When connecting the island modules to current loop wiring:

- use wire sizes in the range 0.20...0.82 mm<sup>2</sup> (24...18 AWG)
- strip at least 9 mm (0.35 in) from the wire's jacket for the module connection
- use shielded twisted-pair cable
- tie the cable shield to an external clamp tied to functional ground (FE)


**NOTE:** Refer to the following examples, for detailed wiring diagrams of inputs and outputs.

### **Wiring the TSX AEY 810 Premium Input Module to the HART Interface Module**

In the following example:

- Because the TSX AEY 810 output module has no pin connectors, this example employs the ABE7CPA31E Telefast connector module.
- This design uses the 260  $\Omega$  internal HART filter of the STB AHI 8321 HART interface module.
- Wiring connections are made from the HART compliant instruments, through the STB AHI 8321 HART interface module, to pins on the ABE7CPA31E Telefast connector module.
- 24V power is supplied through to each channel through the ABE7CPA31E Telefast connector module.
- The TSX AEY 810 input module provides a 250  $\Omega$  resistor to the current loop.

**NOTE:** For other I/O modules and configurations, you need to calculate your specific resistance requirements (*see page 133*).




### Wiring the TSX ASY 410 Premium Output Module to the HART Interface Module

The following diagram shows you how to wire the TSX ASY 410 output module to the STB AHI 8321 HART interface module.

- Current loop wiring is made through the 260  $\Omega$  internal HART filter of the STB AHI 8321 HART interface module.
- Wiring connections are made from the HART compliant instruments, through the STB AHI 8321 HART interface module, to pins on the TSX ASY 410 output module.
- Schneider Electric recommends that each current loop utilize a loop power supply.
- Each current loop employs a 220  $\Omega$  resistor placed between the output module and HART interface module.

**NOTE:** It may be necessary to adjust the rise and fall times (see page 134) of analog output modules to facilitate HART communication.

**NOTE:** For other I/O modules and configurations, you need to calculate your specific resistance requirements (see page 133).



- 1 HART instrument
- 2 External 24 Vdc power supply

## M340 I/O Wiring Example

### HART Multiplexer and Remote M340 I/O Drop

The following graphic depicts an overview of a HART multiplexer that supports the maximum number of 32 analog channels—28 input channels and 4 output channels. The input and output modules are located in an M340 PLC drop.


This HART multiplexer is assembled using the following STB equipment:

- Modules:
  - STB NIP 2311 network interface module (1)
  - STB AHI 8321 HART interface modules (8)
  - STB PDT 3100 power distribution modules (3)
  - STB CPS 2111 auxiliary power supplies (2)
- Bases:
  - STB XBA 2100 bases (2)—for auxiliary power supplies
  - STB XBA 2200 bases (3)—for power distribution modules
  - STB XBA 3000 type 3 bases (8)—for HART interface modules

The M340 PLC includes the following modules:

- BMX CPS 3500 power supply (1)
- BMX P34 20302 central processing unit (1)
- BMX AMI 0310 4-channel input modules (7)
- BMX AMO 0210 ASY 4-channel output module (2)

A HART multiplexer with M340 I/O:



- 1 PC running asset management software
- 2 Ethernet switch
- 3 M340 PLC with analog I/O
- 4 4-20 mA current loop wiring, connecting analog I/O and HART multiplexer
- 5 HART multiplexer
- 6 4-20 mA current loop wiring, connecting HART multiplexer to HART instruments

When connecting the island modules to current loop wiring:

- use wire sizes in the range 0.20...0.82 mm<sup>2</sup> (24...18 AWG)
- strip at least 9 mm (0.35 in) from the wire's jacket for the module connection
- use shielded twisted-pair cable
- tie the twisted-pair cable shield to an external clamp that is tied to functional ground (FE)


**NOTE:** Refer to the following examples, for detailed wiring diagrams of inputs and outputs.

### Wiring the BMX AMI 0410 M340 Input Module to the HART Interface Module

In the following diagram:

- Current loop wiring is made through the internal 260 Ω HART filter of the STB AHI 8321 HART interface module.
- Schneider Electric recommends that each current loop utilize a loop power supply (see page 61).

**NOTE:** For other I/O modules and configurations, you need to calculate your specific resistance requirements (see page 133).



- 1 HART instrument
- 2 External 24 Vdc power supply


### Wiring the BMX AMO 0210 M340 Output Module to the HART Interface Module

The following diagram shows you how to wire the BMX AMO 0210 output module to the STB AHl 8321 HART interface module.

- Current loop wiring is made through the internal 260 Ω HART filter of the STB AHl 8321 HART interface module.
- The BMX AMO 0210 output module supplies 24 Vdc internal power to each current loop, so an external power supply is not required.
- Each output module provides an internal 250 Ω resistor to the current loop.

**NOTE:** It may be necessary to adjust the rise and fall times (see page 134) of analog output modules to facilitate HART communication.

**NOTE:** For other I/O modules and configurations, you need to calculate your specific resistance requirements (see page 133).



1 HART instrument

---

# HART Device Management Software

# 9

---

## Introduction to HART

A HART multiplexer can centralize the management of HART field instruments. From a PC with device management software, you can manage HART instruments that are connected to the multiplexer:

- Configure field instruments.
- Diagnose field instruments.
- Save field instrument configurations on your PC. (You can later download a configuration to a replacement field instrument.)
- Track changes made to field instruments.

## What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
9.1	Configuring HART Devices	156
9.2	AMS Device Management Software Example	171

## 9.1 Configuring HART Devices

---

### What Is in This Section?

This section contains the following topics:

Topic	Page
Using the DTM	157
User Interface Configuration for the HART STB Multiplexer DTM	161

## Using the DTM

### Introduction

Follow these instructions to add the DTM for the HART STB Multiplexer to your application. The instructions apply to these software platforms:

- **Unity Pro:** Unity Pro is high-performance PC-based multitask software for Modicon M340, Premium, and Quantum platforms from Schneider Electric.
- **Endress+Hauser FieldCare:** FieldCare is PC-based Asset Management Software.
- **PACTware:** PACTware (Process Automation Configuration Tool software) runs on a PC and communicates with field instruments through DTMs. PACTware is a free download that is device- and fieldbus-independent.

**NOTE:** The Schneider Electric HART DTMs are supported by STB NIP 2311 firmware version 4.01 or greater.

### Download the DTMs

Download the Schneider Electric HART DTMs:

Step	Action
1	Go to the global Schneider Electric web site ( <a href="http://www.schneider-electric.com">www.schneider-electric.com</a> ).
2	Locate the DTM files ( <b>Support</b> → <b>Documents &amp; Downloads</b> → <b>Software/Firmware</b> → <b>DTM files</b> ).
3	Download the Schneider Electric HART DTMs to your PC.
4	Unzip the downloaded files.
5	Double-click the executable file (.exe).
6	Follow the on-screen instructions to download the DTMs.

**NOTE:** A single installation file contains both the STB HART Multiplexer DTM and the Schneider Electric Generic HART Device DTM.

### Initial Installation of DTMs and Device Catalog Update

If your software platform (**Unity Pro**, **Endress+Hauser FieldCare**, or **PACTware**) automatically detects the new DTM, follow the on-screen instructions to install the DTM and update your device catalog. Otherwise, use these steps the first time you install and update the DTMs:

Unity Pro:	
1	Open Unity Pro.
2	In the <b>DTM Browser</b> , right-click <b>Host PC</b> → <b>DTM Hardware Catalog</b> .
3	In the <b>Hardware Catalog</b> , press <b>Update</b> . (Unity Pro scans your PC and automatically imports all newly installed DTMs.)

<b>Endress+Hauser FieldCare:</b>	
1	Open Endress+Hauser FieldCare.
2	From the menu, select <b>DTM Catalog</b> → <b>Update</b> .
3	Press the <b>Update</b> button. ( <b>NOTE:</b> Wait for the <b>Update progress</b> window to run. The new DTMs appear under <b>Device Types not part of DTM Catalog</b> .)
4	Select (left-click) the DTMs in <b>Device Types not part of DTM Catalog</b> .
5	Press the <b>Move &gt;&gt;</b> button to move the selected DTMs into <b>Device Types in DTM Catalog</b> .
6	Press <b>OK</b> to close and update the <b>DTM Catalog</b> window.
<b>PACTware:</b>	
1	Open PACTware (or open an existing PACTware project).
2	From the menu, select <b>View</b> → <b>Device Catalog</b> .
3	Press <b>Update device catalog</b> .
4	When the prompt for a new PACTware device catalog appears, say <b>Yes</b> . (PACTware scans and automatically imports all newly installed DTMs.)

### Add the DTM to Your Program

Follow these steps to add the DTM (with your preferred software platform):


<b>Unity Pro:</b>	
1	Open Unity Pro.
2	In the <b>DTM Browser</b> , right-click <b>Host PC</b> → <b>Add</b> .
3	Select (left-click) <b>HART STB Multiplexer</b> in the <b>Devices</b> column.
4	Click <b>Add DTM</b> .
5	In the <b>Properties of Devices</b> dialog, press <b>OK</b> .
<b>Endress+Hauser FieldCare:</b>	
1	Open Endress+Hauser FieldCare.
2	Double-click <b>Create Project</b> (or open an existing project).
3	Right-click <b>Host PC</b> → <b>Add Device</b> .
4	Select (left-click) <b>HART STB Multiplexer</b> in the <b>Devices</b> column.
5	Press <b>OK</b> .
<b>PACTware:</b>	
1	Open PACTware (or open an existing PACTware project).
2	Right-click <b>Host PC</b> → <b>Add Device</b> .
3	Select (left-click) <b>HART STB Multiplexer</b> in the <b>Devices</b> column.
4	Press <b>OK</b> .

**Access DTM Parameters**

Use these commands to access the DTM parameters (with your preferred software platform):

Software	Right-Click ...
Unity Pro	HART_STB_Multiplexer → Device → Configuration
Endress+Hauser FieldCare	HART_STB_Multiplexer → Configuration
PACTware	HART_STB_Multiplexer → Parameter → Configuration

For each software platform, the same DTM configuration parameters screen appears:



## Configure DTM Parameters and Connect

Follow these steps to configure the parameters and connect the DTM:

Step	Action
1	Configure these parameters: <ul style="list-style-type: none"> <li>● <b>IP Address:</b> Enter the IP address of the STB NIP 2311 NIM on the STB island.</li> <li>● <b>Node Id:</b> The Node Id (0...31) corresponds to the HART multiplexer.</li> <li>● <b>Comm retry count:</b> This value represents the number of times that the HART interface module resends a command after it does not communicate with a HART instrument.</li> <li>● <b>Busy retry count:</b> This value represents the number of times that the HART interface module resends a command after receiving a busy reply from a HART instrument.</li> </ul>
2	Press <b>Apply</b> to apply all changes.
3	Right-click <b>HART_STB_Multiplexer</b> → <b>Connect</b> to connect the software platform to the DTM.

## Find All HART Devices

Use your software to find HART field devices:

Software	Right-Click ...
Unity Pro	<b>HART_STB_Multiplexer</b> → <b>Fieldbus Discovery</b>
Endress+Hauser FieldCare	<b>HART_STB_Multiplexer</b> → <b>Create Network</b>
PACTware	<b>HART_STB_Multiplexer</b> → <b>Topology Scan</b>


### NOTE:

- To search for HART field devices to add to your project, refer to the Unity Pro, Endress+Hauser FieldCare, and PACTware software documentation.
- Schneider Electric provides a generic DTM for HART field devices. Use the generic DTM when a HART field device does not have a device-specific DTM from the manufacturer. (The generic DTM contains online help.)
- Initially, the Schneider Electric generic HART DTM is “Unregistered Trial (0) day” (with limited functionality). A few moments after being instantiated, it changes to “Registered Professional.” The DTM is then fully functional and ready to use.
- Schneider Electric recommends that only 4 device DTM windows are active at any given time.
- Refer to [www.schneider-electric.com](http://www.schneider-electric.com) for known resolutions concerning device-specific DTMs.

## User Interface Configuration for the HART STB Multiplexer DTM

### Introduction

To access the communication parameters for the user interface (UI) of the HART STB Multiplexer, right-click the DTM icon in the network view of your FDT (Field Device Tool) frame application and click *Configuration*:



This table describes the components of the window:

<b>Parameter</b>	IP Address	Enter the IP address of the STB NIP 2311 NIM on the STB island.
	Node Id	Enter the node ID (0 ... 31) that corresponds to the HART multiplexer. (The default value is 0.)
	Comm retry count	Enter a value that represents the number of times that the HART interface module resends a command after it does not communicate with a HART instrument. (The default value is 2.)
	Busy retry count	Enter a value that represents the number of times that the HART interface module resends a command after receiving a busy reply from a HART instrument. (The default value is 2.)
<b>Button</b>	OK	Save all parameters and close the <i>Configuration</i> window.
	Cancel	Cancel the modification of all parameters and close the configuration window. (The original values are applied at the next connection.)
	Apply	Save the parameters. (The configuration window remains open. New parameter values are applied at the next connection.)

## Offline (DTM) Parameters

The offline parameter UI of the HART STB Multiplexer DTM contains the parameters that are used in the DTM dataset. To view the offline parameters, right-click the DTM icon in the network view of your FDT frame application and click *Offline Parameter*:

**<-> HART STB Multiplexer - Offline Parameter**

HART STB Multiplexer  
Communication DTM

**Schneider Electric**

**Multiplexer Parameters**

Tag: ID\_1

Descriptor: ISLAND\_1

Date: 22.10.2013

Long Tag: HART STB Multiplexer

Message: HART STB MULTIPLEXER ISLAND 1

Gender: Primary

OK Cancel Apply Help

Disconnected Data set Planning Engineer

This table describes the read/write parameters for the `Offline Parameter` window:

<b>Parameter</b>	Tag	This field contains the HART tag name for the HART STB Multiplexer. It is used as the FDT tag name in the DTM. <b>NOTE:</b> The HART tag has an 8-character limit. However, some FDT frames allow tag names that exceed 8 characters. If there are more than 8 characters in the FDT frame, the HART STB Multiplexer DTM truncates all characters after the eighth character.
	Descriptor	This field contains the HART Descriptor (16-character maximum) for the HART STB Multiplexer.
	Date	This field contains the HART date field for the HART STB Multiplexer.
	Long Tag	This field contains the Long Tag name (16-character maximum) for the HART STB Multiplexer.
	Message	This field contains the HART message (32-character maximum) for the HART STB Multiplexer.
	Gender	The HART protocol provides for up to 2 masters (primary and secondary). This allows secondary masters such as handheld communicators to be used without interfering with communications to or from the primary master.
<b>Button</b>	OK	Save all parameters and close the configuration window.
	Cancel	Cancel the modification of all parameters and close the configuration window. (The original values are applied at the next connection.)
	Apply	Save the parameters. (The configuration window remains open. New parameter values are applied at the next connection.)

### Online (Device) Parameters

The online parameter UI of the HART STB Multiplexer DTM contains the parameters that are set in the online dataset. To view the device parameters, right-click the DTM icon in the network view of your FDT frame application and click `Online Parameter`:

<-> HART STB Multiplexer - Online Parameter

HART STB Multiplexer  
Communication DTM

Schneider Electric

Multiplexer Parameters

Tag ID\_1

Descriptor ISLAND\_1

Date 22.10.2013

Long Tag HART STB Multiplexer

Message SCHNEIDERELECTRIC MUX HRM V1,0

Gender Primary

OK Cancel Apply Refresh Help

Connected Data set Planning Engineer

This table describes the parameters on the `Online Parameter` window:

<b>Parameter</b>	Tag	This field contains the HART tag name for the HART STB Multiplexer. It is used as the FDT tag name in the DTM. <b>NOTE:</b> The HART tag has an 8-character limit. However, some FDT frames allow tag names that exceed 8 characters. If there are more than 8 characters in the FDT frame, the HART STB Multiplexer DTM truncates all characters after the eighth character.
	Descriptor	This field contains the HART Descriptor (16-character maximum) for the HART STB Multiplexer.
	Date	This field contains the HART date field for the HART STB Multiplexer.
	Long Tag	This field contains the Long Tag name (16-character maximum) for the HART STB Multiplexer.
	Message	This field contains the HART message (32-character maximum) for the HART STB Multiplexer.
	Gender	The HART protocol provides for up to 2 masters (primary and secondary). This allows secondary masters such as handheld communicators to be used without interfering with communications to or from the primary master.
<b>Button</b>	OK	Save all parameters and close the configuration window.
	Cancel	Cancel the modification of all parameters and close the configuration window. (The original values are applied at the next connection.)
	Apply	Save the parameters. (The configuration window remains open. New parameter values are applied at the next connection.)
	Refresh	Upload all parameters from the device and display them in the window.
<b>Equality Indication</b>	These symbols apply to values in the window:  	
	green	<b>equal:</b> The online (device) value is equal to the offline (DTM) value.
	yellow	<b>not equal:</b> The online (device) value is not equal to the offline (DTM) value.

## Diagnostics Configuration

The diagnostics UI of the HART STB Multiplexer DTM contains status information about the HART STB Multiplexer device. The diagnostics configuration screen contains these tabs:

- Multiplexer Status
- Instrument Status
- HART Communication Status

To access the diagnosis UI, right-click the DTM icon in the network view of your FDT frame application and click `Diagnosis`.

The Multiplexer Status shows the status of the HART STB Multiplexer:

**HART STB Multiplexer - Diagnosis**

HART STB Multiplexer  
Communication DTM

Schneider Electric

Multiplexer Status | Instrument Status | Host Communication Status

**HARTPORT Parameters**

Max Delayed Responses/Primary	1
Max Delayed Responses/Secondary	1
Number Delayed Responses/Primary	0
Number Delayed Responses/Secondary	0
Signaling	0
Max Instruments Connected	32
Max Instruments Stored	32
Instruments on Instrument List	8
Instruments on Scan List	8
Gender	Primary
Search Algorithm	Single analog
Scan Command	Command #3
Scan Mode	Disable
Busy retry count	2
Comm retry count	5

**Status**

- Device malfunction
- Configuration Changed
- Cold Start
- More Status Available
- Loop Current Fixed
- Loop Current Saturated
- Non-Primary Variable Out of Limits
- Primary Variable Out of Limits

Close Help

Connected Planning Engineer

This table describes the read-only parameters on the `Multiplexer Status` tab:

<b>HARTPORT Parameters</b>	Max Delayed Responses/Primary	These fields display the number of supported messages that can simultaneously wait for data from HART instruments.
	Max Delayed Responses/Secondary	
	Number Delayed Responses/Primary	These fields display the number of messages that are waiting data from the HART instruments.
	Number Delayed Responses/Secondary	
	Signaling	This field displays the algorithm that is used for sending signals between a master and a device.
	Max Instruments Connected	This field displays the maximum number of instruments that can be connected to the HART STB Multiplexer.
	Max Instruments Stored	This field displays the maximum number of instruments that can be stored in the HART STB Multiplexer.
	Instruments on Instrument List	This field displays the number of stored instruments in the instrument list.
	Instruments on Scan List	This field displays the number of stored instruments in the scan list.
	Gender	The HART protocol provides for up to 2 masters ( <code>Primary</code> or <code>Secondary</code> ). This allows secondary masters such as handheld communicators to be used without interfering with communications to or from the primary master.
	Search Algorithm	This field displays the algorithm that the HART STB Multiplexer uses to search for an instrument in the loop.
	Scan Command	This field displays the command the HART STB Multiplexer uses to cache data from instruments on the scan list.
	Scan Mode	This field displays the scanner status ( <code>Enable</code> or <code>Disable</code> ).
	Busy retry count	This is the number of busy retries.
	Comm retry count	This is the number of communication retries.

<b>Status</b>	Device Malfunction	This indicator is not used by the HART STB Multiplexer.
	Configuration Changed	<b>ON:</b> The configuration of the HART STB Multiplexer has been changed.
	Cold Start	<b>ON:</b> The HART STB Multiplexer has been reset. <b>NOTE:</b> It is only set for the first command after the reset.
	More Status Available	<b>ON:</b> You can get additional status information through command 49. <b>NOTE:</b> The bit is cleared when command 48 is read.
	Loop Current Fixed	This indicator is not used by the HART STB Multiplexer.
	Loop Current Saturated	This indicator is not used by the HART STB Multiplexer.
	Non-Primary Variable Out of Limits	This indicator is not used by the HART STB Multiplexer.
	Primary Variable Out of Limits	This indicator is not used by the HART STB Multiplexer.
<b>Button</b>	Close	Close the window.

The Instrument Status tab displays the HART instruments that are connected to the HART STB Multiplexer:

**HART STB Multiplexer - Diagnosis**

HART STB Multiplexer 1.0.3.0  
Communication DTM

Schneider Electric

Multiplexer Status | **Instrument Status** | Host Communication Status

Channel	Manufacturer	Device Type Id	Communication...	Device Status	Tries	Fails
1	ABB	11	OK	Configuration ch...	27355	0
2	ABB	11	OK	Configuration ch...	27877	0
3	ABB	11	OK	Configuration ch...	27300	0
4	ABB	11	OK	Configuration ch...	27361	0
5	PR Electronics	223	OK	Configuration ch...	29218	292
6	ABB	11	OK	Configuration ch...	27379	0
7	ABB	11	OK	Configuration ch...	27397	0
8	ABB	11	OK	Configuration ch...	27400	0


Reset Close Help

Connected Planning Engineer

This table describes the read-only parameters on the `Instrument Status` tab:

<b>Parameter</b>	Channel	This field contains the number of instruments stored in the instrument list. <b>NOTE:</b> This number may not match the actual channel that an instrument is connected to if the instrument was move from one channel to another.
	Manufacturer	This field contains the name of the instrument manufacturer.
	Device Type Id	This field contains the unique device type that is defined by the manufacturer.
	Communication Status	This field contains the number of communication errors that were detected since the last reset.
	Device Status	This field displays the set device status information that is stored in the HART STB Multiplexer.
	Tries	This field contains the total number of messages sent by the HART STB Multiplexer to the instruments.
	Fails	This field contains the total number of messages that included detected communication errors.
<b>Button</b>	Reset	Set all values in the <b>Tries</b> and <b>Fails</b> columns to 0.
	Close	Close the window.

The `Host Communication Status` tab displays the status of the host:



This table describes the read only parameters on the Host Communication Status window:

<b>Parameter</b>	<b>Description</b>
Number of commands	This field contains the total number of messages received by the multiplexer from a client.
Number of replies	This field contains the total number of replies sent by the multiplexer back to the client.
Number of burst replies	This value is always 0. (The HART STB Multiplexer does not support burst replies.)

---

## 9.2 AMS Device Management Software Example

---

### Overview

This section explains the use of Emerson Process Management's *AMS Device Manager, Version 10.5* software (including its *Network Configuration* tool).

It also includes an introduction to Eltima Software's *Serial to Ethernet Connector, Version 5.0*, which allows device management software programs (Unity Pro, FieldCare, PACTware) to communicate over Ethernet.

**NOTE:** The following example describes third-party software. Refer to the manufacturer's product documentation for detailed operating instructions.

### What Is in This Section?

This section contains the following topics:

Topic	Page
Eltima Software <i>Serial to Ethernet Connector</i> Setup	172
Add the Schneider Electric Multiplexer to the AMS Device List	176
Creating a HART Multiplexer Network	180
Managing HART Network Devices	185

## **Eltima Software *Serial to Ethernet Connector* Setup**

### **Converting an Ethernet Port to a Virtual Serial Port**

The Schneider Electric HART multiplexer communicates via Ethernet connections. Device management software typically communicates via serial connections. This topic introduces the *Serial to Ethernet Connector* software application from Eltima Software. You can use this software to enable communication between device management software and the Schneider Electric HART multiplexer.


**NOTE:** The following example describes third-party software. Refer to the manufacturer's product documentation for detailed operating instructions.


**Eltima Software Setup**

To configure the Eltima Software *Serial to Ethernet Connector* program, follow these steps:

Step	Action												
1	Install the Eltima Software <i>Serial to Ethernet Connector</i> program on your PC by following the manufacturer's installation instructions.												
2	Start up the <i>Serial to Ethernet Connector</i> program.												
3	Click on the <b>Create connection</b> tab to display the following page: <div data-bbox="203 459 1186 1112" style="border: 1px solid black; padding: 5px; margin: 10px 0;"> </div>												
4	In the <b>Create connection</b> page (above), enter the following connection settings: <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Setting</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Connection type</td> <td>Select <b>Connect serial port to remote host (Client)</b>.</td> </tr> <tr> <td>Port type</td> <td>Select an unused serial port—in this case, <b>COM6</b>.</td> </tr> <tr> <td>Virtual serial port</td> <td>Select <b>Create as virtual serial port</b>. <b>NOTE:</b> This setting may be pre-selected and read-only.</td> </tr> <tr> <td>Remote IP/ Host name</td> <td>Type in the IP address of the HART multiplexer network interface module—in this case, <b>192.168.1.6</b>.</td> </tr> <tr> <td>Socket number</td> <td>Type in the socket number, <b>5001</b>. <b>NOTE:</b> The HART server uses socket number 5001.</td> </tr> </tbody> </table>	Setting	Description	Connection type	Select <b>Connect serial port to remote host (Client)</b> .	Port type	Select an unused serial port—in this case, <b>COM6</b> .	Virtual serial port	Select <b>Create as virtual serial port</b> . <b>NOTE:</b> This setting may be pre-selected and read-only.	Remote IP/ Host name	Type in the IP address of the HART multiplexer network interface module—in this case, <b>192.168.1.6</b> .	Socket number	Type in the socket number, <b>5001</b> . <b>NOTE:</b> The HART server uses socket number 5001.
Setting	Description												
Connection type	Select <b>Connect serial port to remote host (Client)</b> .												
Port type	Select an unused serial port—in this case, <b>COM6</b> .												
Virtual serial port	Select <b>Create as virtual serial port</b> . <b>NOTE:</b> This setting may be pre-selected and read-only.												
Remote IP/ Host name	Type in the IP address of the HART multiplexer network interface module—in this case, <b>192.168.1.6</b> .												
Socket number	Type in the socket number, <b>5001</b> . <b>NOTE:</b> The HART server uses socket number 5001.												

Step	Action
5	Click <b>Add</b> to add the new connection to the connection list.
6	Repeat steps 4 and 5 for each additional connection you wish to add to the list. <b>NOTE:</b> Each HART multiplexer on your network requires a separate COM port. In this example, with only one multiplexer, no additional connections are required.
7	When all connections have been added, click <b>Create connection</b> . The new connections are created, and the page looks like this:



Step	Action				
8	<p data-bbox="198 203 1195 277">After the serial port is also configured in the HART OPC server, you can use this screen to observe the communication between the PC and the multiplexer. This screen will display the connected state, and the number of bytes sent and received over the connection:</p>  <p>The screenshot shows the 'Serial to Ethernet Connector 5.0 by Eltima Software' window. On the left, a tree view shows 'COM6 [Client]' expanded to show a connection to '192.168.1.6:5001'. The connection status is 'Connected' and shows 'Sent: 127 Bytes' and 'Received: 497 Bytes'. The main panel is titled 'Create connection' and shows the 'COM6 [Client]' selected. Under 'Select connection type you want to create', the 'Connect serial port to remote host (Client)' option is selected. Under 'Select port type you want to create', 'COM6' is selected in the 'Select Serial Port' dropdown, and 'Create as virtual serial port' is checked. The 'Remote IP/Host name' is '192.168.1.6' and the port is '5001'. A table below shows the IP address and port for the connection.</p> <table border="1" data-bbox="563 899 854 992"><thead><tr><th>IP address</th><th>Port</th></tr></thead><tbody><tr><td>192.168.1.6</td><td>5001</td></tr></tbody></table>	IP address	Port	192.168.1.6	5001
IP address	Port				
192.168.1.6	5001				

## Add the Schneider Electric Multiplexer to the AMS Device List


### Introduction

This topic shows you how to add a Schneider Electric HART multiplexer device definition file (DD) to the AMS device list. After the Schneider Electric HART multiplexer DD is added, the AMS software will recognize the Schneider Electric HART multiplexer when it rebuilds the hierarchy of your HART network.


The Schneider Electric HART multiplexer DD file ships with your STB AHI 8321 HART multiplexer module installation CD, and is named: 0101.fm6.

### Adding the Schneider Electric DD File

Use the *Add Device Type* AMS software tool to perform this task. The *Add Device Type* tool is installed on your PC as part of the *AMS Device Manager Suite*. Follow these steps:

Step	Action
1	Copy the Schneider Electric HART Multiplexer DD file (0101.fm6) from your STB AHI 8321 installation disk to a location on your PC's hard drive.
2	Startup the <i>Add Device Type</i> tool by selecting <b>Start</b> → <b>AMS Device Manager</b> → <b>Add Device Type</b> . The following message displays: 

Step	Action
3	<p>Click <b>OK</b>. The following navigation dialog opens:</p>  <p>The screenshot shows a dialog box titled "Add Device Type". It contains two lines of text: "To install files for this directory, click OK." and "To install files for a different directory, click Browse and select another directory." Below the text is a text field labeled "Source Directory" containing "C:\". To the right of the text field is a "Browse..." button. At the bottom of the dialog are three buttons: "OK", "Cancel", and "Help".</p>
4	<p>Click <b>Browse...</b> to open the following navigation dialog:</p>  <p>The screenshot shows a dialog box titled "Select Source Directory". It contains the text "Please choose the install source". Below this is a "Path:" label followed by a text field containing "C:\AMS\006058\e1b1\". Below the path field is a "Directories:" label followed by a list box containing "[..]". Below the list box is a "Drives:" label followed by a dropdown menu showing "C:\". At the bottom of the dialog are two buttons: "OK" and "Cancel".</p>
5	<p>Click in the <b>Directories</b> area of this dialog to navigate to and select the folder that contains the Schneider Electric HART multiplexer DD file. In this case, that path is C:\AMS\006058\e1b1.</p>

Step	Action
6	<p>Click <b>OK</b> to close the <b>Select Source Directory</b> dialog. The selected directory appears as the <b>Source Directory</b>:</p> 
7	<p>Click <b>OK</b> to close the <b>Add Device Type</b> dialog.</p>
8	<p>The following dialog may open:</p>  <p>If this dialog opens, enter the following information:</p> <ul style="list-style-type: none"> <li>● : Schneider Electric</li> <li>● <b>Device's name:</b> HRM V1.0</li> </ul> <p>Click <b>OK</b> to close the dialog.</p>

Step	Action
9	<p>The following message appears, indicating the Schneider Electric HART multiplexer DD file is saved to the AMS device list:</p>  <p>Click <b>OK</b> to close the message.</p>

## Creating a HART Multiplexer Network


### Introduction


The first task to perform when working with Emerson Process Management's *AMS Device Manager, Version 10.5* software is to create a new HART multiplexer network. To do this, use the *Network Configuration* tool that installs on your PC as part of the *AMS Device Manager Suite*.


### Creating a New HART Network

Follow these steps to create a new HART multiplexer network:

Step	Action
1	Install the <i>AMS Device Manager, Version 10.5</i> software, following the manufacturer's installation instructions.
2	<p>Startup the <i>Network Configuration</i> tool, by selecting <b>Start</b> → <b>AMS Device Manager</b> → <b>Network Configuration</b>. The <b>Network Configuration</b> dialog opens:</p> 

Step	Action
3	<p>Click <b>Add</b>. The <b>Select Network Component Type</b> dialog opens:</p> 
4	<p>Select <b>Multiplexer Network</b>, then click <b>Install...</b>. The following dialog opens for starting the new network wizard:</p> 

Step	Action
5	<p>Click <b>Next</b>. The following dialog opens for naming the new network:</p> 

Step	Action
6	<p>For the purpose of this example, accept the default network name <b>Multiplexer Network 1</b>, then click <b>Next&gt;</b>. The following dialog opens:</p>  <p>The screenshot shows a 'Connection' dialog box with the following settings:</p> <ul style="list-style-type: none"><li><b>Mux Network Parameters</b><ul style="list-style-type: none"><li>COM Port: COM 6</li><li>Baud Rate: 9600</li><li>Network timeout: 1000 ms.</li><li>Communication retries: 2</li><li>HART Busy retries: 5</li></ul></li><li><b>Multiplexer address range</b><ul style="list-style-type: none"><li>RS485 addresses from: 0 to: 1</li></ul></li><li><b>Multiplexer HART Master Mode</b><ul style="list-style-type: none"><li><input checked="" type="radio"/> Primary master (Handheld Communicator is Secondary master)</li><li><input type="radio"/> Secondary master (control system is Primary master)</li></ul></li></ul> <p>Buttons at the bottom: &lt;Back, Next&gt;, Cancel, Help.</p>

Step	Action
7	<p>In the <b>Connection</b> dialog, define the COM port connection the new multiplexer network will use. Enter the following settings:</p> <ul style="list-style-type: none"><li>● <b>COM Port:</b> Select COM 6. This is the same COM port that was previously configured using the Eltima software (<i>see page 173</i>).</li><li>● <b>Baud Rate:</b> Select 9600.</li><li>● <b>Network Timeout:</b> Accept the default value of 1000.</li><li>● <b>Communication Retries:</b> Select 2.</li><li>● <b>HART Busy retries:</b> Select 5.</li><li>● <b>RS485 addresses:</b> Select from 0 to 1.</li><li>● <b>Multiplexer HART Master Mode:</b> Select Primary master.</li></ul> <p>Click <b>Next&gt;</b>. The <b>Connection</b> dialog closes, and the <b>Network Configuration</b> dialog displays the new network:</p> 
8	Click <b>Close</b> to close the <i>Network Configuration</i> tool.



## Managing HART Network Devices



### Introduction

The next task is to open the *AMS Device Manager* tool, confirm that it includes the Schneider Electric HART multiplexer in its device list, then automatically discover the HART instruments connected to the Schneider Electric HART multiplexer. The *AMS Device Manager* tool installed on your PC when as part of the *AMS Device Manager Suite*.

## Discovering the New Network

To view the HART instruments connected to the new network, follow these steps:


Step	Action																																														
1	<p>Startup the <i>AMS Device Manager</i> by selecting <b>Start</b> → <b>AMS Device Manager</b> → <b>AMS Device Manager</b>. The following Login dialog opens:</p> 																																														
2	<p>Type in your Username/Password combination.  <b>NOTE:</b> You created the Username/Password combination when you installed the <i>AMS Device Manager</i> on your PC.</p>																																														
3	<p>Click <b>OK</b>. The <i>AMS Device Manager</i> opens:</p>  <table border="1" data-bbox="655 1019 1218 1344"> <thead> <tr> <th>Tag</th> <th>Manufacturer</th> </tr> </thead> <tbody> <tr><td>Rosemount Tank Radar</td><td>Rosemount Tank Radar</td></tr> <tr><td>Rotork</td><td>Rotork</td></tr> <tr><td>Samson</td><td>Samson</td></tr> <tr><td>SAMSON AG</td><td>SAMSON AG</td></tr> <tr><td>Schneider Electric</td><td>Schneider Electric</td></tr> <tr><td>Siemens</td><td>Siemens</td></tr> <tr><td>SMAR</td><td>SMAR</td></tr> <tr><td>SMC Corporation</td><td>SMC Corporation</td></tr> <tr><td>Spectrum Controls</td><td>Spectrum Controls</td></tr> <tr><td>Status Instruments Ltd.</td><td>Status Instruments Ltd.</td></tr> <tr><td>Stonel Corporation</td><td>Stonel Corporation</td></tr> <tr><td>TopWorx</td><td>TopWorx</td></tr> <tr><td>Toshiba</td><td>Toshiba</td></tr> <tr><td>Tyco Valves &amp; Controls</td><td>Tyco Valves &amp; Controls</td></tr> <tr><td>Valmet</td><td>Valmet</td></tr> <tr><td>Valve Automation</td><td>Valve Automation</td></tr> <tr><td>VEGA</td><td>VEGA</td></tr> <tr><td>VEGA Grieshaber KG</td><td>VEGA Grieshaber KG</td></tr> <tr><td>Westlock Controls</td><td>Westlock Controls</td></tr> <tr><td>WIKA</td><td>WIKA</td></tr> <tr><td>Yamatake</td><td>Yamatake</td></tr> <tr><td>YOKOGAWA</td><td>YOKOGAWA</td></tr> </tbody> </table>	Tag	Manufacturer	Rosemount Tank Radar	Rosemount Tank Radar	Rotork	Rotork	Samson	Samson	SAMSON AG	SAMSON AG	Schneider Electric	Schneider Electric	Siemens	Siemens	SMAR	SMAR	SMC Corporation	SMC Corporation	Spectrum Controls	Spectrum Controls	Status Instruments Ltd.	Status Instruments Ltd.	Stonel Corporation	Stonel Corporation	TopWorx	TopWorx	Toshiba	Toshiba	Tyco Valves & Controls	Tyco Valves & Controls	Valmet	Valmet	Valve Automation	Valve Automation	VEGA	VEGA	VEGA Grieshaber KG	VEGA Grieshaber KG	Westlock Controls	Westlock Controls	WIKA	WIKA	Yamatake	Yamatake	YOKOGAWA	YOKOGAWA
Tag	Manufacturer																																														
Rosemount Tank Radar	Rosemount Tank Radar																																														
Rotork	Rotork																																														
Samson	Samson																																														
SAMSON AG	SAMSON AG																																														
Schneider Electric	Schneider Electric																																														
Siemens	Siemens																																														
SMAR	SMAR																																														
SMC Corporation	SMC Corporation																																														
Spectrum Controls	Spectrum Controls																																														
Status Instruments Ltd.	Status Instruments Ltd.																																														
Stonel Corporation	Stonel Corporation																																														
TopWorx	TopWorx																																														
Toshiba	Toshiba																																														
Tyco Valves & Controls	Tyco Valves & Controls																																														
Valmet	Valmet																																														
Valve Automation	Valve Automation																																														
VEGA	VEGA																																														
VEGA Grieshaber KG	VEGA Grieshaber KG																																														
Westlock Controls	Westlock Controls																																														
WIKA	WIKA																																														
Yamatake	Yamatake																																														
YOKOGAWA	YOKOGAWA																																														
4	<p>Click on the <b>Device List</b> node (above) to confirm there is a folder for Schneider Electric. This confirms the Schneider Electric HART multiplexer DD has been added to the AMS device list.</p>																																														

Step	Action																		
5	<p>Open the <b>Physical Networks</b> node to display the new network <b>Multiplexer Network 1</b>, then click the right mouse button to display the following menu:</p>  <p>The screenshot shows the 'AMS Suite: Intelligent Device Manager - [Device Explorer]' window. The tree view on the left is expanded to 'Physical Networks' &gt; 'Workstation-1' &gt; 'Multiplexer Network 1'. A right-click context menu is open over 'Multiplexer Network 1', showing the following options: 'Rebuild Hierarchy', 'Scan', 'Help', and 'Options'. The status bar at the bottom of the window displays 'Ready'.</p>																		
6	<p>Select <b>Rebuild Hierarchy</b> (above). The <i>AMS Device Manager</i> software searches for HART devices connected to the network. The software adds a new node to the physical network tree when it discovers the Schneider Electric HART multiplexer:</p>  <p>The screenshot shows the same software window after the 'Rebuild Hierarchy' action. The tree view now includes a new node '1/31/2012 15:15:38:467' under 'Multiplexer Network 1'. The right pane displays a table of discovered devices:</p> <table border="1" data-bbox="669 1143 1200 1403"> <thead> <tr> <th>Tag</th> <th>Manufacturer</th> <th>Device Type</th> <th>Device Rev.</th> <th>Protocol</th> <th>Pr...</th> </tr> </thead> <tbody> <tr> <td>1/31/2012 15:15:52:747</td> <td>Endress+Hauser</td> <td>TMT 122</td> <td>2</td> <td>HART</td> <td>5</td> </tr> <tr> <td>1/31/2012 15:15:54:623</td> <td>Manufacture 94</td> <td>238</td> <td>1</td> <td>HART</td> <td>5</td> </tr> </tbody> </table> <p>The status bar at the bottom of the window now displays 'Ready', 'Workstation-1', and 'User:admin'.</p>	Tag	Manufacturer	Device Type	Device Rev.	Protocol	Pr...	1/31/2012 15:15:52:747	Endress+Hauser	TMT 122	2	HART	5	1/31/2012 15:15:54:623	Manufacture 94	238	1	HART	5
Tag	Manufacturer	Device Type	Device Rev.	Protocol	Pr...														
1/31/2012 15:15:52:747	Endress+Hauser	TMT 122	2	HART	5														
1/31/2012 15:15:54:623	Manufacture 94	238	1	HART	5														

Step	Action
7	Select the new HART multiplexer node in the left pane to display a list of connected HART field instrument in the right pane.
8	You can right click on an item listed in the right pane to display a menu, which you can use to open monitoring, configuration, and diagnostic windows relating to that device. <b>NOTE:</b> Consult the documentation provided by the vendor of the device management software and the HART field instruments for instructions on how to work use the software in conjunction with the HART instruments.

---

# Glossary



---

## A

### **analog input**

A module that contains circuits that convert analog input signals to digital values that can be manipulated by the processor. By implication, these analog inputs are usually direct. That means a data table value directly reflects the analog signal value.

### **analog output**

A module that contains circuits that transmit an analog signal proportional to a digital value input to the module from the processor. By implication, these analog outputs are usually direct. That means a data table value directly controls the analog signal value.

### **asset management software**

A software application that can configure, monitor, and manage devices employed as part of an industrial automation system.

### **asynchronous**

Communication mode typified by the absence of a global, fixed-rate clock signal. Instead, asynchronous communication control is spread among multiple devices, that communicate and synchronize over shared channels.

### **auto addressing**

The automatic assignment of an address to each island bus I/O module.

**auto configuration**

The ability of island modules to operate with predefined default parameters. A configuration of the island bus based completely on the actual assembly of I/O modules.

**B**

**basic I/O**

Low-cost STB input/output modules that use a fixed set of operating parameters. A basic I/O module cannot be re-configured with the Advantys configuration software, and cannot be used in reflex actions.

**basic NIM**

A low-cost STB network interface module that supports up to 12 STB I/O modules. A basic NIM does not support the Advantys configuration software, reflex actions, nor the use of an HMI panel.

**basic PDM**

A low-cost STB PDM that distributes sensor power and actuator power over a single field power bus on the island. The bus provides a maximum of 4 A total power. A basic PDM requires a 5 A fuse to help protect the I/O.

**Bell 202 FSK standard**

A standard defining the operation of *frequency shift keying*: a frequency modulation scheme that transmits digital information by means of discrete frequency changes in a carrier wave.

**BootP**

*Bootstrap Protocol*: A UDP/IP protocol that allows an internet node to obtain its IP parameters based on its MAC address.

**BOS**

*Beginning of Segment*: An STB XBE 1300 BOS module is installed in the first position in an extension segment, when the STB island consists of more than one segment. Its job is to carry island bus communications to—and provide logic power for—the modules in the extension segment.

## C

### **configuration**

The arrangement and interconnection of hardware components within a system, and the hardware and software settings that determine the operating characteristics of the system.

### **current loop**

An analog electrical signaling scheme, that allows a device to be monitored or controlled over a pair of conductors. Only one current level can exist in a current loop at any point in time. A digital signal can be added to the analog current loop using the HART protocol, enabling additional communication with the analog device.

## D

### **DDL**

*Device Description Language file:* A definitional template for a HART field instrument, that describes its configurable parameters, the data that it can produce, and its operating procedures, including menus, commands and display formats.

### **device name**

A user-defined, unique identifier for an Ethernet NIM. A device name (or *role name*) is created when you combine the upper and lower numeric rotary switch values with the NIM (for example, STBNIP2212\_123). After the NIM is configured with a valid device name, a DHCP server can use it to identify the island and provide an IP address to the NIM at power up.

### **DHCP**

*Dynamic Host Configuration Protocol.* A TCP/IP protocol that allows a server to assign an IP address based on a device name (host name) to a network node.

### **DIN**

*Deutsche Industrial Norms.* A German agency that sets engineering and dimensional standards and now has worldwide recognition.

**DTM**

*Device Type Manager.* A DTM is a software component that acts as a device driver. It contains information for configuring, diagnosing, and maintaining particular field devices. Many manufacturers provide device-specific DTMs, but a generic DTM can be used to drive a wide variety of devices.

**E**

**EIA**

*Electronic Industries Association:* An organization that establishes electrical/electronic and data communication standards.

**EMC**

*electromagnetic compatibility:* Devices that meet EMC requirements can operate within a system's expected electromagnetic limits without interruption.

**EMI**

*electromagnetic interference:* EMI can cause an interruption or disturbance in the performance of electronic equipment. It occurs when a source electronically transmits a signal that interferes with other equipment. Also known as radio frequency interference (RFI).

**EOS**

*End of Segment:* An STB XBE 1100 EOS module is installed in the last position in every segment that has an extension following it, when an island consists of more than 1 segment. The EOS module extends island bus communications to the next segment.

**Ethernet**

A 10 or 100 Mb/s, CSMA/CD, frame-based LAN that can run over twisted pair or fiber optic cable, or wireless. The IEEE standard 802.3 defines the rules for configuring a wired Ethernet network; the IEEE standard 802.11 defines the rules for configuring a wireless Ethernet network.

## F

### **fallback state**

A known state to which an STB I/O module can return in the event that it loses communication with the PLC.

### **FE**

*functional ground*: A grounded supply conductor, often carrying current, that is used to enhance the operation of equipment. Contrast: *protective ground (PE)*.

### **Flash memory**

Nonvolatile memory that can be overwritten. It is stored on an EEPROM that can be erased and reprogrammed.

## H

### **half duplex**

A system of communication that provides for transmissions in both directions, but in only one direction at a time.

### **HART**

*Highway Addressable Remote Transducer protocol*: A bi-directional communication protocol for transmitting—across analog wires—digital information between intelligent field devices and a host control/monitoring system. For more information, refer to the *HART Communication Foundation* web site: [www.hartcomm.org](http://www.hartcomm.org).

### **HART interface module**

A modem that serves as the pass through device between one or more HART master devices, and multiple HART slave devices. In STB the STB AHI 8321 module.

### **HART master**

A HART host application, typically resident in a PC. For example, asset management software.

**HART slave**

A HART compliant smart field device, which responds via the HART protocol only when commanded to do so by a HART master.

**high pass filter**

A frequency-based filter that permits transmissions only above a pre-set frequency threshold to pass. In HART, the frequency threshold is typically set in range of 400...800 Hz: transmissions above this threshold—HART digital signals—are allowed to pass through; transmissions beneath this threshold are filtered.

**HMI**

*human-machine interface:* An operator interface, usually graphical, used by operators of industrial equipment.

**hot swapping**

Replacing a component with a like component while the system remains operational. When the replacement component is installed, it begins to function automatically.

**I**

**I/O base**

A mounting device, designed to seat an STB I/O module, connect the module to a DIN rail, and connect the module to the island bus. The I/O base provides the connection point where the I/O module can receive power from the input or output power bus distributed by a PDM.

**I/O module**

In a programmable controller system, an I/O module interfaces directly to the sensors and actuators of the machine/process. This module is the component that mounts in an I/O base and provides electrical connections between the controller and the field devices.

**IEC**

*International Electrotechnical Commission Carrier:* Founded in 1884 to focus on advancing the theory and practice of electrical, electronics and computer engineering, and computer science. EN 61131-2 is the specification that deals with industrial automation equipment.

**IEEE**

*Institute of Electrical and Electronics Engineers, Inc.:* The international standards and conformity assessment body for all fields of electrotechnology, including electricity and electronics.

**IP**

*Internet Protocol:* That part of the TCP/IP protocol family that tracks the internet addresses of nodes, routes outgoing messages, and recognizes incoming messages.

**IP rating**

*ingress protection rating:* A standardized approach to establishing the degree to which a device resists the ingress of particles and water, as defined by IEC 60529. For example:

- IP20 requires that a device not permit the ingress and contact of objects larger than 12.5 mm (0.49 in). The standard does not require resistance to ingress by water.
- IP67 requires that a device completely resist the ingress of dust and contact by objects. The standard requires that no Ingress of water in harmful quantity be permitted when the enclosure is immersed in water up to 1 m (39.37 in).

**L****low pass filter**

A frequency-based filter that permits transmissions only below a pre-set frequency threshold to pass. In HART, the frequency threshold is typically set in range of 25 Hz: transmissions below this threshold—analogue signals—are allowed to pass through; transmissions above this threshold—HART digital signals—are filtered.

**M****MAC address**

*Media Access Control address:* A 48-bit number, unique on a network, that is programmed into each network card or device when it is manufactured.

**mandatory module**

An STB I/O module configuration setting that requires the module to be present and healthy in the island configuration, if the island is to remain operational. If a mandatory module is inoperable or is removed from its location on the island bus, the island goes to a pre-operational state. By default, all I/O modules are not mandatory. Use the Advantys configuration software to set this parameter.

**Modbus**

An application layer messaging protocol. Modbus provides serial communications between master and slave devices connected on different types of buses or networks.

**multiplexer**

A multiplexer (MUX) is a device that selects one of several input signals and forwards the selected input into a single line. In STB, an island consisting of a HART enabled Ethernet network interface module and from 1 to 8 HART interface modules perform the task of multiplexer.

**N**

**NaN**

*Not a number:* A numeric data type value representing an undefined or unrepresentable value.

**NEMA**

*National Electrical Manufacturers Association*

**NIM**

*network interface module:* The interface between an island bus and the fieldbus network of which the island is a part. A NIM enables all the I/O on the island to be treated as a single node on the fieldbus. The NIM also provides 5 V of logic power to the STB I/O modules in the same segment as the NIM. The HART multiplexer uses the STB NIP 2311 Ethernet NIM.

---

## P

### PDM

*power distribution module*: A module that distributes either field power to a cluster of input and output modules, located directly to its right, on the island bus. For the HART multiplexer, you can use either the STB PDT 3100 standard NIM, or the STB PDT 3105 basic NIM.

### PE

*protective ground*: An equipment grounding conductor that keeps the exposed conductive surfaces of equipment at earth potential. A PE conductor does not enhance or facilitate the operation of the equipment. Its purpose is to guard the operator against potential electric shock. Contrast: *functional ground (FE)*.

### PLC

*programmable logic controller*: The PLC is a digital computer used for automation of electromechanical processes, such as control of machinery. PLCs are used in many industries and machines. The PLC is designed to:

- communicate via multiple inputs and outputs
- operate in an extended range of temperatures
- perform under conditions that may include dust, water, electrical noise, vibration and impact

Programs to control machine operation are typically stored in non-volatile memory. A PLC is designed to provide highly deterministic performance, within predictable time boundaries.

### primary master

In HART, when two master devices are connected to the HART communication network, the HART controller. The HART primary master is typically asset management software resident on a PC.

### process image

A part of the NIM firmware that serves as a real-time data area for the data exchange process. The process image includes an input buffer that contains current data and status information from the island bus and an output buffer that contains the current outputs for the island bus, from the fieldbus master.

## R

### **reflex action**

A simple, logical command function configured locally on an island bus I/O module. Reflex actions are executed by island bus modules on data from various island locations, like input and output modules or the NIM. Examples of reflex actions include compare and copy operations.

### **RFI**

*radio frequency interference: See EMI.*

## S

### **secondary master**

In HART, when two master devices are connected to the HART communication network, a hand-held master device temporarily connected to the network.

### **segment**

A group of interconnected I/O and power modules on an island bus. An island consists of at least 1 segment and, depending on the type of NIM used, may have as many as 7 segments. The first (leftmost) module in a segment needs to provide logic power and island bus communications to the I/O modules on its right. In the primary segment, that function is filled by a NIM. In an extension segment, that function is filled by a BOS module.

### **SELV**

*safety extra low voltage:* A secondary circuit designed so that the voltage between any 2 accessible parts (or between 1 accessible part and the PE terminal for Class 1 equipment) does not exceed a specified value under normal conditions or under single point of failure conditions. Schneider Electric's Phaseo ABL8 range of power supplies has products that comply with the SELV standard in IEC/EN 60364-4-41.

### **SIM**

*subscriber identification module.* In STB, configuration data created or modified with the Advantys configuration software can be stored on a SIM (referred to as the "removable memory card") and then written to the NIM's Flash memory.

**sink load**

An output that, when turned on, receives DC current from its load.

**size 1 base**

A mounting device, designed to seat an STB module, connect it to a DIN rail, and connect it to the island bus. It is 13.9 mm (0.55 in.) wide and 128.25 mm (5.05 in.) high.

**size 2 base**

A mounting device, designed to seat an STB module, connect it to a DIN rail, and connect it to the island bus. It is 18.4 mm (0.73 in.) wide and 128.25 mm (5.05 in.) high.

**size 3 base**

A mounting device, designed to seat an STB module, connect it to a DIN rail, and connect it to the island bus. It is 28.1 mm (1.11 in.) wide and 128.25 mm (5.05 in.) high.

**source load**

A load with a current directed into its input; it is driven by a current source.

**standard I/O**

Any of a subset of STB input/output modules designed at a moderate cost to operate with user-configurable parameters. A standard I/O module may be reconfigured with the Advantys configuration software, and may be used in reflex actions.

**standard NIM**

An STB network interface module designed at moderate cost to support the configuration capabilities, multi-segment design and throughput capacity suitable for many standard applications on the island bus. An island run by a standard NIM can support up to 32 addressable I/O modules. The HART multiplexer uses the STB NIP 2311 standard NIM.

**standard PDM**

A standard PDM (power distribution module) is an STB module that distributes sensor power to the input modules and actuator power to the output modules over two separate power buses on the island. The bus provides a maximum of 4 A to the input modules and 8 A to the output modules. A standard PDM requires a 5 A fuse to help protect the input modules and an 8 A fuse to help protect the outputs. The HART multiplexer supports the use of the STB PDT 3100 standard PDM.


## T

### TCP

*transmission control protocol*: A connection-oriented transport layer protocol that provides full-duplex data transmission. TCP is part of the TCP/IP suite of protocols.

---

# Index



---

## 0-9

- 140 ACI 030 00
  - wiring, 143
- 140 ACO 020 00
  - wiring, 144

## A

- AMS software
  - add Schneider Electric DD file, 176
  - create network, 180
  - discover network, 185
- analog I/O
  - current consumption, 57
- analog I/O modules
  - CE compliance for, 85
- auto-configure, 100

## B

- BMX AMI 0410
  - wiring, 153
- BMX AMO 0210
  - wiring, 154
- BootP server, 95

## C

- configuration
  - custom, 103
  - default, 100
- cooling the cabinet, 46

- current consumption
  - analog I/O, 57
  - EOS, 57
  - HART interface module, 57
- current loop resistance
  - calculating, 133
- custom configuration, 121, 123

## D

- default IP address, 98
- device description language file, 25
- DHCP server, 95
- DIN rail
  - installing, 64

## E

- Eltima software, 172
- enclosing the multiplexer, 42
- EOS module
  - current consumption, 57
- EOS/BOS modules compatibility
  - installing extension segments, 77
- extending the island bus, 40
- extension segments
  - installing, 76
- external power supplies
  - recommended, 61
  - selecting, 60

## **F**

FE, 84  
Flash memory, 101  
    overwriting, 121  
functional ground, 84

## **G**

getting started, 9

## **H**

half-duplex, 25  
HART protocol, 24

## **I**

initial configuration, 122  
input power, 54  
installation plan, 68  
installing extension segments  
    EOS/BOS modules compatibility , 77  
IP address  
    default, 98  
    MAC address, 98  
    setting, 95  
IP address  
    setting, 95  
island bus  
    creating, 68  
    extending, 40  
    terminating, 71  
island bus node address, 95  
Isolation requirements, 80

## **L**

logic power, 52

## **M**

M340 I/O wiring, 151  
MAC address, 98  
mandatory module, 113

## **Multiplexer**

components, 26  
enclosing, 42  
features, 28  
functions, 29  
HART data flows, 31  
I/O placement, 32  
island components, 34  
maximum size, 27

## **N**

network considerations, 122  
NIM  
    installing, 65  
    not present, 113

## **O**

output power, 54

## **P**

PE, 82  
power distribution modules, 47  
power supplies  
    logic bus current capacity, 56  
Premium I/O wiring, 146  
protective ground, 82

## **Q**

Quantum I/O wiring, 141

## **R**

reflex actions, 113  
removable memory card, 123, 125  
resistance  
    current loop, 133  
RFI/EMI  
    suppressing with EMC kit, 85  
rise and fall times  
    analog outputs, 134  
rotary switches, 95

RST button, *101*

## S

SELV-rated isolation

in the 24 Vdc power source, *80*

Serial to Ethernet Connector, *172*

STB ACI 8320

wiring, *137*

STB ACO 0220

wiring, *139*

STB AHI 8321 module

adding data items, *114*

channel settings, *105*

configuring, *103*

current consumption, *57*

IO image, *110*

mandatory, *112*

mapping data items, *108*

STB I/O wiring, *136*

STB modules

installing, *73*

STB PDT 310x

power supply capacity, *58*

STB XMP 4440 removable memory card

installing, *124*

removing, *125*

STB XTS 1120 screw type power connector,  
*77*

STB XTS 2120 spring clamp field wiring con-  
nector, *77*

storing configuration data

to a removable memory card, *123*

## T

TSX AEY 810

wiring, *148*

TSX ASY 420

wiring, *149*

## V

Virtual Placeholders, *113*

voltage cut-out switching

advantages, *81*

relays for, *81*

## W

wattage dissipation

in a system cabinet, *46*

wiring

140 ACI 030 00, *143*

140 ACO 020 00, *144*

BMX AMI 0410, *153*

BMX AMO 0210, *154*

M340 I/O, *151*

Premium I/O, *146*

Quantum I/O, *141*

STB ACI 8320, *137*

STB ACO 0220, *139*

STB I/O, *136*

TSX AEY 810, *148*

TSX ASY 420, *149*

wiring diagram

actuator power, *128*

logic power, *128*

sensor power, *128*

