




NHA3717101

Altivar Process Drive Systems

Exchange the power fan



VX5VPM001

⚠️ ⚠️ DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Only appropriately trained persons who are familiar with and understand the contents of this manual and all other pertinent product documentation and who have received safety training to recognize and avoid hazards involved are authorized to work on and with this drive system. Installation, adjustment, repair and maintenance must be performed by qualified personnel.
- The system integrator is responsible for compliance with all local and national electrical code requirements as well as all other applicable regulations with respect to grounding of all equipment.
- Many components of the product, including the printed circuit boards, operate with mains voltage. Do not touch. Use only electrically insulated tools.
- Only use properly rated, electrically insulated tools and measuring equipment.
- Do not touch unshielded components or terminals with voltage present.
- Motors can generate voltage when the shaft is rotated. Prior to performing any type of work on the drive system, block the motor shaft to prevent rotation.
- AC voltage can couple voltage to unused conductors in the motor cable. Insulate both ends of unused conductors of the motor cable.
- Do not short across the DC bus terminals or the DC bus capacitors or the braking resistor terminals.
- Before performing work on the drive system:
 - Disconnect all power, including external control power that may be present.
Take into account that the circuit breaker or main switch does not de-energize all circuits.
 - Place a "Do Not Turn On" label on all power switches related to the drive system.
 - Lock all power switches in the open position.
 - Wait 15 minutes to allow the DC bus capacitors to discharge.
- Measure the voltage (in AC mode and in DC mode) using a properly rated voltmeter on the mains input and the motor output terminals between the phases and between each phase and ground to verify that no hazardous voltage is present.
 - If there is still hazardous voltage present on the terminals, contact your local Schneider Electric representative. Do not repair or operate the product.
 - Verify that there is no other voltage present on the drive system.
 - Ground and short-circuit the mains and motor terminals.
- Before applying voltage to the drive system:
 - Verify that the work has been completed and that the entire installation is in a safe condition and cannot cause hazards.
 - Remove the ground and short circuits on mains and motor terminals.
 - Verify that all protective equipment such as covers, doors, grids is installed and/or closed.

Failure to follow these instructions will result in death or serious injury.

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this product.


© 2016 Schneider Electric. All Rights Reserved.

NHA37171-01
08-2016


1/4

Schneider
Electric


1




2




3




4




5




6




7




8




9




10




11




12



13



14



15

