

INSTRUCTIONS V00029BV

© Panduit Corp. 2013

Front and Rear Floor Seal Installation

- Install Floor Seal to front or rear of cabinet frame using (2) M10x20mm Bolts. (Flange on floor seal will face outward away from the cabinet.)

