


Tasti intercambiabili per pulsanti

Interchangeable rockers for push-buttons

Life 44	Allumia	Descrizione Description	Info	€	□	□
		■ 442TSP ■ 443TSP Tasto intercambiabile con simbolo SUONERIA illuminabile - 1 modulo <i>Interchangeable rocker with lightable BELL symbol - 1 module</i>	14	14		
442TSP	443TSP	■ 442TSP/2 ■ 443TSP/2 Tasto intercambiabile con simbolo SUONERIA illuminabile - 2 moduli <i>Interchangeable rocker with lightable BELL symbol - 2 modules</i>	2	2		
		■ 442TLSP ■ 443TLSP Tasto intercambiabile con simbolo LUCE SCALE illuminabile - 1 modulo <i>Interchangeable rocker with lightable STAIR LIGHT symbol - 1 module</i>	14	14		
442TSP/2	443TSP/2	■ 442TCP ■ 443TCP Tasto intercambiabile con simbolo CAMERIERE illuminabile - 1 modulo <i>Interchangeable rocker with lightable WAITER symbol - 1 module</i>	14	14		
		■ 442TRESP ■ 443TRESP Tasto intercambiabile con scritta RESET illuminabile - 1 modulo <i>Interchangeable rocker with lightable RESET symbol - 1 module</i>	14	14		
442TLSP	443TLSP	■ 442TNDP ■ 443TNDP Tasto intercambiabile con simbolo/scritta DO NOT DISTURB illuminabile - 1 modulo <i>Interchangeable rocker with lightable DO NOT DISTURB symbol - 1 module</i>	14	14		
		■ 442TCP ■ 443TCP Tasto intercambiabile con simbolo/scritta PLEASE CLEAN illuminabile - 1 modulo <i>Interchangeable rocker with lightable PLEASE CLEAN symbol - 1 module</i>	14	14		
442TRESP	443TRESP					
						
442TNDP	443TNDP					
						
442TPCP	443TPCP					

127



Sistema 45