



Dimensional data 375006

* Recommended height, unless different regulations are specified.




To ensure proper operation, the Fingerprint Reader must be installed in a location protected from rain.

Installation 375006




Dimensional data 375007

* Recommended height, unless different regulations are specified.




To ensure proper operation, the Fingerprint Reader must be installed in a location protected from rain.

Installation 375007




Dimensional data 375008

* Recommended height, unless different regulations are specified.






To ensure proper operation, the Fingerprint Reader must be installed in a location protected from rain.

Installation 375008





Dimensional data 375009

* Recommended height, unless different regulations are specified.



To ensure proper operation, the Fingerprint Reader must be installed in a location protected from rain.

Installation 375009



Warnings and consumer rights



Read carefully before use and keep for future reference



Touching the units with wet hands is forbidden
Using liquid cleaners or aerosols is forbidden
Blocking the ventilation openings is forbidden
Modifying the devices is forbidden
Removing protective parts from the devices is forbidden
Installing the units near liquids and powders is forbidden
Installing the units near heat sources is forbidden
Installing the units near harmful gases, metal dusts or similar is forbidden
Fastening the units on unsuitable surfaces is forbidden



Risk of devices falling because the surface on which they are installed collapses or inappropriate installation
Switch the power supply OFF before any work on the system



Caution: Installation, configuration, starting-up and maintenance must be performed exclusively by qualified personnel.
Check that the wall installation has been carried out correctly
Lay out the wires respecting the standards in force
Connect the power supply wires as indicated
Use only the items indicated in the technical specifications for any system expansions