



ERX 2000





Important product
information (1 2 4)



www.deltadore.com




	230 V~, 50 Hz 1 VA		54 x 140 x 25 mm
	16 max.	IP	IP 44
 ERX	2 max.	CE	
	868,7 MHz -> 869,2 MHz (EN 300 220) - 300 m max. Maximum wireless power < 10 mW - Category 2 receiver	°C Stockage / Storage	-10°C / +70°C
		°C Utilisation / Use	-20°C / +60°C




1



2



5





ERX 2000 N°1




ON

230V~
50 Hz






3



OK

ERX 2000 N°2



Récepteur / Receiver / Receptor / Receptor / Ricevitore / Empfänger / Odbiornik / Ontvanger / Prijímač / Mottagare / Modtager / Mottaker / Vastaanotin / 接收器 /



Émetteur / Transmitter / Emisor / Emissor / Emittitore / Sender / Nadajnik / Zender / Vysílač / Sändare / Transmitter / Sender / Lähetin / 发射器 /



Association / Association / Asociación / Associação / Associazione / Verbinndung / Przepisanie / Verbinndung / Přřazení / Associering / Tilknytning / Forbindelse / KytKentä / 连接 /



Suppression d'une association / Delete one association / Borrar asociación / Eliminar asociación / Eliminare le associazioni / Verbinndung löschen / Usunięcie przypisania / Een verbinnding opheffen / Zrušit přřazení / Ta bort associationerna / Sletning af en tilknytning / Slette en Forbindelse / Poista kytKentä / 删除一个连接 /



Reset total / Total reset / Reset total / Reinicialização total / Reset totale / Reset / Reset calkowity / Totale reset / Celkový reset / Total återställning / Total nullstilling / Total nullstilling / Nollaa kaikki / 完全初始化设置 /



Clignotement lent / Slow flashing / Parpadeo lento / Intermitência lenta / Lamppeggiamento lento / Langsames blinken / Wolne miganie / Langzaam knipperen / Pomale błikani / Blinking lngsam / Langsomme blink / Langsomme blink / Hidas vilkunta / 缓慢的闪烁 /



Clignotement rapide / Fast flashing / Parpadeo rápido / Intermitência rápida / Lamppeggiamento rapido / Schnelles blinken / Szybkie miganie / Snel knipperen / Rychle błikani / Snabb blinkningar / Hurtige blink / Raske blink / Nopea vilkunta / 快速的闪烁 /



Temps d'appui / Press time / Tiempo de pulsación / Tempo de pressão / Tempo pressione / Tastendruckdauer / Czas naciskania / Drukttj / Doba stisknutí / Kopplingstid / Tid Nedtrykning / Trykktid / Painallisaika / 按键时间 /



Voyant éteint / LED off / Testigo apagado / Indicador apagado / Spia spenta / Kontrollleuchte aus / Lamka gašnie / Controlelampe uit / LED nesviti / Lampan släcks / Kontrolllampe slukket / Lysdiode slukket / Merkkivalo palaa / 指示灯熄灭 /