




XT-RJ45-ETH-RS232




Dimensions




Fitting



Dismantling





I
N

Signal		
Ethernet		RS232
8	–	RxD
7	–	GND
6	Rx–	–
5	–	TxD
4	–	GND
3	Rx+	–
2	Tx–	–
1	Tx+	–

E
T
H
E
R
N
E
T

Signal		
Ethernet		
8	–	
7	–	
6	Rx–	
5	–	
4	–	
3	Rx+	
2	Tx–	
1	Tx+	

R
S
2
3
2

Signal		
		RS232
8		RxD
7		GND
6		–
5		TxD
4		GND
3		–
2		–
1		–

08/21 IL05009002Z

