


KIT SINFONIA SYSTEM
UP TO 6-LIGHT COMPOSITION
rev:0



- CA103DWHEZZ
- CA103DBBEZZ
- CA103DCEZZ
- CA103DHGEZZ

■ KIT0110
 ■ KIT0106

KIT NOT INCLUDED

- CA106RWHEZZ
- CA106RBEZZ
- CA106RCHEZZ
- CA106RHGEZZ

5m

5m

- CA107DWHWDI - 3000K
- CA107DBBWDI - 3000K
- CA107DCHWDI - 3000K
- CA107DHGWDI - 3000K
- CA107DWHMDI - 2700K
- CA107DBBMDI - 2700K
- CA107DCHMDI - 2700K
- CA107DHGMDI - 2700K

- CA108DWHWDI - 3000K
- CA108DBBWDI - 3000K
- CA108DCHWDI - 3000K
- CA108DHGWDI - 3000K
- CA108DWHMDI - 2700K
- CA108DBBMDI - 2700K
- CA108DCHMDI - 2700K
- CA108DHGMDI - 2700K

- CA109DWHWDI - 3000K
- CA109DBBWDI - 3000K
- CA109DCHWDI - 3000K
- CA109DHGWDI - 3000K
- CA109DWHMDI - 2700K
- CA109DBBMDI - 2700K
- CA109DCHMDI - 2700K
- CA109DHGMDI - 2700K

- CA110DWHWDI - 3000K
- CA110DBBWDI - 3000K
- CA110DCHWDI - 3000K
- CA110DHGWDI - 3000K
- CA110DWHMDI - 2700K
- CA110DBBMDI - 2700K
- CA110DCHMDI - 2700K
- CA110DHGMDI - 2700K

4W 4W 6W 6W

KIT NOT INCLUDED

5m

- CA113DWHWDI - 3000K
- CA113DBBWDI - 3000K
- CA113DCHWDI - 3000K
- CA113DHGWDI - 3000K
- CA113DWHMDI - 2700K
- CA113DBBMDI - 2700K
- CA113DCHMDI - 2700K
- CA113DHGMDI - 2700K

- CA112DWHWDI - 3000K
- CA112DBBWDI - 3000K
- CA112DCHWDI - 3000K
- CA112DHGWDI - 3000K
- CA112DWHMDI - 2700K
- CA112DBBMDI - 2700K
- CA112DCHMDI - 2700K
- CA112DHGMDI - 2700K





- CA111DWHWDI - 3000K
- CA111DBBWDI - 3000K
- CA111DCHWDI - 3000K
- CA111DHGWDI - 3000K
- CA111DWHMDI - 2700K
- CA111DBBMDI - 2700K
- CA111DCHMDI - 2700K
- CA111DHGMDI - 2700K

6W 6W 6W


KIT NOT INCLUDED

House icon with light bulb (correct) vs. person icon with red X (incorrect).
 Four diagrams showing correct and incorrect installation methods in a ceiling.
 Box icon = Manual icon + Screws icon.


Three diagrams showing the correct and incorrect way to mount the fixture to a ceiling using screws.





5





6





1





2



3




4





DETTAGLIO A

7




8







ON/OFF

Max 30mtl








MIN 2.5 - MAX 36W






ON/OFF







■ KIT0110



ISTRUZIONI PER IL LAVAGGIO DELL'APPARECCHIO D'ILLUMINAZIONE
LUMINAIRE CARE INSTRUCTIONS
ISTRUCCIONES PARA LIMPIAR LA LUMINARA
INSTRUCTIONS POUR LE LAVAGE DE L'APPAREIL D'ECLAIRAGE
ANLEITUNG ZUR REINIGUNG DES BELEUCHTUNGSGERATS



IT - ATTENZIONE!!!

Lavare la superficie del diffusore luce con panno umido, utilizzando solo acqua e sapone neutro.

EN - WARNING!!!

Wipe clean with a cloth dampened in water with neutral detergent.

ES - ATENCION!!!



Limpie la superficie del difusor con un pano humedecido con agua y jabon neutro.

FR - ATTENTION!!!

Laver la surface du diffuseur de lumiere a l'aide d'un chiffon humide et en utilisant seulement de l'eau et du savon neutre.

DE - ACHTUNG!!!

Die oberfläche vom lampenschirm mit einem feuchten lappen reinigen. De lappen mit wasser und neutralseife befeuchten.



IT - ATTENZIONE!!!

Non utilizzare panni abrasivi e/o solventi.

EN - WARNING!!!

Avoiding the use of chemical solvents and/or abrasive cloths.

ES - ATENCION!!!

No utilizar panos abrasivos y solventes.

FR - ATTENTION!!!

Ne pas utiliser de chiffons abrasifs ou de dissolvants.

DE - ACHTUNG!!!

Abschleifende tuche und/oder losungmittel nicht benutzen.