

SMALL

3000 K	2700 K
 CA117ABBWDI	 CA117ABBMDI
 CA117ADBWDI	 CA117ADBMDI



MEDIUM

3000 K	2700 K
 CA118ABBWDI	 CA118ABBMDI
 CA118ADBWDI	 CA118ADBMDI




LARGE

3000 K	2700 K
 CA119ABBWDI	 CA119ABBMDI
 CA119ADBWDI	 CA119ADBMDI



1



TO AVOID CONDENSATION INSTALL
THE DIFFUSER IN A DRY ENVIRONMENT


2



3




IF THERE IS CONDENSATION IN THE LAMP





WAIT UNTIL COMPLETE
EVAPORATION

USE A TIMER FOR A DAY/NIGHT CYCLE



ISTRUZIONI PER IL LAVAGGIO DELL'APPARECCHIO D'ILLUMINAZIONE
LUMINAIRE CARE INSTRUCTIONS
ISTRUCCIONES PARA LIMPIAR LA LUMINARA
INSTRUCTIONS POUR LE LAVAGE DE L'APPAREIL D'ECLAIRAGE
ANLEITUNG ZUR REINIGUNG DES BELEUCHTUNGSGERATS



IT - ATTENZIONE!!!

Lavare la superficie del diffusore luce con panno umido, utilizzando solo acqua e sapone neutro.

EN - WARNING!!!

Wipe clean with a cloth damped in water with neutral detergent.

ES - ATENCION!!!



Limpie la superficie del difusor con un pano humedecido con agua y jabon neutro.

FR - ATTENTION!!!

Laver la surface du diffuseur de lumiere a l'aide d'un chiffon humide et en utilisant seulement de l'eau et du savon neutre.

DE - ACHTUNG!!!

Die oberfläche vom lampenschirm mit einem feuchten lappen reinigen. De lappen mit wasser und neutralseife befeuchten.



IT - ATTENZIONE!!!

Non utilizzare panni abrasivi e/o solventi.

EN - WARNING!!!

Avoiding the use of chemical solvents and/or abrasive cloths.

ES - ATENCION!!!

No utilizar panos abrasivos y solventes.

FR - ATTENTION!!!

Ne pas utiliser de chiffons abrasifs ou de dissolvants.

DE - ACHTUNG!!!

Abschleifende tuche und/oder losungsmittel nicht benutzen.