

I POSIZIONE DI MONTAGGIO
 INTERRUTTORI SEZIONATORI E COMMUTATORI

GB MOUNTING POSITION SWITCH DISCONNECTORS
 AND CHANGEOVER

GE...


POSIZIONE DI MONTAGGIO

Le prestazioni funzionali riportate nel catalogo LOVATO Electric più aggiornato sono state stabilite con gli interruttori sezionatori serie GE montati su un piano verticale e con attacchi di linea in alto e quelli di carico in basso.


Tutti gli interruttori sezionatori della serie GE possono essere montati, come riportato di seguito, senza subire declassamenti ad eccezione della pos. A.

È sconsigliabile montare il polo neutro verso il basso.


INTERRUPTORI SEZIONATORI



COMMUTATORI SEZIONATORI



COMMUTATORI SEZIONATORI CON COMANDO MOTORIZZATO







MOUNTING POSITION

The performances, given in the most update LOVATO Electric catalogue, have been established with GE series switch disconnectors mounted on a vertical place with line terminals facing upwards and load terminals facing downwards.

All GE series switch disconnectors can be mounted as illustrated in the following figures without any derating except for position A. It is not recommended to mount switch disconnectors with the neutral pole facing downwards.





1615 | GGB 06 19

SWITCH DISCONNECTORS







Pos. A

CHANGEOVER SWITCHES








Pos. A

MOTORISED CHANGEOVER SWITCHES



Pos. A



Pos. A

❶ Special assembly. Contact our Technical support (Tel. +39 035 4282422; E-mail: service@LovatoElectric.com) for details.