## **VERTICAL 4 POST TIE OFF BRACKET**




Part Number(s): V4PTOB, V4PTOBWH

© Panduit Corp. 2023 **INSTALLATION INSTRUCTIONS** V00030AP\_01 9. U A. Lower Panel n.u u n·n n a a a a a a R4P 00 a a a Mount < **Brackets** a a a Upper Panel a a a Rack Brackets a a a N a a a N Required hardware - included (6) M5-10mm CARRIAGE BOLT (14) M6 FLANGE NUT Required tools - not included RATCHET W/ M7 SOCKET & M10 SOCKET

#### TIE OFF BRACKET HEIGHT ADJUSTMENT


Tie Off Brackets can be adjusted to fit 42RU, 45RU & 52RU racks. See below for hole spacing for your specific rack height.


### **42RU**



# TIE OFF BRACKET HEIGHT ADJUSTMENT (cont.)


#### **45RU**






#### **R4P TIE OFF BRACKET ASSEMBLY**

- 1. Attach R4P Rack Mount Brackets at top & bottom of Rack using (4) M6 hex nuts.
- 2. Attach Rack Bracket to R4P Mount brackets using (4) M6 hex nuts.
- 3. Secure assembled panels to the Rack Brackets using (6) M6 hex nuts.




#### **AR4P TIE OFF BRACKET ASSEMBLY**

- 1. Attach Rack Bracket to rack using (4) M6 hex nuts.
- 2. Secure assembled panels to the Rack Brackets using (6) M6 hex nuts.



## L-Retainer (S1LR, S2LR) and D-Ring (S1DR, S2DR) Installation

- Cable Management L-Retainers Insert mounting tab of L-Retainer into any keyed mounting slot located on the cable management panel. Slide L-Retainer up or down in keyed slot and engage release tab in adjacent cutout. Pull release tab and reverse the process to remove L-Retainer.
- Cable Management D-Rings Insert mounting tab(s) of L-Retainer into round keyhole slot(s) located on the cable management panel. Slide D-Ring in keyhole slot to engage D-Ring.



For Instructions in Local Languages and Technical Support:

d Technical Support:

www.panduit.com

www.panduit.com

www.panduit.com

E-mail: techsupport@panduit.com Phone: 866-405-6654