



Indicator light

Non-illuminated  
button  
spring-return

Illuminated  
button  
spring-return

Emergency  
push button

	Contacts	Diagram
Device 1	/	
Device 2	1NO	
Device 3	1NO	
Device 4	2NC	

