



2 position key selector switch

Illuminated selector switch 2 positions

Indicator light

Illuminated button spring-return

Illuminated button spring-return

Illuminated button spring-return

Emergency push button

| | Contacts | Diagram |
|----------|----------|-----------------------------|
| Device 1 | 1NO | A1 — A4 A2 — A3 LED |
| Device 2 | 1NO | A1 — A5 A6 — A3 LED |
| Device 3 | / | A12 — A3 LED |
| Device 4 | 1NO | B1 — B4 B2 — B3 LED |
| Device 5 | 1NO | B1 — B5 B6 — B3 LED |
| Device 6 | 1NO | B1 — B7 B12 — B3 LED |
| Device 7 | 2NC | B8 — B9 B10 — B11 LED |

