



Illuminated button spring-return

Indicator light

Illuminated button spring-return

Indicator light

Non-illuminated button spring-return

Illuminated button spring-return

Emergency push button

	Contacts	Diagram
Device 1	1NO	A1 — A4 A2 — A3 LED
Device 2	/	A6 — A3 LED
Device 3	1NO	A1 — A7 A12 — A3 LED
Device 4	/	B2 — B3 LED
Device 5	1NO	B1 — B5 B6 — B3 LED
Device 6	1NO	B1 — B7 B12 — B3 LED
Device 7	2NC	A1 — B9 A12 — B11 LED

