



Indicator light

Indicator light

Indicator light

Indicator light

Illuminated selector switch  
2 positions  
∨

Illuminated button  
spring-return

Emergency push button

	Contacts	Diagram
Device 1	/	A2 — LED — A3
Device 2	/	A6 — LED — A3
Device 3	/	A12 — LED — A3
Device 4	/	B2 — LED — B3
Device 5	1NO	B1 — B5 B6 — LED — B3
Device 6	1NO	B1 — B7 B12 — LED — B3
Device 7	2NC	B8 — B9 B10 — B11

