



Illuminated button spring-return

Non-illuminated button spring-return

Indicator light

Indicator light

Illuminated selector switch 3 positions
↓

Indicator light

Emergency push button

| | Contacts | Diagram | Connections |
|----------|----------|----------------------------|-------------|
| Device 1 | 1NO | 6 — 4 1 — 19 | |
| Device 2 | 1NO | 6 — 5 2 — 19 | |
| Device 3 | / | 7 — 19 | |
| Device 4 | / | 12 — 19 | |
| Device 5 | 2NO | 6 — 17 6 — 3 16 — 19 | |
| Device 6 | / | 18 — 19 | |
| Device 7 | 2NC | 10 — 11 13 — 14 | |

Connector

M23 with 19 pole at the bottom

