



Illuminated selector switch  
2 positions

Illuminated selector switch  
2 positions

Illuminated button  
spring-return

Illuminated button  
spring-return

Illuminated button  
spring-return

Non-illuminated button  
spring-return

	Contacts	Diagram	Connections
Device 1	1NO	A1 — A2 A6 — A3 LED	
Device 2	1NO	A1 — A4 A8 — A3 LED	
Device 3	1NO	A1 — A7 A5 — A3 LED	
Device 4	1NO	B1 — B2 B6 — B3 LED	
Device 5	1NO	B1 — B4 B8 — B3 LED	
Device 6	1NO	B1 — B7 B5 — B3 LED	

