



Illuminated button spring-return

Illuminated button spring-return

Illuminated selector switch 2 positions

Non-illuminated button spring-return

Illuminated button spring-return

Illuminated button spring-return

	Contacts	Diagram
Device 1	1NO	A1 — A4 A2 — LED A3
Device 2	1NO	A1 — A5 A6 — LED A3
Device 3	1NO	A1 — A7 A12 — LED A3
Device 4	1NO	B1 — B4 B2 — LED B3
Device 5	1NO	B1 — B5 B6 — LED B3
Device 6	1NO	B1 — B7 B12 — LED B3

