



ACCESSORI / ACCESSORIES / ACCESSOIRES

**OVOLUX MOUNTING ADAPTER**



ADATTATORE (necessario per utilizzare gli accessori)
 ADAPTER (to mount the accessories)
 ADAPTATEUR (nécessaire pour utiliser les accessoires)

● 27697

**EXTENDED FOOT L10**



Base piana per montaggio superficiale con estensione di 10 cm
 Flat base for surface mount with 10 cm extension
 Base pour montage à plat (position soulevée de 10 cm)

● 27764

**WALL MOUNT**

Base parete per montaggio laterale
 Wall base for side mount
 Support fixation en applique (à filetage simple)

● 27762

**DOUBLE WALL MOUNT**

Base parete per montaggio laterale di 2 dispositivi
 Wall base for side mount of 2 devices
 Support fixation en applique (à double filetage) pour 2 dispositifs

● 27763

