






TYBOX 437

www.deltadore.com

Important product
information (24)

		
	2 x 1,5V LR03 - AAA Alkaline	230V~, 50 Hz +/- 10% 0,5 VA
		
	868 MHz (EN 300 220) 100 m	
	8 max.	
	/	3 A max., 230V~ (Type 1.C)
	-5°C / +40°C	
	80 x 103 x 25 mm	54 x 120 x 25 mm
		IP 44
		



MENU 1

1-01

0	PROG 7
1	PROG 1

1-02

0	60 min.
1	30 min.
2	15 min.

1-06

0	HEAT-COOL
1	HEAT

1-08

0	Yes
1	No

1-09

0	No
1	Yes

EXIT

MENU 2

1. Press the power button.

2. Press the '1' button.

3. Wait for more than 5 seconds.

4. Press the '2-01' button.

5. Press the '1' button.

6. Press the '2-02' button.

7. Press the '1' button.

8. Press the '2-04' button.

9. Press the '1' button.


10. Press the '2-08' button.

11. Press the '1' button.

12. Press the '2-09' button.

13. Press the '1' button.

EXIT



RESET

