

# **COUNTIS E5x**

## Active energy meters

three-phase - connection to current transformers up to 6000 A - door mounting



COUNTIS E53 up to 6000 A via CT

#### **Function**

The **COUNTIS E5x** is a panel mounted active and reactive electrical energy meter displaying energy and multi-measurement values directly on its large backlit LCD display. It is designed for utilisation on three-phase or single-phase networks with connection via CT and is suitable for applications of up to 6000 A. The CT ratio can be configured by the user via the keypad and the display, or via RS485 MODBUS communication (E53).

#### Common characteristics

- Measurement accuracy: 0.5%.
- · Large backlit LCD display.
- Direct access to multi-measurement and metering values.
- Detects connection errors.

#### Advantages

# RS485 MODBUS communication or pulse output

To enable the remote reporting of energy consumption, COUNTIS E5x are provided with either a pulse output (E50) or an RS485 MODBUS communication output (E53). Remote configuration of the Countis E53 is

Remote configuration of the Countis E53 is possible via RS485 MODBUS communication.


#### Detection of connection errors

The COUNTIS E5x is protected against phase/neutral inversion and has an integrated test function which can be utilised to detect wiring errors. This function enables CT installation errors to be corrected without having to remake connections. This simplifies the installation and commissioning, thereby reducing associated costs, and ensures that the device operates correctly.

#### Large backlit LCD display

Thanks to its large backlit LCD display and its multiple viewing screens with direct pushbutton access, COUNTIS E5x provide clear readings and are easy to use.

## Principle diagram



They directly display a number of total/partial metering and multi-measurement values :  $\pm$  kWh,  $\pm$  kvarh, kVAh, I, U, V, S, PF, etc.

# Direct display of multi-measurement and metering values

#### Multi-measurement

- Currents: instantaneous: I1, I2, I3
- Voltages: instantaneous: V1, V2, V3, U12, U23, U31
- Power
- instantaneous: 3P, 3Q, 3S
- maximum average: 3P
- Power factor:
  - instantaneous: 3PF

#### Meterina

- Active energy: ± kWh
- Reactive energy: ± kvarh
- Apparent energy: kVAh

# models Key characteristics E50 Pulse output E53 RS485 MODBUS communication

#### The solution for

- > Industry
- > Infrastructure
- > Data centres



#### **Strong points**

- RS485 MODBUS communication or pulse output
- > Large backlit LCD display
- > Detection of connection errors
- Direct display of multimeasurement and metering values

#### **Conformity to standards**

- > IEC 62053-23 class 2
- > IEC 62053-22 class 0.5S
- > IEC 61557-12



#### **Management software**

> To get the most effective use from your Socomec measurement and metering devices, we offer a range of dedicated software tools.

## Associated with current transformers



See "Current transformers".




#### three-phase - connection to current transformers up to 6000 A - door mounting

#### Front panel



- 1. Backlit LCD display
- 2. Energy display and test function key
- 3. Power and power factor display key
- 4. Current and voltage display key
- 5. Programming mode access key

#### Dimensions (mm)



Туре	Panel mounting
Dimensions W x H x D	96 x 96 x 60 mm
Case degree of protection	IP30
Front degree of protection	IP52
Display type	backlit LCD display
Voltage and current connection cross-section	0.5 2.5 mm <sup>2</sup>
Current connection cross-section	1.5 6 mm²
Weight	370 g

- (1)  $I_{(min)} \leq 0.5 * I_{tr}$
- (2) The accuracy class is guaranteed between  $I_{tr}$  and  $I_{max}$ .
- (3)  $I_{\text{(ref)}} = I_{\text{(b)}}$  (base current) = 10 \*  $I_{\text{(tr)}}$  for direct connection COUNTIS.

#### Electrical characteristics

Current measurement				
Туре	three-phase on CT/5A up to 6000 A			
Input consumption	< 0.6 VA			
Startup current (I <sub>st</sub> )	40 mA			
Minimum current (I <sub>min</sub> )	50 mA <sup>(1)</sup>			
Transition current (Itr)	250 mA <sup>(2)</sup>			
Reference current (I <sub>ref</sub> )	5 A <sup>(3)</sup>			
Permanent overload (I <sub>max</sub> )	6 A			
Intermittent overload	50 A for 1 s			
Voltage measurement				
Range of measurement	86 520 VAC			
Input consumption	< 0.1 VA			
Permanent overload	800 VAC			
Energy accuracy				
Reactive (according to IEC 62053-23)	Class 2			
Active (according to IEC 62053-22)	Class 0.5S			
Power supply				
Self-supplied	no			
Auxiliary power supply U <sub>s</sub>	110 400 VAC / 125 350 VDC ±10 %			
Frequency	45 65 Hz			
Output (pulsed)				
Number	1			
Type	100 VDC - 0.5 A - 10 VA			
Max. number of operations	≤ 10 <sup>8</sup>			
Operating conditions				
Operating temperature	-10 55 °C			
Storage temperature	-20 85 °C			
Relative humidity	95 %			
Communication				
Link	RS485			
Type	2 3 half duplex wires			
Protocol MODBUS® arread	MODBUS RTU			
MODBUS® speed	1400 38400 bauds			

#### References

Туре	COUNTIS E50 Reference	COUNTIS E53 Reference
Pulse output	4850 <b>3010</b>	
RS485 MODBUS communication (1)		4850 <b>3011</b>
Management software for COUNTIS		

(1) 4 tariffs through RS485 communication.

Accessories	To be ordered in multiples of	Reference
Fuse disconnect switches to protect 3-pole voltage inputs (RM type)	4	5701 <b>0018</b>
Fuse disconnect switches to protect the 1-pole + neutral auxiliary power supply (RM type)	6	5701 <b>0017</b>
gG 10x38 0,5 A fuses	10	6012 <b>0000</b>

#### Connection


#### Recommendation:

- For IT earthing systems, it is recommended that the CT secondary is not connected to earth.

- When disconnecting the COUNTIS, the secondary of each current transformer must be short-circuited. This operation can be carried out automatically by a SOCOMEC PTI, an accessory which is included in this catalogue. Please consult us.

3 wires with 2 CTs

### Low voltage balanced network



Use of 1 CT reduces by 0.5% the accuracy of the phases, the current of which is worked out by vector calculation

#### 3/4 wires with 3 CTs L1 S1 L2 L3 <u>S2</u> S1 0 0 liris\_395\_d\_1\_x\_cat V1 V2 V3 VN S1 S2 S1 S2 S1 S2 L<sub>I3</sub>J L<sub>l2</sub>J

Low voltage unbalanced network


#### S1 L2 S1 L3 0 0 S1 S2 S1 S2 S1 S2 V2 V3 VN L<sub>I1</sub>J $L_{12}J$ L<sub>I3</sub>J


Use of 2 CT reduces by 0.5% the accuracy of the phases, the current of which is worked out by vector calculation.

#### Additional information

Communication via RS485 link

**zsocomec** 





AC & DC auxiliary power supply

1. Fuses 0.5 A gG / 0.5 A class CC.